
SHARP

SERVICE MANUAL 维修手册

S76N3VC-ML3W/



VHS VIDEO CASSETTE RECORDER

VHS 盒式磁带录象机

MODELS 型 号

VC-ML3 VC-ML3W

In the interests of user-safety (Required by safety regulations in some countries) the set should be restored to its original condition and only parts identical to those specified should be used.

为了使用者的安全(有些国家用安全规定加以要求),修理本装置时 必须完全保持其原有配件状态,更换只得使用规定者。

CONTENTS

_	_
	₹
=	

SHARP CORPORATION

PRECAUTIONS IN PART REPLACEMENT

When servicing the unit with power on, be careful to the section marked white all over. This is the primary power circuit which is live.

When checking the soldering side in the tape travel mode, make sure first that the tape has been loaded and then turn over the PWB with due care to the primary power circuit.

Make readjustment, if needed after replacement of part, with the mechanism and its PWB in position in the main frame.

- (1) Start and end sensors: D710 and D709
 Insert the sensor's projection deep into the upper hole of the holder (LHLDZ1962AJ00). Referring to the PWB, fix the sensors tight enough.
- (2) Photocoupler RH-FX0004GEZZ: IC901

 Refer to the symbol on the PWB and the anode marking of the part.
- (3) Cam switches A and B (RH-PX0253GEZZ): D714 and D713

 Adjust the notch of the part to the white marker of the symbol on the PWB. Do not allow any looseness.
- (4) Take-up and supply sensors (RH-PX0252GEZZ): D712 and D711

 Be careful not to confuse the setting direction of the parts in reference to the symbols on the PWB. Do not allow any looseness.
- (5) Diode bridge (RH-DX0083GEZZ): D901

 Adjust the + marking of the part to the symbol's cathode marking on the PWB.

零件更换时的注意事项

在需要对本录象机进行带电保养检查时,对所有注有白色标记的部分均应特加小心注意。 注有白色标记的部分为初级电源电路部分。

在进行走带状况检查调整过程中检查印刷电路板焊线面时,应先确认磁带的装挂状态符合要求,再边注意初级电源电路边翻转其印刷电路板进行检查。

如更换了零件,将盒室机构及其印刷电路板安置就位后,重新进行调整。

- (1)带头、带尾感应器:D710、D709 将两感应器的凸销分别深插于插座 (LHLDZ1962AJ00) 上面插孔之中,并相对于盒室机构 分别将其紧固之。
- (2)光电耦合器 (RH-FX0004GEZZ): IC901 参照盒室机构印刷电路板以及该部件阳极端的标记。
- (3) 凸轮开关A和B (RH-PX0253GEZZ): D714和D713 调该部件的槽口部于盒室机构印刷电路板的白色标记处。扣紧之 切勿让其产生任何松 动。
- (4)卷带盘、供带盘感应器 (RH-PX0252GEZZ): D712和D711 参照盒室机构印刷电路板上的所有标记,切勿混淆这两个感应器的设定方向。扣紧之, 切勿让其产生任何松动。
- (5) 二极管电桥(RH-DX0083GEZZ): D901 调该零件的十标记于盒室机构印刷电路板上的阴极处。

1. SPECIFICATIONS

Format: VHS PAL, MESECAM, NTSC standard

Video recording system: Two rotary head helical scan system

Video signal: PAL/SECAM/NTSC colour or monochorome signal

Recording/playing time: 240 min. max. with SHARP E-240 tape (PAL/MESECAM: SP mode) 480 min. max. with SHARP E-240 tape (PAL/MESECAM: LP mode)

160 min. max. with SHARP T-160 tape (NTSC: SP mode) 480 min. max. with SHARP T-160 tape (NTSC: EP mode)

Tape width: 12.7mm

Tape speed: 23.39 mm/s (PAL/MESECAM: SP mode)

11.70 mm/s (PAL/MESECAM: LP Mode)

33.35 mm/s (NTSC: SP mode) 16.68 mm/s (NTSC: LP mode) 11.12 mm/s (NTSC: EP mode)

Antenna: 75 ohm unbalanced

Receiving channel: VHF Channel E2 - S41, UHF Channel E21 - C57

RF converter output signal: UHF Channel E30 - E39 Preset to E39 (SINGAPORE)

UHF Channel E30 - E39 Preset to E36 (HONG KONG)

Power requirement: AC110 - 240V, 50/60Hz Power consumption: Approx. 25W (220V/50Hz)

Operating temperature: 5°C to 40°C
Storage temperature: -20°C to 55°C

Weight: 4.9kg

Dimensions: 430 mm (W) x 350 mm (D) x 97 mm (H)

Video

Input: 0.5 - 2.0 Vp-p, 75 ohm

Output: 1.0 Vp-p, 75 ohm S/N ratio: 45 dB min. (PAL-SP)

Horizontal resolution: 250 lines (PAL-SP)
Audio 0 dBs = 0.775 Vrms

Audio 0 dBs = 0.775 Vrms
Input: Line: -8 dBs/47k ohm
Output: Line: -8 dBs/1k ohm
S/N ratio: 42 dB min. (Normal)

HiFi dynamic range: 85 dB typ.

Frequency responce: 80 Hz ~ 10 kHz (Normal SP)

80 Hz - 5 kHz (Normal LP/EP)

20 Hz - 20 kHz (Hi-Fi)

Accessories included: 75 ohm coaxial cable

Operation manual Infrared remote control

Battery AV cable

> As part of our policy of continuous improvement, we reserve the right to alter design and specifications without notice.

Note: The antenna must correspond to the new standard DIN 45325

(IEC 169 - 2) for combined UHF/VHF antenna with 75 ohm connector.

1规格

形式: VHS(家庭用录象机)PAL,MESECAM,NTSC标准型

视频记录方式: 双旋转磁头螺旋形扫描方式

视频信号: PAL/SECAM/NTSC 制式彩色或黑白信号

记录再现时间: 夏普 E-240 录象磁带最大 240 分钟(PAL/MESECAM: SP 方式)

夏普 E-240 录象磁带最大 480 分钟(PAL/MESECAM: LP 方式)

夏普 T-160 录象磁带最大 160 分钟(NTSC, SP 方式) 夏普 T-160 录象磁带最大 480 分钟(NTSC, EP 方式)。

磁带带宽: 12.7 毫米

走带速度: 23.39毫米/秒(PAL/MESECAM: SP 方式)

11.70毫米/秒(PAL/MESECAM, LP 方式)

33.35 毫米/秒(NTSC: SP 方式)

16.68毫米/秒(NTSC: LP 方式)

11.12毫米/秒(NTSC: EP 方式)

天线: 75 欧姆,非平衡式

接收频道: VHF(甚高频)頻道 E2-S41, UHF(超高频)頻道 E21-C57

射频变换器输出信号: UHF(超高频)频道 E30~E39,出厂预设为频道 E39(新加坡)

UHF(超高频)频道 E30~E39,出厂预设为频道 E36(香港)

电源: 交流 110~240 伏,50/60 赫兹

消耗功率: 大约 25 瓦(220 伏/50 赫兹)

工作温度: 5℃~40℃

存放温度: -20℃~55℃

重量: 4.8公斤

尺寸: 430(宽)×350(深)×97(高)毫米

视频信号

输入: 0.5~2.0Vp_p,75 欧姆

输出: 1.0Vp_p,75 欧姆

信号噪声比: 45 分贝(PAL-SP 方式)

水平清晰度: 250 线条(PAL-SP 方式)

普频信号: 0分贝=0.775 伏均方根值

输入: 线路输入: -8 分贝/47k 欧姆

输出: 线路输出: -8 分贝/1k 欧姆

信号噪声比: 42 分贝(标准型)

Hi-Fi 动态范围: 85 分贝

频率响应: 80Hz~10kHz(标准型 SP 方式)

80Hz~5kHz(标准型 LP/EP 方式)

20Hz \sim 20kHz(Hi-Fi)

附件: 75 欧姆同轴联接电缆

使用说明书

红外线遥控器

电池

AV 电缆

由于电子产品不断更新换代,有不经预告而改变设计及其规格的情况。

注: 天线应使用符合 DIN45325(IEC169—2)新标准的带有 75 欧姆连接器的 UHF/VHF 型天线。

A CONTRACTOR OF THE PARTY OF TH

2. DISASSEMBLY AND REASSEMBLY

2-1 DISASSEMBLY OF MAJOR BLOCKS

TOP CABINET **BOTTOM PLATE** : Remove 4 screws 1.

:Remove 2 screws 2 and 6

screws 3.

FRONT PANEL

: Remove 2 screws 4. Remove SHUTTLE switch knob (5) and volume knob (6). Remove 6 clips 7). Remove 1 FFC (8). (Note: In reconnecting the ground lead, place the washer on the angle and tighten uphe screw.)

LCD PANEL


: Remove the 3 screws (A). Open the bottom of the LCD panel

about 25 mm (B) and slide it down straight about 15 mm ©.

Now detach the panel.

MPX PWB HOLDER: Remove 4 screw (9) and 1 screw

Hi-Fi PWB HOLDER : Remove 2 screws (f) and 1 screw



OPERATION PWB

: Remove 1 screw (3), 1 FFC (4), 3 connectors (6) and 2 hooks (6).

LCD PWB


:Remove 1 connectors (17), 1 screw (18) and 2 hooks (19).

MPX PWB

: Remove 1 connector ② and 2 connectors ②.

MECHANISM/ MAIN PWB ASSEMBLY : Remove 1 connector 20, 1 screw 20, 1 screw 20, 1 screw 20, 1 screw 20, 2 screws 20 and 1 connector 20.

Remove 1 screw (2) and earth lead. Remove 2 hooks (3). Lift the antenna terminal block and take the mechanism/main PWB assembly out of the main frame. Be careful not to hit the REC TIP switch located below the cassette controller.



ANTENNA TERMINAL BOX Hi-Fi PWB : Remove 1 screw 3.

Lift the mechanism chassis/ cassette controller assembly out of the main PWB. Remove 2 screws ③.

MECHANISM CHASSIS/ connectors ③. : Remove 1 screw ④ and the 2 screws @.

CASSETTE : Remove 2 screws @s.

CASSETTE CONTROLLER

ASSEMBLY

Shield case.

Remove 3 FFCs and 2 connectors © Remove 4 fooks ® from

: Remove 1 connector @ and 4

CONTROLLER

tors 39. Remove 4 fooks 39 from behind the main PWB.

MECHANISM CHASSIS/ CASSETTE CONTROLLER CASSETTE CONTROLLER 38 **ASSEMBLY** 37 Hi-Fi PWB 35 32 37 33 35 (33) Ø ANTENNA TERMINAL **BLOCK BOTTOM VIEW**

2-2 PRECAUTIONS IN REASSEMBLING


MOUTING THE CASSETTE CONTROLLER

Initial setting is indispensable before placing the cassette controller in the mechanism. The initial setting is made in two ways; electrical and mechanical.

Electrical setting:

- (1) Make a short-circuit between TP5005 and TP5006 of the TP plug (TP500*) which is on the operation PWB.
- (2) Plug in the AC power cord and make sure the mechanism is in the initial setting position (*1).
- (3) Unplug the AC power cord. Remove the above short-circuit.

NOTE: This method is used when the mechanism has been already set on its PWB.



Mechanical setting:

Turn the loading motor's pulley feed gear using a screwdriver and be sure that the mechanism is back to its initial setting position (*1). Now place the cassette controller in position. (This method is applicable for the mechanism alone.)

COUPLING THE MECHANISM TO THE PWB

Match the mechanism's projections with the two symbols (round reference and oval sub-reference) on the main PWB. Place the mechanism straight down in position with due care so that the mechanism chassis's outer edges should not damage any parts nearby.


Tighten up the two screws (one for fixing the mechanism and the head amplifier shield, the other on the main PWB's soldering side and located near the loading motor) to fix the mechanism and main PWB. Reconnect the FFC cables (AG, AD and AH) and harnesses (AE and AL) between the mechanism and main PWB.

Parts to pay attention to:


Start and end sensors D710, D709

Record tip switch S701

Take special care of the MC-AC connector (board to board) between the mechanism and main PWB.




3. FUNCTION OF MAJOR MECHANICAL PARTS (TOP VIEW)



No.	Function	No.	Function
1.	Full erase head ass'y Erase the old recording on the tape in the recording mode.	13.	Reverse guide lever ass'y Pulls out the tape and controls the tape drive train height with the upper and lower guides.
3.	Tension arm ass'y Detects the tension of tape while running, and brakes the supply reel disk via the tension band.	16.	Pinch roller lever ass'y Press-fits the tape to the capstan during tape
7.	Supply main brake ass'y	,	running.
	Brakes the supply reel disk to prevent tape slack- ening when the unit is stopped in fast forward or rewind mode.	18.	Loading motor A motive power which drives the mechanism. It transmits the power to the master cam and cas-
9:	Take-up main brake ass'y Brakes the take-up reel disk to prevent tape slackening when the unit is stopped in fast forward or rewind mode.		sette housing control assembly.

(BOTTOM VIEW)



No.	Function	No.	Function
1.	Slow brake lever Gets in contact with the capstan D.D. motor linking to the master cam in the slow still mode,		Limiter pulley ass'y Transmits the power of the capstan D.D. motor to the reel disk via the drive idler.
e · ·	and brakes it to a certain degree.	8.	Shifter
3.	A motive power which runs the tape. It transmits		Transmits the operation of the master cam to break ass'y. loading gear, tension arm and clutch lever.
.	the power via the Drive belt.	9.	Take-up loading gear
4.	Drive belt Transmits the power to run the tape to the Limiter pulley.		Shifts the take-up pole base and guide roller via the loading gear T, and applies the tape around the drum assembly, as well as transmits the power to the loading gears.

4. ADJUSTMENT, REPLACEMENT AND ASSEMBLY OF MECHANICAL UNITS

Here we will describe a relatively simple service work in the field, not referring to the more complicated repairs which would require the use of special equipment and tools (drum assembly replacement, for example).

We are sure that the easy-to-handle tools listed below would be more than handy for periodical maintenance to keep the machine in its original working condition.

TOOLS NECESSARY FOR ADJUSTING THE MECHANICAL UNITS

The following tools are required for proper service and satisfactory repair.

No.	Jig Item	Part No.	Code	Configuration	Remarks
1	Reel Disk Height Adjusting Jig	JiGRH0002	BR	<i>Q</i>	These Jigs are used for checking and
2	Master Plane Jig	JiGMP0001	BY	(6.0)	adjusting the reel disk height.
3	A/C Head Tilt Adjusting Jig	9DAACH-A323U	вх		This Jig is used for setting the A/C head tilt.
	Torque Gauge (90g)	JiGTG0090	СМ		
4	Torque Gauge (1.2kg)	JiGTG1200	CN		These Jigs are used for checking and adjusting the torque of take-up and
5	Gauge Head	JiGTH0006	AW		supply reel disks.
6	Cassette Torque Meter	JiGVHT-063	cz		This cassette torque meter is used fo checking and adjusting the torque o take-up for measuring tape back tension.
	Tension Gauge (300g)	JiGSG0300	BF		There are two gauges used for the tension measurements, 300 g and
7	Tension Gauge (2.0kg)	JiGSG2000	BS		2.0kg.
	Hex Wrench (0.9mm)	JiGHW0009	AE		
8	Hex Wrench (1.2mm)	JiGHW0012	AE		These Jigs are used for loosening of tightening special hexagon type
	Hex Wrench (1.5mm)	JiGHW0015	AE	<u> </u>	screws.
	Alignment Tape (NTSC)	VROATSV	CD		
9	Alignment Tape (PAL)	VROCPSV	ск		These tapes are especially used f
	Hi-Fi Alignment Tape	VROCBFFS	СВ		electrical fine adjustment.
	Alignment Tape	VROCPZJS	CA		
11	Tension Gauge Adapter	JiGADP003	ВК		This Jig is used with the tension gauge Rotary transformer clearance adjuing jig.

No.	Jig Item	Part No.	Code	Configuration	Remarks
12	Special Bladed Screwdriver	JIGDRIVERH-4	AP		This screwdriver is used for adjusting the guide roller height.
14	Torque Driver	JiGTD1200	СВ		This is used to screw down resinmade parts: the specified torque is 5kg.
		JiGDRIVER110-7	AS		This Jig is used for height adjustment of the A/C head and X-position.
15	Box Driver	JiGDRiVER110-4	AV		This Jig is used for replacement of the SI roller.
		JiGDRiVER110-55	AR	6 7	This Jig is used for replacement of the reverse guide.
16	Reverse Guide Height Adjusting Jig	JiGRVGH-F18	BU	T	This Jig is used for height adjustment of the reverse guide.

MECHANICAL PARTS REQUIRING PERIODICAL INSPECTION

Use the following table as a guide to maintain the mechanical parts in good operating condition.

Maintained Parts	500 hrs.	1000 hrs.	1500 hrs.	2000 hrs.	Possible symptom encountered	Remarks
Guide roller ass'y				0		Abnormal rotation or significant vibration
Supply impedance roller				0	requires replaceme	
Supply impedance roller (inner hole and shaft)					Lateral noises Head occasionally blocked	Clean with pure high quality isopropyl alcohol.
Supply impedance roller flange					The design of the second of th	Clean tape contact part
Retaining guide						with the specified cleaning liquid.
Slant pole				0		
Upper and Lower drum ass'y		0	00	0	Poor S/N ratio, no colour Poor flatness of the envelope with alignment tape	Clean tape contact area with the specified cleaning liquid.
Fuil-erase head				0	Poor colour, beating	inquio.
A/C head				0	Sound too small or distorted	
Capstan D.D. Motor				0	No tape running, uneven colour	
Pinch roller				0	No tape running, tape slack	Clean rubber and rubber
Reel belt				0	No tape running, tape slack, no fast forward/rewind motion contact area with specified cleaning	
Tension band ass'y				0	Cassette not loaded or unloaded	
Loading Motor				0	Oddotto not loaded of disease	
Reel idler ass'y				0	No tape running	
Reel pully ass'y						
Clutch gear ass'y				0		
Main supply/take-up brake levers				0	Tape slack	
AHC (Automatic Head Cleaner)		0		0		Replace the roller of the cleaner when it wears down. Just change the AHC roller assembly for new one.

NOTE:	┌ .	Part replacement. Cleaning (For cleaning, use a lint-free cloth dampened with pure isopropyl alcohol). Oil refilling (The indicated point should be lubricated with high quality spindle oil every 1000hrs)
If the	roadir	og is out of the specified value, clean or replace the part.

REMOVAL AND REASSEMBLY OF CASSETTE HOUSING CONTROL ASSEMBLY

• Removal

- 1. Set the cassette ejected condition in the cassette eject mode.
- 2. Unplug the recorder from the main source.
- 3. Follow the procedures below in the specified order.
 - a) Remove the cassette housing installation screws ①.
 - b) Slide and pull out the cassette housing control assembly upward.
- Reassembly




Figure 4-2.



- ① In using a magnet screw driver, be sure to keep it away from the A/C head, FE (Full Erase) head, and the drum.
- ② In removal and reassembly, take care not to hit the cassette housing control assembly and tools against the guide pin, drum, or the like there about.
- 3 Load the cassette once onto the cassette housing control assembly after reassembly.

TO RUN A TAPE WITHOUT THE CASSETTE HOUSING CONTROL ASSEMBLY

- Be sure to make a short-circuit between TP5005 and TP5006, both located on the operation PWB before turning on the power.
- 2. Plug in the power cord.
- 3. Turn on the power switch.
- 4. Open the lid of a cassette tape by hand.
- 5. Hold the lid with two pieces of vinyl tape.
- 6. Set the cassette tape in the mechanism chassis.
- Stabilize the cassette tape with a weight (500g) to prevent floating.
- 8. Perform running test.




Figure 4-1.

- Before installation of the cassette housing control assembly, make a short-circuit between TP5005 and TP5006, both located on the operation PWB. Plug in the power cord. The cassette control drive gear starts and stops just when the big face gear shows in the mechanism chassis window. Engage the tooth 2 of the casecon drive gear with the tooth 3 of the cassette control drive angle as shown in Fig. 4-2, to position the cassette control on the mechanism chassis.
- 2. Follow the procedures for removal in the reverse order.




Figure 4-3.


Note:


The weight should not be more than 500g.


REPLACEMENT AND HEIGHT CHECKING AND ADJUSTMENT OF REEL DISKS

- Removal (Supply and Take-up reel disks)
- 1. Remove the cassette housing control assembly.
- 2. Pull the tension band out of the tension arm.
- 3. Release the supply/take-up auxiliary brake lever by hand, which makes unnecessary removal of the supply main brake and the take-up main brake.
- 4. Open the hook at the top of the reel disk, and remove the reel disk.

<In the EJECT or UL STOP mode>







- 1. Clean the reel disk shaft and apply oil to it.
- 2. Align the phase of the reel disk to that of the reel relay gear, and install a new supply reel disk onto the shaft.
- 3. Replace the tension band around the supply reel disk, and insert it into the hole of the tension arm with the supply auxiliary brake lever released.
- 4. Check the reel disk height.

Notes:

- Take enough care not to deform the tension band during installation of the supply reel disk.
- ② Be careful not to damage the supply main brake and the reel relay gear.

Reassembly (Take-up reel disk)

- 1. Clean the reel disk shaft and apply oil to it.
- 2. Release the take-up auxiliary brake lever to align the phase of the reel disk to that of the reel relay gear and to install a new take-up reel disk onto the shaft.
- 3. Check the reel disk height and reassemble the take-up main brake.

Note:

Take care not to damage the take-up main brake.

After reassembly, check the video search rewind back tension (see page 19), and check the brake torque (see page 21).

Height checking and adjustment Note:

Place the master plane onto the mechanism unit, taking care not to hit the drum (see Figure 4-6).





Figure 4-4.



Set the master plane releasing the reverse guide by a finger.

When the tension band is pressed in the direction of the arrow for removal, the catch is hard to be deformed






Figure 4-5.




Figure 4-6.

 Check that the reel disk is lower than part A but higher than part B. If the height is not correct, readjust the reel disk height by changing the poly-slider washer under the reel disk.

Note:

Whenever replacing the reel disk, perform the height checking and adjustment.




Figure 4-7.

CHECKING AND ADJUSTMENT OF TAKE-UP TORQUE IN FAST FORWARD MODE

- · Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located on the operation PWB. Now turn on the power.

Setting

- Set a torque gauge to zero on the scale. Place it on the takeup reel disk.
- Press the FF button to set the mechanism to the fast forward mode
- To calculate the remaining capacity of the play back mode, slowly rotate the supply reel disk, and then shift it into the forward mode.

Checking

- Turn the torque gauge slowly (one rotation every 2 to 3 seconds) by hand in the take-up direction.
- 2. Check to see if the take-up torque is higher than 69 mN·m (700 gf·cm).




Figure 4-8.

Adjustment

- 1. If the take-up torque is outside the range, clean the capstan D.D. motor pulley, drive belt and limiter pulley with cleaning liquid, then recheck the torque.
- 2. If the take-up torque is still out of range, replace the drive belt. Notes:
- 1. Hold down the torque gauge so that it may not fly off.
- 2. When checking the take-up torque, do not keep the reel disk locked for a longer time.

CHECKING AND ADJUSTMENT OF TAKE-UP TORQUE IN REWIND MODE

- · Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located on the operation PWB. Now turn on the power.

Setting

- Set a torque gauge to zero on the scale. Place it on the supply reel disk.
- Press the REW button to set the mechanism to the rewind mode.
- 3. To calculate the remaining capacity, slowly rotate the take-up reel disk, and then shift it into the rewind mode.

Checking

- Turn the torque gauge slowly (one rotation every 2 to 3 seconds) by hand in the take-up direction.
- 2. Check to see if the take-up torque is higher than 69 mN·m (700 gf-cm).




Figure 4-9.

VC-ML3 **VC-ML3W**

Adjustment

- 1. If the take-up torque is outside the range, clean the capstan D.D. motor pulley, drive belt and limiter pulley with cleaning liquid, then recheck the torque.
- 2. If the take-up torque is still out of range, replace the drive belt. Notes:
- 1. Hold down the torque gauge so that it may not fly off.
- 2. When checking the take-up torque, do not keep the reel disk locked for a longer time.

CHECKING AND ADJUSTMENT OF TAKE-UP TORQUE IN PLAYBACK MODE

- 1. Remove the cassette housing control assembly.
- 2. Make a short-circuit between TP5005 and TP5006, both located on the operation PWB. Now turn on the power.
- 3. Open the lid of the cassette torque meter, and hold it with two pieces of vinyl tapes.
- Load the cassette torque meter into the unit.

CHECKING AND ADJUSTMENT OF TAKE-UP TORQUE IN VIDEO SEARCH REWIND MODE

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located on the operation PWB. Now turn on the power.

- 1. Push the PLAY button to place the ass'y in the playback mode.
- 2. Push the REW button to place the ass'y in the video search rewind mode.

Checking

1. Place the torque gauge on the supply reel disk, and turn it counterclockwise very slowly (one rotation every 1 to 2 seconds) and check that the torque is within the set value 14.0 $\pm\,$ 3.9mN·m (144 ± 40gf·cm).

Set value LP 10.5 ± 3.8 mN·m $(107 \pm 39$ gf·cm)




Figure 4-10.




Figure 4-11.

- 5. Put the weight (500g) on the cassette torque meter.
- 6. Press the REC button to put the unit in REC mode.

Checking

- 1. Check that the torque is in the range of 10.5 \pm 3.8mN·m (107 ±39gf·cm).
- The torque fluctuates due to the rotational deviation of the limiter pulley ass'y. Use the center of the fluctuation as the
- 3. Place the ass'y in the LP record mode, and check that the takeup torque is within the range.

Adjustment

If the take-up torque in the playback mode is outside the range. replace the limiter pulley ass'y.

Stabilize the cassette torque meter to prevent floating.

Set the torque gauge securely on the supply reel disk. If it is not secure, the measurement will be incorrect....

Adjustment

If the take-up torque in video search rewind mode is outside the range, replace the limiter pulley ass'y.

The torque fluctuates due to the rotational deviation of the limiter pulley ass'y. Use the center of the fluctuation at the value.

CHECKING THE VIDEO SEARCH REWIND BACK TENSION

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located on the operation PWB. Now turn on the power.
- Checking
- 1. Push the PLAY button to place the ass'y in the playback mode.
- 2. Push the rewind button to place the ass'y in the video search rewind mode.
- Place the torque gauge on the take-up reel disk, and turn it counterclockwise very slowly (one rotation every 2 to 3 seconds) and check that the torque is within the set value 2.7±1mN·m (28±10gf·cm).




Figure 4-12.

Notes

- 1 Set the torque gauge securely on the take-up reel disk. If it is not secure, the measurement will be incorrect.
- 2 Measure the torque applying the torque gauge's weight.

CHECKING THE PINCH ROLLER PRESSURE

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located on the operation PWB. Now turn on the power.
- Checking

granding states and the state of the state o

Push the PLAY button to place the ass'y in the playback mode.





Figure 4-13.

- 1. Detach the pinch roller from the capstan shaft.
- 2. Set the tension gauge by hooking the tension gauge adapter onto the pinch roller shaft.
- 3. Gradually release the pressure to allow the pinch roller to touch the capstan shaft. When the pinch roller just touches the capstan shaft, read the indication on the gauge.
- 4. Check that the reading of the tension gauge is in the range of 900 to 1200 g.

CHECKING AND ADJUSTMENT OF TENSION POLE POSITION

- · Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located on the operation PWB. Now turn on the power.
- Setting
- 1. Open the lid of cassette tape (E-180), and hold it with two pieces of vinyl tapes.
- 2. Load the cassette tape into the unit.
- 3. Put the weight (500g) on the cassette tape.
- 4. Make the adjustment with the beginning of a E-180 tape.



Checking

 Set a cassette tape, press the REC button and get the tape loaded. Now check the tension pole position.

Adjustment

- 1. If the reading of the cassette torque meter is less than specified, move the tension spring hook toward A.
- 2. If the reading of the cassette torque meter is more than specified, move the tension spring hook toward B.





Figure 4-20.

CHECKING THE BRAKE TORQUE

· Checking the brake torque at the supply side



CCW: 5.9~9.8mN·m (60~100gf·cm) CW: 10~32mN·m (100~330gf·cm)

Figure 4-21.

- . Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located on the operation PWB. Now turn on the power.

Setting

- 1. Set a torque gauge to zero on the scale. Place it on the supply reel disk.
- 2. Switch from the FF mode to the STOP mode.
- 3. Disconnect the AC power plug.

Checking

Rotate the torque gauge (approx. one revolution per 2 seconds) in the clockwise (CW) direction and counterclockwise (CCW) direction of the supply brake so that the reel disk and the indicator of the torque gauge rotate at an equal rate.
 Check that the values are within the range of CW direction = 10 ~32mN·m (100~330gf·cm), CCW direction = 5.9~9.8mN·m (60~100gf·cm), and that the brake torque in the CW direction is at least twice as high as that in the CCW direction.

Checking the brake torque at the take-up side




Figure 4-22.

- Remove the cassette housing control assembly.
- Make a short-circuit between TP5005 and TP5006, both located on the operation PWB. Now turn on the power.
- Setting
- 1. Set a torque gauge to zero on the scale. Place it on the takeup reel disk.
- Switch from the FF mode to the STOP mode.
- Disconnect the AC power plug.

Checking

- 1. Rotate the torque gauge (approx. one revolution per 2 seconds) in the clockwise (CW) direction and counterclockwise (CCW) direction of the take-up brake so that the reel disk and the indicator of the torque gauge rotate at an equal rate. Check that the values are within the range of CCW direction= 9.8~34mN·m (100~340gf·cm), CW direction = 4~8.3mN·m (40~85gf cm), and that the brake torque in the CCW direction is at least twice as high as that in the CW direction.
- Adjustment of the brake torque at the supply side and the take-up side
- 1. If the supply or take-up brake torque is outside the range, clean the supply or take-up reel disk brake lever pad, then recheck the torque.
- 2. If the supply or take-up brake torque is still outside the range, replace the main brake ass'y.

Note:

When the main brake is replaced, perform the height checking and adjustment of reel disks (see page 16), and the brake torque checking.

REPLACEMENT OF A/C (Audio/Control) HEAD

- 1. Remove the cassette housing control assembly.
- 2. Place the unit in the unloading mode, and unplug the power cord.

Removal

- 1. Remove the screw ABC12.
- 2. Unsolder the A/C head PWB soldered to the A/C head assembly.

Notes:

- 1. After replacement, be sure to perform the adjustment of the tape drive train (see page 24). Under any circumstances, avoid touching the head. Clean the head, if touched with your finger, with alcohol.
- 2. Take care that the springs do not fly off when removing the screws ABC.





Figure 4-23.

Replacement

- 1. Solder the removed A/C head PWB onto a new A/C head assembly.
- 2. Using the slide calipers, set 10.3 mm for the height of the A/ C head arm (bottom surface) to the A/C head plate (screw area). (3 places) (See the figure below.)






Figure 4-24.

3. Align the left and of the gear of the A/C head arm to the mark on the chassis, and temporarily tighten the screws ① and ② to allow the A/C head arm to smoothly move.

(Reference: Temporary tightening torque: 0.2 N.m as prefer-





Figure 4-25.

Note:

Take care that the adjustment or height of the A/C head may vary during final tightening if the screws ① or ② is temporarily tightened to be loose.

[A/C head height rough adjustment]






Figure 4-26.

- Set the cassette tape to the mechanism chassis.
- ② Press the PLAY button to the put the unit in the playback
- ③ Roughly adjust the height of the A/C head by turning the screw © until the tape is in the position shown below.




Figure 4-27.

Adjustment

Adjust the screw © visually so that the control head is visible 0.3 to 0.5 mm below the bottom of the tape.

HEIGHT ADJUSTMENT OF REVERSE GUIDE

[Height adjustment of reverse guide]




Figure 4-28.

- 1). Remove open lever (Figure 4-29 (a)).
- ②. In the tape load mode, make adjustment at the 13.38 mm side first and then rotate the reverse guide adjuster nut by 1/10 turn counterclockwise.
- 3. Actually load the unit with a tape, put it in the play mode, and make sure the tape is free from wrinkles near the reverse
- 4. Use a commercially available box driver to turn the height adjusting nut.




Figure 4-29 (a).




Figure 4-29 (b).

ADJUSTMENT OF TAPE DRIVE TRAIN

- Remove the cassette housing control assembly.
- 2. Make a short-circuit between TP5005 and TP5006, both located on the operation PWB. Now turn on the power.
- Check and adjust the position of the tension pole. (See page 19.)
- 4. Check and adjust the video search rewind back tension. (See page 19.)
- Set the A/C head. (See page 22.)
- 6. Rough adjustment of tape drive train.
 - a) Connect the oscilloscope to the test point for PB CHROMA envelope output (TP501). Set the synchronism of the oscilloscope to EXT. The PB CHROMA signal is to be triggered by the head switching pulse (TP502).
 - b) Loosen the setscrew at the lower part of the guide roller, and adjust it with a hexagon wrench (JIGHW0009) so that the guide roller turns smoothly. (Do not overloosen the setscrew, which causes insecurity of the guide roller.) (See Figure 4-30.)



- 1. Place the tracking control in the center position, and adjust the X-position so that the PB CHROMA envelope becomes maximum for easier rough adjustment of the tape drive train.
- 2. In the rough adjustment, pay particular attention to the outlet




Figure 4-32.

Figure 4-33.



Cassette tape Weight of 500g

Figure 4-30.

Figure 4-31.

- c) Set the alignment tape (monoscope pattern) on the reel disk, and place the unit in the playback mode. (Place a 500 g weight on the cassette tape to prevent floating of the cassette tape.)
- d) In the X value adjustment mode (see the Electrical Adjustment), change the envelope waveform from MAX to MIN, and MIN to MAX by pushing the (+) or (-) tracking button, and check a flat response is obtained on the waveform.
- e) If a flat response cannot be obtained, roughly adjust the guide rollers on the supply side and take-up side using an adjusting screw driver until a flat response can be obtained.
- f) Tighten the screw (a) to eliminate wrinkles from the tape of the retain guide flange area. Replace the tape to check the tape on the retain guide

flange area for wrinkles.

- (1) No wrinkle is present. Turn the screw (A) clockwise to generate wrinkles on the tape at the flange area, and then back off the screw (4)
- as far as the wrinkles are just eliminated. (2) Wrinkles are present. Turn the screw (A) counterclockwise as far as the wrinkles are just eliminated.

Reference: If the screw (A) is turned clockwise, wrinkles will be produced on the lower flange.

PB CHROMA envelope (TP501)

CH-1 CH-2

Head switching pulse (TP502)

Figure 4-34.

7. Adjustment of A/C head height and azimuth

a) Connect an oscilloscope to the audio output terminal.

b) Using the alignment tape with linear audio pre-recorded signal of 1 kHz, adjust the screws (B) and (C) to maximize the audio output, and adjust the screw A to eliminate wrinkles from the tape at the retain guide flange. (Refer to P24-6-f.) Repeatedly adjust the screws (B), (C) and (A) in this sequence until the audio output becomes the maximum. (1 to 3 times as ordinary)

c) Using the alignment tape which records a linear audio signal of 6 kHz, finally adjust the screw (B) until the audio

output becomes the maximum.

8. Adjustment of tape drive train and X-Position

a) Connect the oscilloscope to the test points (TP501) for PB CHROMA envelope output. Set the synchronism of the oscilloscope to EXT.

The PB CHROMA signal is to be triggered by the head switching pulse (TP502).

b) Play back the tape drive train alignment tape.

c) Push the (+) or (-) button to change the envelope waveform from MAX to MIN, and MIN to MAX. Adjust the guide roller's height on the supply and take-up sides with an adjusting screw driver, to obtain an envelope waveform that is as flat as possible.

d) If the tape is above or below the helical lead, the PB CHROMA waveform will take the shape shown in Figure 4-25

e) Adjust for maximum flatness of the envelope as the step 6, e) in page 24.

f) Push the (+) or (-) tracking button to check that a flat response is obtained on the envelope waveform.

g) Secure the guide roller by tightening the guide roller setscrew in the unloading mode.

h) Play back the tape drive train alignment tape to check that the envelope waveform does not change.

Г		When the tape is abo	ove the helical lead.	When the tape is be	low the helical lead.
		Supply side	Take-up side	Supply side Take-up sid	
w.	Adjustment	Supply side guide roller rotated in clockwise direction (lowers guide roller) to flatten envelope.	Take-up side guide roller rotated in clockwise direction (lowers guide roller) to flatten envelope.	Supply side guide roller rotated in counterclockwise direction (raises guide roller) to make the tape float above the helical lead. The supply side guide roller is then rotated in the clockwise direction to flatten the envelope.	Take-up side guide roller rotated in counterclock-wise direction (raises guide roller) to make the tape float above the helical lead. The take-up side guide roller is then rotated in the clockwise direction to flatten the envelope.

Figure 4-35.

VC-ML3 VC-ML3W

able.)

- 9. Adjustment of A/C head X-position.
 - a) In the X value adjustment mode (see the Electrical Adjustment), make a short-circuit between TP5005 and TP5006, both located on the operation PWB, to center the tracking.
 - b) Move the A/C head arm with an adjusting gear driver, and adjust the A/C head position for maximum head switching pulse hi side envelope. Finally tighten the screws ① and ②. (First tighten the screw

①, and next the screw ②.) (Figure 4-36①②) (Reference: Final tightening torque: 0.6 N.m as prefer-

c) Adjust the playback switching point.

d) Check the flatness of the envelope waveform and sound by playing back a recorded tape.




Figure 4-36.

REPLACEMENT OF THE CAPSTAN D.D. (DIRECT DRIVE) MOTOR

- Remove the cassette housing control assembly.
- Removal (Follow the order of indicated numbers.)
- 1. Disconnect from the board-to-board connector on the main
- 2. Remove the drive belt ①.
- 3. Remove the screws 2.

Reassembly

- 1. Mount the capstan motor on the mechanism chassis making sure not to allow the capstan shaft to hit the mechanism chassis, and attach it with the three screws.
- 2. Attach the reel belt. Reconnect to the board-to board connector on the main PWB.

Notes:

- 1. After installing the capstan D.D. motor, be sure to rotate the capstan D.D. motor and check the movement.
- 2. Check the servo circuit.

REPLACEMENT OF DRUM D.D. MOTOR

- 1. Put the unit in the cassette eject position.
- 2. Unplug the power cord.


Removal (Reverse the order in reassembly.)

- 1. Disconnect the FFC cable ①.
- 2. Unscrew the D.D. stator assembly fixing screws 2.
- 3. Take out the D.D. stator assembly (3).
- Unscrew the D.D. rotor assembly fixing screws 4.
- 5. Take out the D.D. rotor assembly ⑤.


- 1. In removing the D.D. stator assembly, part of the drum earth spring pops out of the pre-load collar. Be careful not to lose it.
- 2. Secure the D.D. rotor assembly so that the installation positioning holes in the D.D. rotor assembly and upper drum assembly match.

(Match the upper drum's notch with the rotor's hole.)

- 3. Be careful not to damage the upper drum or the video head.
- 4. Be sure that the hall device and the D.D. stator assembly are not damaged by the D.D. rotor assembly or other parts.
- 5. After installation, adjust the playback switching point.









ASSEMBLE THE MECHANISM'S PARTS REQUIRING THE PHASE MATCHING IN THE STEPS BELOW.

- Assembling the pinch roller assembly, reverse guide assembly and the pinch drive cam (on the front of the mechanism chassis).
- 2. Mounting the shifter (on the back of the mechanism chassis).
- 3. Mounting the master cam (on the back of the mechanism chassis).
- Mounting the connection gear, slow brake and loading motor assemblies (on the back of the mechanism chassis).
- 1. Assembling the pinch roller assembly, reverse guide assembly and the pinch drive cam (on the front of the mechanism chassis).

Place the following parts in position in numerical order.





② Insert Pinch Drive Cam

Tum the reverse guide lever assembly counterclockwise to the stopper.

Insert the pinch drive cam, aligning its notch to the projection on the pinch drive lever assembly.

Insert the pinch drive lever assembly, aligning its notch to the projection on the chassis.

Pinch drive lever ass'y

Figure 4-40-1.

VC-ML3W

③ Insert Pinch Roller/Pinch Double Action Lever Ass'y.




Figure 4-40-2.

(4) Insert Open Lever.





Figure 4-40-3.

2. Mounting the shifter (on the back of the mechanism chassis).



- 1. Make sure that the loading gear is at the point ① as shown below.
- 2. Place the shifter in position, keeping in mind the 6 insertion points and the three relief points.
- 3. For the phase matching at the insertion point ①, see the point② as shown below.
- 4. Finally fix the shifter with two washers located on insert points (1) and (4).




Figure 4-42.

VC-ML3 VC-ML3W

3. Mounting the master cam (on the back of the mechanism chassis).

- (1) Make sure beforehand that the shifter is at the point as shown
- (2) Place the master cam in the position as shown below.

Note:

See the figure below for the phase matching between the master cam and the cassette control drive gear.

(3) Finally fix the master cam with E ring.




Figure 4-43.

REPLACEMENT OF LOADING MOTOR

Removal

Remove 2 screws.




Figure 4-44.

Replacement

① Take out the old loading motor. Place a replacement loading motor as shown above (Figure 4-44.).




Figure 4-45.

Press-fit the loading motor pulley with a force of less than 98N (10 kgf). Be sure that the pulley is 7.7 $^0_{-0.1}$ mm away from the motor.

ASSEMBLY OF CASSETTE HOUSING

① Framer ass'y




Figure 4-46.

② Synchro Gear, Drive Gear L and Drive Gear R




Figure 4-47.




Figure 4-48.

5. ELECTRICAL ADJUSTMENT

Notes:

Before the adjustment:

Electrical adjustments discussed here are often required after replacement of electronic components and mechanical

Check that the mechanism and all electric components are in good working condition prior to the adjustments, otherwise adjustments can not be completed.

- Instruments required:
 - O Colour TV monitor
 - Audio signal generator
 - ODC voltmeter
 - OBlank video cassette tape
 - Screwdriver for adjustment
 - OColour bar signal generator

- O Dual-trace oscilloscope
- O AC milli-voltmeter
- O Frequency counter
- Alignment tape (VROCPSV)
- Alignment tape (VROATSV)
- O Alignment tape (VROCBFFS)
- Alignment tape (VROCPZJS)

Servicing precations

When the IC703 (E²PROM) has been replaced, make the following reprogramming. Depending on models, the IC703 (E2PROM) has been factry-adjusted for it's memory function.

It's therefore necessary to reprogram the memory function for the model in question.

Note that the servo circuit requires readjustments for the head switching point, slow and still modes.

Location of controls and test points




Figure 5-1.

SERVO CIRCUIT ADJUSTMENT

ADJUSTMENT OF PAL SYSTEM HEAD SWITCHING POINT

Measuring instrument	Dual-trace oscilloscope Colour TV monitor
Mode	Playback
Cassette	Alignment tape (VROCPSV)
Test point	TP502 (H.SW.P.) to CH-1, VIDEO OUT jack to CH-2 (CH-1 trigger slope switch at (+), Internal trigger at CH-1 side.)
Specification	6.5 ± 0.5H (lines)

 Remove the front panel and play the alignment tape. (VROCPSV)

(Playback picture on the monitor screen.)

 Make for a moment short-circuit between TP5001 and TP5002, both located on the operation PWB.
 Make the test points short-circuited and see if the REC LED and the TIMER LED light up.
 (See Note below ①)

- 3. Press the PLAY button, in the automatic adjustment mode.
- Make sure the REC LED is flashing during the automatic adjustment.
- 5. When the automatic adjustment is over, the REC LED goes out.
- 6. Press the STOP button to return to normal mode.
- 7. Make sure the head switching point has been properly adjusted. Play back the alignment tape and check to seeif the waveform on the oscilloscope screen is as shown in figure 5-2.

If out of spec, call the test mode again. Press the FF or REW button to get the specified value.

Note:

- ① Set-up of TEST mode.
 - When the adjustment of HEAD SWITCHING POINT, AUTO TRACKING function is invalid.
- ② When the cassette housing control ass'y is removed, set-up of mechanism operating mode.
- 1) Replug the AC power cord it a few minutes later.
- Make a short-circuit between TP5005 and TP5006, both located on the operation PWB, to center the tracking.
- 3) AC power cord is plugged in.
- 4) You can make mechanism operating mode.




Figure 5-2.

ADJUSTMENT OF PAL SYSTEM SP/LP SLOW TRACKING PRESET

Measuring instrument	Colour TV monitor
Mode	Playback
Cassette	Self-recorded tape (SP/LP mode) (See Note below)
Control	Tracking control buttons (+) or (-)
Specification	Minimized noise on monitor screen

- Have the unit to receive a good TV broadcast or feed a video signal to the VIDEO IN jack.
- Set the tape speed in SP mode by using the remote control and record the signal on tape.
- 3. Rewind and play the tape where signal was recorded in above step.
- 4. Press the SLOW button on the remote control,and playback the recorded portion in the slow mode.
- Make for a moment short-ciucuit between TP5001 and TP5002, both located on the operation PWB.
 Make the test points short-circuited and see if the REC LED and the TIMER LED light up.
- 6. Look at the monitor screen and adjust the (+) or (-) TRACKING buttons so that the there is noise disappears from the screen.
- 7. Press the STOP button to return to normal mode.
- 8. Play the tape a few seconds then press the SLOW button again and make sure there is no noise in the screen.

(For the LP mode put adjustment at the same adjustment way as SP mode.)

Notes:

Self-recorded tape means a cassette whose program was recorded by the unit being adjusted.

ADJUSTMENT OF PAL SYSTEM FV (False Vertical Sync) OF STILL PICTURE

7CH(10th 0 y 11-)		
Measuring instrument	Colour TV monitor	
Mode	Playback still	
Cassette	Self-recorded tape (SP mode) (See Note below)	
Control	Tracking control buttons (+) or (-)	
Specification	No vertical jitter of picture	

- 1. Play a cassette which was recorded by the unit in SP mode.
- 2. Press the PAUSE/STILL button to freeze the picture.
- 3. Look at the monitor screen and adjust (+) or (-) TRACKING buttons so that the vertical jitter of the picture to be minimized.
- 4. Play and freeze the self-recorded tape in SP mode and make sure vertical jitter of the picture is not noticeable.
 - (For the LP mode put adjustment at the same adjustment way as SP mode.)

Note:

Self-recorded tape is a cassette whose program was recorded by the unit being adjusted.

ADJUSTMENT OF NTSC SYSTEM HEAD **SWITCHING POINT**

Measuring instrument	Dual-trace oscilloscope Colour TV monitor
Mode	Playback
Cassette	Alignment tape (VROATSV)
Test point	TP502 (H.SW.P.) to CH-1, VIDEO OUT jack to CH-2 (CH-1 trigger slope switch at (+), Internal trigger at CH-1 side.)
Specification	6.5 ± 0.5H (lines)

- 1. Remove the front panel and play the alignment tape. (VROATSV)
 - (Playback picture on the monitor screen.)
- 2. Make for a moment short-circuit between TP5001 and TP5002, both located on the operation PWB. Make the test points short-circuited and see if the REC LED and the TIMER LED light up. (See Note below 1)

():

- 3. Press the PLAY button, in the automatic adjustment mode.
- 4. Make sure the REC LED is flashing during the automatic adjustment.
- 5. When the automatic adjustment is over, the REC LED goes out.
- 6. Press the STOP button to return to normal mode.
- 7. Make sure the head switching point has been properly adjusted. Play back the alignment tape and check to seeif the waveform on the oscilloscope screen is as shown in figure 5-3.
 - If out of spec, call the test mode again. Press the FF or REW button to get the specified value.

Note:

- Set-up of TEST mode.
 - When the adjustment of HEAD SWITCHING POINT, AUTO TRACKING function is invalid.
- ② When the cassette housing control ass'y is removed, set-up of mechanism operating mode.
- 1) Replug the AC power cord it a few minutes later.
- 2) Make a short-circuit between TP5005 and TP5006, both located on the operation PWB, to center the tracking.
- 3) AC power cord is plugged in.
- 4) You can make mechanism operating mode.
- (3) With the PAL system head switching point already adjusted, it is not necessary to adjust the NTSC system head switching point. Just observe the waveform at the above test point and makes sure that it is as specified.




Figure 5-3.

ADJUSTMENT OF NTSC SYSTEM SP/EP SLOW TRACKING PRESET

Measuring instrument	Colour TV monitor
Mode	Playback
Cassette	Self-recorded tape (SP/EP mode) (See Note below)
Control	Tracking control buttons (+) or (-)
Specification ,	Minimized noise on monitor screen

- Have the unit to receive a good TV broadcast or feed a video signal to the VIDEO IN jack.
- 2. Set the tape speed in SP mode by using the remote control and record the signal on tape.
- 3. Rewind and play the tape where signal was recorded in above step.
- Press the SLOW button on the remote control, and playback the recorded portion in the slow mode.
- 5. Make for a moment short-ciucuit between TP5001 and TP5002, both located on the operation PWB. Make the test points short-circuited and see if the REC LED and the TIMER LED light up.
- Watching the monitor screen, adjust the tracking (+) and (-) buttons so that the noise on the screen be minimum.
- 7. Press the STOP button to return to normal mode.
- Play the tape a few seconds then press the SLOW button again and make sure there is no noise in the screen.
 - (For the EP mode put adjustment at the same adjustment way as SP mode.)

Notes

Self-recorded tape means a cassette whose program was recorded by the unit being adjusted:

ADJUSTMENT OF NTSC SYSTEM FV (False Vertical Sync) OF STILL PICTURE

Measuring instrument	Colour TV monitor
Mode	Playback still
Cassette	Self-recorded tape (SP mode) (See Note below)
Control	Tracking control buttons (+) or (-)
Specification	No vertical jitter of picture

- Play a cassette which was recorded by the unit in SP mode.
- 2. Press the PAUSE/STILL button to freeze the picture.
- 3. Look at the monitor screen and adjust (+) or (-) TRACKING buttons so that the vertical jitter of the picture to be minimized.
- 4. Play and freeze the self-recorded tape in SP mode and make sure vertical jitter of the picture is not noticeable.
 - (For the LP mode put adjustment at the same adjustment way as SP mode.)

Note:

Self-recorded tape is a cassette whose program was recorded by the unit being adjusted.

ADJUSTMENT OF NTSC SKEW COMPEN-SATION

Measuring instrument	Colour TV monitor
Mode	Playback still (SP mode)
Cassette	Alignment tape (VROATSV)
Control	R5410 (Flicker control)
Specification	No flicker on the monitor TV screen


- 1. Play the alignment tape (VROATSV) and place the unit to the playback still mode.
- 2. Look at the monitor screen and adjust R5410 so that the flicker of the picture to be minimized.

Y/C CIRCUIT ADJUSTMENT

CHECKING OF VIDEO E-E LEVEL

Measuring instrument	Oscilloscope
Mode	E-E or Record
Input signal	EIA colour bar (1.0Vp-p PAL and NTSC system)
Test point	VIDEO OUT jack
Specification	1.0 ± 0.2Vp-p

- 1. Connect a 75 ohm terminating resistor to the VIDEO OUT jack and connect an oscilloscope across this terminating resistor. (See Note below.)
- 2. Feed a colour bar signal to the VIDEO IN jack.
- 3. Make sure that the E-E signal amplitude is 1.0Vp-p as shown in Figure 5-4.
- 4. For the NTSC mode, put to checking in the same way as PAL mode.



Notes:

If the 75 ohm terminating resistor is missing, the signal amplitude will be doubled.

CHECKING OF WHITE CLIP LEVEL

Measuring instrument	Oscilloscope
Mode	E-E or Record (PAL LP/NTSC EP mode)
Input signal	EIA colour bar (1.0Vp-p PAL and NTSC system)
Test point	Pin(48) of IC401, GND
Specification	190 \pm 5% (See note below)

- 1. Connect a oscilloscope to pin(48) of IC401 and GND.
- 2. Feed the colour bar signal to the VIDEO IN jack and set the unit in E-E or recording mode.
- 3. Make sure that the overshoot of the video signal is clipped at 190% as shown in Figure 5-5.
- 4. For the NTSC mode, put to checking in the same way as PAL mode.




Figure 5-5.

Note:

From sync tip to white peak, the level is 100%. The white clip level is 90% above the white level.

CHECKING OF RECORD LEVEL

CHECKING O.	
Measuring instrument	Dual-trace oscilloscope
Mode	Record mode (PAL LP/NTSC EP mode)
Input signal	EIA colour bar (1.0Vp-p PAL and NTSC system)
Test point	Chroma (Red) R514 terminal lead at L509 side (Sig.) ~ GND Sync tip R225 terminal lead at L210 side (Sig.) ~ GND
Specification	Chroma (Red): 170~230mVp-p Sync tip: 720~880mVp-p

1)

- 1. Feed the colour bar signal to the VIDEO IN jack and set the unit in recording mode.
- 2. Connect a dual -trace oscilloscope to each test point shown in table.
- 3. Make sure so that the amplitude of the chrome (Red) portion and the sync tip portion are specified as shown in Figure 5-6.
- 4. For the NTSC mode, put to checking in the same way as PAL mode.




Figure 5-6 (a).

Figure 5-6 (b).


CHECKING OF PLAYBACK LEVEL

_ · · ·	
Measuring instrument	Oscilloscope ·
Mode	Record/Playback (PAL LP/NTSC EP mode)
Input signal	EIA colour bar (1.0Vp-p PAL and NTSC system)
Test point	VIDEO OUT jack
Specification	1.0 ± 0.2Vp-p

- 1. Be sure that E-E level has been correctly specificed.
- Connect a 75 ohm terminating resistor to the VIDEO OUT jack and connect an oscilloscope across this terminating resistor. (See Note below.)
- 3. Feed a colour bar signal to the VIDEO IN jack and set the unit in recording mode.
- 4. Play the colour bar portion of the recorded tape.
- 5. Make sure that the output signal amplitude is 1.0Vp-p as shown in Figure 5-7.
- 6. For the NTSC mode, put to checking in the same way as PAL mode.

Note:

If the 75 ohm terminating resistor is missing, the signal amplitude will be doubled.



ADJUSTMENT OF S. PICTURE

Colour TV monitor
Record/Playback (PAL SP mode)
Monoscope signal
TP402 (Sig) ~ TP403 (GND)
R430 (S. Picture control)

- Record the PAL monoscope signal in the SP mode. Play back the signal.
- 2. Connect a 1M ohm resistor between the test points TP402 (SIG) and TP403 (GND).
- 3. With the picture perfect on the monitor screen, slowly turn R430 (S.PICTURE control) until there will be problem with the picture.
- 4. Then disconnect the above resistor, Finally make sure the picture on the screen turns perfect again.


CHECKING OF PLAYBACK LEVEL

Measuring instrument	Oscilloscope
Mode	Record/Playback (PAL LP/NTSC EP mode)
Input signal	EIA colour bar (1.0Vp-p PAL and NTSC system)
Test point	VIDEO OUT jack
Specification	1.0 ± 0.2Vp-p

- 1. Be sure that E-E level has been correctly specificed.
- Connect a 75 ohm terminating resistor to the VIDEO OUT jack and connect an oscilloscope across this terminating resistor. (See Note below.)
- 3. Feed a colour bar signal to the VIDEO IN jack and set the unit in recording mode.
- 4. Play the colour bar portion of the recorded tape.
- 5. Make sure that the output signal amplitude is 1.0Vp-p as shown in Figure 5-7.
- 6. For the NTSC mode, put to checking in the same way as PAL mode.

Note:

If the 75 ohm terminating resistor is missing, the signal amplitude will be doubled.



ADJUSTMENT OF S. PICTURE

Measuring instrument	Colour TV monitor
Mode	Record/Playback (PAL SP mode)
Input signal	Monoscope signal
Test point	TP402 (Sig) ~ TP403 (GND)
Control	R430 (S. Picture control)
Specification	

- 1. Record the PAL monoscope signal in the SP mode. Play back the signal.
- 2. Connect a 1M ohm resistor between the test points TP402 (SIG) and TP403 (GND).
- 3. With the picture perfect on the monitor screen, slowly turn R430 (S.PICTURE control) until there will be problem with the picture.
- 4. Then disconnect the above resistor, Finally make sure the picture on the screen turns perfect again.

Hi-Fi AUDIO CIRCUIT ADJUSTMENT. IMPORTANT NOTES ON HI-FI SECTION.

 Though adjustment procedures are written for the left channel, those for the right channel are basically the same.

Words shown in the bracket "[]" are for the right channel only.

- 2. SERVICING OF THE Hi-Fi block.
 - 1) "RECORD MODE".

Under this condition record a stereo broadcast on tape and adjust control.

2) "PLAYBACK MODE".

Under this condition play a Hi-Fi tape and adjust control.

(You can select the audio output channels in the playback mode by pressing the MENU button on the remoto control or the SET UP button on the VCR. Set the desired Audio Output mode by pressing the (+) or (-) button.

The Audio Output mode will change in the normally select Hi-Fi L+R mode with the pressing the (+) or (-) button both the L and R audio channels are taken from the Hi-Fi mode track. The L and R indicators light up on the Multi-function display in this mode.)

· Location of controls and test points




Figure 5-8.

CHECKING OF E-E LEVEL

Measuring instrument	AC milli-voltmeter
Mode	E-E or REC mode
Input signal	1kHz, -8dBs
Test point	AUDIO OUT jack
Specification	-8 ± 2dBs

- Feed the audio signal shown in table to the left channel of the AUDIO IN jack.
- Connect an AC milli-voltmeter to the left channel of the AUDIO OUT jack and right channel of the AUDIO OUT jack
- 3. Put the unit in E-E or record mode and make sure that the milli-voltmeter read is specified value.

NOTE:

Check the level is less than 2dBs both Left and Right channels.

ADJUSTMENT OF FM CARRIER FREQUENCY

Measuring instrument	Frequency counter
Mode	E-E or REC mode
Input signal	Not required
Test point	TP6301 (Sig.) ~ TP6302 (GND)
Controls	R6310 [R6363] NTSC Carrier frequency control R6308 [R6365] PAL Carrier frequency control
Specification	1.3 [1.7] MHz ± 5kHz (at NTSC mode) 1.4 [1.8] MHz ± 5kHz (at PAL mode)

- 1. Put the unit in A/V input mode. Do not feed any signal to the VIDEO IN JACK.
 - (Disconnect any cable from video input terminal.)
- Put the unit in E-E or recording mode and connect a frequency counter to test points TP6301 (Sig.) and TP6302 (GND).
- Put the unit in NTSC mode and adjust R6310 [R6363] (NTSC carrier control) so that the counter read is specified value.
- 4. In the next, place the unit in PAL mode and adjust R6308 [R6365] (PAL carrier control) so that the counter read is specified value.

CHECKING OF LINEAR AUDIO PLAYBACK LEVEL

Measuring instrument	AC milli-voltmeter
Mode	Playback
Input signal	Alignment tape.(VROCPZJS)
Test point	AUDIO OUT jack
Specification	-12.0 ± 2dB

- 1. Connect an AC milli-voltmeter to the AUDIO OUT jack.
- 2. Playback the Alignment tape. (VROCPZJS)
- 3. Make sure that the output level is as specified.

CHECKING OF Hi-Fi AUDIO PLAYBACK LEVEL

Measuring instrument	AC milli-voltmeter
Mode	Playback
Cassette	Alignment tape (VROCBFFS)
Test point	AUDIO OUT jack
Specification	-8.0 ± 2dBs (at RCA jack)

- Connect an AC milli-voltmeter to the AUDIO OUT jack.
- 2. Play the alignment tape (VROCBFFS).
- 3. Make sure that the AUDIO OUT level is as specified.

Check the PLAYBACK level is less than 2.0dBs both Left and Right channels.

CHECKING OF HI-FI/LINEAR AUDIO SELF-RECORD/PLAYBACK LEVEL

Measuring instrument	AC milli-voltmeter
Mode	Record/playback
Input signal	1kHz, -8.0dBs
Test point	AUDIO OUT jack
Specification	-8.0 ± 3dBs

- 1. Feed the audio signal shown in table to the Left channel AUDIO IN jack.
- Connect an AC milli-voltmeter to the Left channel AUDIO OUT jack and Right channel AUDIO OUT jack.
- Make sure so that the milli-voltmeter reads spcified value.

Note:

CHeck the PLAYBACK level is less than 2.0dB both Left and Right channels.

CHECKING OF ERASE VOLTAGE AND OSCILLATION FREQUENCY

Measuring instrument	Oscilloscope
Mode	Record
Cassette	Full erase head
Test point	T6301
Specification	70 ± 5kHz, 40Vp-p or greater


- 1. Put the unit in record mode.
- 2. Connect an oscilloscope across the full erase head.
- 3. Make sure the erase voltage across the full erase head is approx. 40Vp-p or more and frequency is 70 ± 5kHz.

LCD DISPLAY CIRCUIT ADJUSTMENT

CONSTRAST ADJUSTMENT

Measuring instrument	Oscilloscope					
Mode	E-E					
Input signal PAL video signal (white 50%						
Test point	TP8941 (G output) ~ GND(TP8943)					
Control	R8902 (CONTRAST ADJ.)					
Specification	Luminance level to be the same (+0.1Vp-p)					

- 1. In the A/V mode, feed the PAL video signal (white 50%) to the video input terminal.
- Connect the oscilloscope between TP8941 (G output) and GND. Adjust R8902 (contrast control) so that the normal white portion and the inverted one of the G output waveform be at the same level.



H-POSITION ADJUSTMENT

Measuring Colour Monitor TV instrument						
Mode	Playback					
Cassette	Alignment tape (VROCPSV)					
Control	R9021 (H-POSITION ADJ.)					
Specification	Monoscope pattern to be centered on screen					

- 1. Play back the alignment tape (VROCPSV).
- Observing the monitor screen, turn R9021 (H-position control) until the monoscope pattern gets centered on the screen.

COMMON BIAS ADJUSTMENT (ROUGH ADJUSTMENT)

Measuring instrument	DC voltmeter			
Mode	E-E			
Input signal PAL video signal (white 50%)				
Test point	TP9045 (COM-BIAS ADJ.)			
Control	R9061 (COM-BIAS ADJ.)			
Specification	1.5 ± 0.1Vp-p			

- In the A/V mode, feed the PAL color bar signal to the video input terminal. Connect the DC voltmeter between TP9045 (common bias) and GND.
- Turn R9061 (common bias control) until the DC voltmeter reading becomes 1.5V.

WHITE BALANCE ADJUSTMENT

Measuring instrument	Oscilloscope
Mode	E-E
Input signal	PAL video signal (white 50%)
Test point	TP8941 (G output) - GND, TP8940 (R output) - GND, TP8942 (B output) - GND
Control	R8966 (SUB BRIGHT-R ADJ.), R8961 (SUB BRIGHT-B ADJ.)
Specification	Luminance level to be the same (+0.1Vp-p)

- Before making this adjustment, make sure that the contrast has been completely adjusted.
- Call the A/V input mode and feed the PAL vudeo signal (50% white) to the video input terminal.
- Connect the oscilloscope between TP8940 and GND, and adjust R8966 to have the specified luminance value. Reconnect the oscilloscope between TP8942 and GND, and adjust R8961 to have the same luminance level.




Figure 5-10.

BURSTCLEANING ADJUSTMENT (IN PAL MODE ONLY)

Measuring instrument	Oscilloscope				
Mode E-E (BLUE BACK mode)					
Input signal No signal					
Control	C8911 (PAL COLOUR BURST ADJ.)				
Specification	Make such adjustment that the will be no horizontal streaks.)				

- 1. In the PAL mode, make the blue background on the LCD panel.
- 2. Watching the LCD panel, adjust C8911 so that there will be no horizontal streaks. (Be sure to call the PAL mode. In the NTSC mode, the blue background mode does not change with C8911.)

COMMON BIAS ADJUSTMENT (FINE ADJUSTMENT)

Measuring instrument	Colour Monitor TV
Mode	E-E
Input signal	NTSC 10-step-wave video signal
Control	R9021 (H-POSITION ADJ.)
Specification	Vertical stripes to disappear from screen

- 1. In the A/V mode, feed the NTSC 10-step-wave video signal to the video input terminal.
- Observing the monitor screen, slowly turn R9061 (common bias control) until the vertical stripes disappears from the screen.

Note:

Be sure to turn the control slowly. The changing image cannot be observed if the control is turned quickly.

RF CIRCUIT

ADJUSTMENT OF RF AGC CIRCUIT

Measuring instrument	Oscilloscope
Mode	Good TV Commercial broadcast reception
Test point	TP1553 (Sig.) TP1554 (GND) (Located on the main PWB)
Control	VR101 RF AGC control (Located on IF PACK)
Specification	Just before shrinking (See Figure 5-9)

- Have the unit received good TV commercial broadcast reception.
 - (Input field stregth: 85 dBμV of antenna terminal.)
- 2. Connect an oscilloscope to test points TP1553 (Sig.) TP1554 (GND).
- 3. Observe the video output terminal waveform on the oscilloscope.
 - Adjust VR101 (RF AGC control) in the IF pack until the noise disappears from the oscilloscope screen and the waveform nearly comes into sync.




Figure 5-11.

CHECKING OF TUNER AUDIO LEVEL


- Make weighting comparison of the sound volume between in the TV Through mode and in the VCR E-E mode to see if the volume is the same as each other.
- If the volume is not equal, turn the VR102 control on the IF pack to reach the same volume level.


6. MECHANISM OPERATION FLOWCHART AND TROUBLESHOOTING GUIDE


MECHANISM OPERATION FLOWCHART


* This flowchart describes the outline of the mechanism's operation, but does not give its details.


CASSETTE INSERTION → STOP












Replace cassette control ass'y.




Replace T901.


2


Check short-circuit or leak of T901.


Check primary circuit, Q901, Q902, C913 thru to C915, C910 and D925.


∀YES











YES

] [[- 4.6V

D-FG

--- 4.6V Ş

D-PG.

Is the drum PG signal and drum FG signal present on pins (65) and (66) of IC701, respectively?


Is the drum motor rotating?


YES


Check drum motor and the between AD and ME harness.


signals present on pins (5) and (3) of AD connector? Are the drum PG and drum FG


8
























Note: The LCD gives colours in the PAL and NTSC3.58 modes. In the SECAM, NTSC4.43 and NTSC NT-PAL TV modes, however, the unit does not give any colours.



REPLACEMENT OF IC703 (E²PROM)

«Servicing precautions»

When the IC703 (EEPROM) has been replaced, it is necessary to program the memory again.

- 1. Set the unit to the power off mode (power on standby).
- Make an instantaneous short-circuit between TP5001 and TP5002 on the operation PWB. Make sure the REC LED and the timer LED lights up. The unit is now in the test mode and Jumper No. (JP-0) appears on the LCD screen.
- 3. Using the channel (+) and (-) buttons, enter the JP-0 thru JP-31 function numbers (displayed on the LCD screen) on the EEPROM map sequentially. Press the DISPLAY button to turn on a selected function, or the CLEAR button to turn it off.
 - When the DISPLAY button is pressed, the memory function turns on and the REC LED and the timer LED go out.
 - * When the CLEAR button is pressed, the memory function turns off and the REC LED and the timer LED light up.
- 4. Go through the JP-1 to JP-31 entries. Make an instantaneous short-circuit between the test points TP5001 and TP5002 again in order to bring the unit back to the normal mode (clock display).

LOTT						 	 	
	No.	FUNCTION	ML3/ML3W/NL3	мнззо			 	
	JP0	COROUR 0	0	0		 	 	
	1	COROUR 1	0	0		 	 	
	2	VPS PDC	0	0		 	 	
-	3	SPATIALIZER	0	1		 	 	
-	4	VCR 0	0	0		 	 	
	5	VCR 1	0	0	************	 	 	
т	6	SYSTEM 0	1	1		 	 	
i	7	SYSTEM 1	1	1		 	 	
M E	8	R/C CODE	0	1		 	 	
R	9	P-IN-P	0	0		 	 	
	10	LCD	1	0		 	 	
	11		0	0		 	 	•
	12	DUAL SCART	1	1		 	 	·
	13	FRONT A/V	0	0		 	 	
	14	LP/EP	1	1		 	 	
	15	(0: 00) OEM	1	1		 	 	
	16	G-CODE0	1	1		 	 ···	
	17	G-CODE1	0	0		 	 	
	18	NICAM 0	1	1		 	 	
	19	NICAM 1	0	0		 	 	
	20	S. PICTURE	0	0		 	 	
S Y	21	DECODER	0	0		 	 	
S	22	AUTO CLOCK/SORT	г О	0		 	 	
	23	Hi-Fi	1	1		 	 	
N	24	HEAD0	0	1		 	 	
	25	HEAD1	1	0		 	 	
	26	NTSC SKEW	1	. 1		 	 	
	27	INSTANT REPLA	Y 1	1		 	 	
	28		0	0		 	 	
	29		0	0		 	 ·····	
	30		0	0		 	 	
	31		0	0			 	

(Note: "1"; REC LED and the TIMER LED go out ,"0"; REC LED and TIMER LED light up)

2. 分解和组装

2-1主要部件的分解

上部壳盖

: 松去四支固定螺丝(1)

底板

: 松去两支固定螺丝(2)

和六支固定螺丝(3)。

前面板

:松去两支固定螺丝(4),

取下高速走带方向突

变旋钮(5)和音量旋钮 (6)。然后松去六支销

卡(7), 拆下一条全平

电缆(8)。

液晶显示板

: 松去三支固定螺丝(A),

打开液晶显示板下面(B)

25mm左右,并向下(C)滑

移15mm左右,取出之。

(安装时按相反步骤进行)

MPX电路印刷电路板 : 松去四支固定螺丝(9)


支架

和一支固定螺丝(10)。

Hi-Fi电路印刷电路板 : 松去两支固定螺丝(11)

和一支固定螺丝(12)。

(注意:在安装时,必须将接地线的垫圈部位置



VC-ML3 VC-ML3W

: 松去一支固定螺丝(13), 工作电路印刷电路板

拆下一条全平电缆(14)、

三个接线器(15)及两支

卡销(16)。

:取出一个接线器(17), LCD电路印刷电路板

松去一支固定螺丝(18)

和两支卡销(19)。

MPX电路印刷电路板

:取出一个接线器(20)和


两个接线器(21)。

机械装置/主电路印刷 :取出一个接线器(22),

电路板组件

松去一支固定螺丝(23)、

(24)、(25)、(26)及两 支固定螺丝(27),然后 取出接线器(28)。松去 一支固定螺丝(29),拆 下接地线,接着拆开两 支卡销(30)。 将天线接线端组件提起, 从主框架上取出机械装 置/主电路印刷电路板 组件。注意避免碰嗑磁 带盒室机构控制器下部 的录象用片状(REC TIP) 开关。



天线接线端盒: 松去一支固定螺丝(31)。 Hi-Fi电路印刷电路板: 拆下一个接线器(32)

和四个接线器(33)。

机芯底盘/磁带盒室 机构控制器组件

: 松去一支固定螺丝(34),

取出屏敝盒。

拆下三条全平电缆和 两个接线器(35), 然

后松去主电路印刷电


路板后面的四支卡销

(36)。

将机芯底盘/磁带盒 室机构控制器提起, 取出主电路印刷电路 板,然后松去两支固

定螺丝(37)。

: 松去两支固定螺丝(38)。



2-2盒室控制机构组装的注意事项


盒室控制机构的组装

安置盒室控制器电路于盒室机构之前,先对其自身进行初期设定。初期设定的进行分电路设定和机械设定。

电路设定:

- (1)短接工作电路印刷电路板上的TP插头(TP500*)的TP5005与TP5006之间。
- (2)插AC引线插头于AC电源插座,以确认盒室机构退回至其初始位置(*1)。
- (3)拔出AC引线插头,拆去TP5005与TP5006之间的短路。

注意:此方法用于盒室机构已设定好其印刷电路板之场合。



机械设定:

用螺丝刀拨转磁带装挂马 达皮带轮进送齿轮,让盒 室机构退回至其初始位置 (*1)。确认其动作到位后, 再安置盒室控制器电路于 其机构之上。(此方法用 于盒室机构未设装印刷电 路板之场合。)

盒室机构与印刷电路板的连接


将盒室机构上的两个凸块对准主电路印刷电路板上的两个定位参考记号(圆形为正参考,椭圆形为副参考)。然后垂直放下盒室机构,注意切勿让其机构的边缘部碰伤附近的其他元件。 旋紧固定盒室机构和主电路印刷电路的两支螺丝(一支用于固定盒室机构和前置放大器屏蔽,另一支位于主电路印刷电路板焊线侧的磁带装挂马达近旁)。插接盒室机构和主电路印刷电路板间的扁平型电缆插接器(AG、AD和AH)以及导线插接器(AE和AL)。

应特加注意的元件:


带头感应器、带尾感应器: D710、D709

录象功能触点开关: \$701

盒室机构与主电路印刷电路板间的MC-AC 插接器(板间插接器)也应加以特别注意。




3.主要机械部件的配置(俯视)及其功能



序号	功能	序号	功能
3.	张力臂组件 检测走带时录象磁带的松紧程度,并通过张 力带对供带盘产生制动作用。	13.	反转导杆组件 拉挂磁带,并且通过其高导杆和低导杆控制 其走带高度。
7.	供带盘主制动杆组件 于录象机动作停止时以及录象机处快进或倒 带状态时,对供带盘产生制动作用, 以防止磁带的松弛。	16.	紧带轮杆组件 于走带状态中,压装磁带于主导轴。
9.	改防止磁带的松弛。 卷带盘主制动杆组件 于录象机动作停止时以及录象机处快进或倒 带状态时,对卷带盘产生制动作用, 以防止 磁带的松弛。		带盒装填马达 其马达之作用在于为装填状态机构提供带盒 填入及磁带装挂的动力。其动力通过马达皮 带的传动,转为主凸轮及磁带盒室控制机构 的动作。

主要机械部件的配置(仰视)及其功能



序号	功 能	序号	功能
1.	缓速制动器 于缓速静止状态时,其制动器相触于与主凸轮 连动的主导轴,对其轴产生适当的制动作用。	6.	限幅皮带轮组件 将主导轴直接驱动马达的动力经带盘惰轮传送 给带盘。
		8.	移行器
3.	主导轴直接驱动马达 提供走带所需动力。其动力的转换由带盘皮带 实现。		将主凸轮的运动传输至制动器组件、磁带装挂 齿轮、张力臂及离合器杆。
4.	驱动皮带 带动限幅皮带轮转动,以驱动磁带的运转。	9.	卷带盘磁带装挂齿轮 通过磁带装挂继动齿轮,移动卷带杆底座及导辊, 并将磁带环绕于磁鼓。另外,其齿轮还有传动力 于供带盘磁带装挂齿轮之作用。

4.机械部件的调整、更换及装配

这里我们将为您介绍一些较简单的保养调试方法。 这些方法与需要特殊的仪器和工具的复杂检修 (例如, 磁鼓的组装或更换等) 相比更为容易简单。 我们相信,下表所列便于使用的工具在您为本录 象机定期保养以维持其原有的工作状态中无疑能起很 大的作用。

机械部件调整必需的工具

检查修理时,应准备下列工具才能顺利进行修理工作。

序号	工具名称	零件编号	编码	形状	备 注
1	带盘高度调整工具	JiGRH0002	BR	<i>Q</i>	— 用于检查、调整带盘高度。
2	主平面调整工具	JiGMP0001	BY	6.0	一用了位置、调度市益問及。
3	音頻/控制磁头傾斜调整 工具	9DAACH-A323U	BX		用于设定音频 / 控制磁头的倾斜角度。
,	转矩測量计(90克)	JiGTG0090	СМ		·
4	转矩測量计(1.2公斤)	JiGTG1200	CN		│ │ 用于检査、调整供带轮和卷
5	转矩測量计測头	JiGTH0006	AW		一 带轮的转动力矩。
6	盒匣磁带式转矩测量计	JiGVHT-063	cz		用于检查、调整卷带轮的转 动力矩以及测量磁带反向张 力。
_	张力測量计(300 克) JiGSG0300 BF		分为300克和2.0公斤两量级,		
7	张力測量计(2.0公斤)	JiGSG2000	BS		用于张力測量。
	六角扳手(0.9毫米)	JiGHW0009	AE		
8	六角扳手(1.2毫米)	JiGHW0012	AE		用于松弛或紧固特制六角螺栓。
	六角扳手(1.5毫米)	JiGHW0015	AE	9	
_	校正用磁带 (NTSC)	VROATSV	CD		
9	校正用磁带 (PAL)	VROCPSV	ск	(Circum)	
	校正用磁带	VROCBFFS	СВ		专用于机器的电路微调。
	校正用磁带	VROCPZJS	CA		
11	张力測量计接续器	JiGADP003	вк		用于张力測量计。

序	工具名称	零件编号	编号	形状	备 注
12	专用螺丝刀	JiGDRIVERH-4	АР		用于导辊高度调整。
14	扭转改锥(5公斤)	JiGTD1200	СВ		用于扭转树脂制工具。标准 扭转值为5公斤。
		JIGDRIVER110-7	AS		用于音频/控制磁头高度和 X位置的调整。
15	套管改锥	JiGDRIVER110-4	AV		用于更换供带阻抗滚子。
· 		JIGDRIVER110-55	AR	© 	用于更换反转导杆。
16	反转导杆高度调整工具	JiGRVGH-F18	BU	T	用于反转导杆的高度调整。

机械部件的定期保养期间

为保持机械部件的正常工作性能,务必按下表定期进行维护保养。

保养间隔	每500	每1000	毎1500	海2000	可能出现症状	备注
部件名称	小时	小时	小时	小时	THE LU ACTIENT	超 江
导辊组件				0		如发生不正常的旋转或 显著的摇摆, 就需更换
供带阻抗滚子				0		该部件。
供带阻抗滚子(内侧)					水平噪音线出现, 磁头不时被磁带缠	
供带阻抗滚法兰					(位代介可被做市通 (交。	
定位导杆		<u> </u>				用指定清洁剂擦拭与磁 带接触部份。
斜杆				0		
上部磁鼓组件和下部磁鼓组件		00	0	00	信号/噪声比过小,无彩色表现。 装人校正用磁带时,包络线非 平坦。	TE 44.65 (本) 生物性 44.65 74
完全消 磁磁 头				0	色彩过淡,图象闪跳。	用指定清洁剂擦拭与磁 带接触部份。
音頻/控制磁头				0	声音太小或者噪音太大。	
主导轴直接驱动马达				0	磁带不转,色彩不均。	
紧带轮				0	不走带,磁带松弛。	用指定清洁剂擦拭橡胶
带盘皮带				0	不走带, 磁带松弛, 快进或倒带 时走带 不正常。	与橡胶接触部份。
张力带组件				0	· · · · · · · · · · · · · · · · · · ·	,
装填马达				0	市盖小具人或小区山。	
带盘惰轮组件			_	0	不走带。	
带盘皮带轮组件						
离合器齿轮组件				0		
供带/卷带主制动杆				0	磁带松弛。	
AHC (自动录象头除垢器)		0		. 0		除垢器滚轮部位的磨耗过 大时,就需更换该部件。 更换时,只要更换录象头 除 垢器臂组件即可。

注意:〇:部件更换

□:部件清洗 (用不起毛的网布蘸异丙醇擦拭)

△:部件注油(注有标记之部件应该每1000小时用高级轴油点注润滑)

如发现所测数值超过或不及规定范围, 务必对该部件进行清洗或加以更换

磁带盒室控制机构的拆 卸及安装

- ●盒室控制机构的拆卸
- 1.退出磁带盒匣,设机构于出盒状态。
- 2. 从电源插座中拔出电源引线插头。
- 3.按下述步骤的要求顺序进行拆卸。
 - a)松去紧固磁带盒室控制机构的紧固螺丝①。
 - b)按箭头方向移动磁带盒室控制机构,然后 将其向上拉出。




图4-1

●盒室控制机构的组装

1.安装盒室控制机构前,短接工作电路印刷电路板上的TP5005与TP5006之间,然后,插入电源引线插头,盒室控制机构驱动齿轮开始转动。机芯底盘窗口处正好看见大齿转时转动停止。按图4-2所示,盒室控制机构驱动齿转的第二齿条与盒室控制机构驱动角板的第三齿条啮合,以便调整机芯底盘上的盒室控制机构位置。




图4-2

- 2.按拆卸步骤的相反顺序进行组装。 注意:
- ①拆卸或组装时,如使用带磁螺丝刀,务请注意不要让其触碰音频/控制(A/C)磁头、完全消磁(FE)磁头以及磁鼓。
- ②拆卸或组装磁带盒室控制机构时,务请谨慎 小心,切勿磕碰其机构,同时注意不要让工 具等碰撞导向销、磁鼓等精密度较高的部件。
- ③组装之后,填装—录象带盒于盒室控制机构中。

无盒室控制机构的走带 测试

1. 电源接通之前,短接工作电路印刷电路板上的 TP5005与TP5006之间。

- 2.插电源引线插头于电源插座。
- 3. 开启电源开关。
- 4. 用手打开磁带盒匣端口之盖。
- 5. 用胶带张贴之以保持其开盖状态。
- 6. 置其于机芯底盘中的走带机构。
- 7.应将500克的重物牢固地安置于录象带盒上。
- 8.作磁带的走带测试。




图4-3


注:压其重物不得超过500克。


带盘座的更换及其 高度的检测和调整

●带盘座的拆卸


- 1. 拆去磁带盒室控制机构。
- 2. 从张力臂上取出张力带。
- 3. 用手松开供带/卷带用辅助制动器, 拆去供 带用主制动器和卷带用主制动器。
- 4. 松开带盘座上的卡销、拆去供带盘座和卷带 盘座。

<出盒或UL停止状态时>





拆卸时,应按图中箭头所示方向按压张力带, 以免使锁扣变形。



- ●供带盘座的更换
- 1.清擦供带盘座轴,并注油加以润滑。
- 2. 将带盘座的接合部与带盘继动齿轮啮合, 然 后将准备好的新供带盘座插套入其轴。

- 3.环张力带与供带盘座装置安置就位,并在松 开供带用辅助制动器之状态下,将其端插入 张力臂之插孔。
- 4.检查供带盘座的高度。

注意:

- ①安置供带盘座时,务请格外小心,切勿弯折 扭曲张力带。
- ②切勿碰伤供带用主制动器与带盘继动齿轮。

●卷带盘座的更换

- 1. 清擦卷带盘座轴,并注油加以润滑。
- 2.松开卷带用辅助制动器,接着将带盘座的接 合部与带盘继动齿轮啮合, 然后将准备好的 新卷带盘座插套入其轴。
- 3.检查卷带盘座的高度后,安置卷带用主制动 器就位。

注意:


务请小心谨慎、切勿碰伤卷带用主制动器。

*带盘座更换之后,须检查调试视频搜索倒带 时的反向张力(见第82页),以及其制动力 矩(见第84页)。

●带盘高度的检测和调整

注意:

将主平面板设置于机芯底盘、注意切勿磕碰磁 鼓(见图4-6所示)。



用手指松开反转导杆、使主平面板设置。




图 4-6

VC-ML3 VC-ML3W

●检查带盘座是否低于图示A位置而高于B位置。 如果所测高度不在AB两位置的要求范围内, 则通过更换带盘座下面的滑动垫圈对其高度 进行调整。

注意:

带盘座只要一经更换,就必须对其进行高度的 检测和调整。



快进状态时卷带转矩的 检测和调整

- ●拆去磁带盒室控制机构。
- ●电源接通之前,短接工作电路印刷电路板上的 TP5005与 TP5006之间。

●转矩测量计的设置

- 1. 设转矩测量计的刻度于0, 然后将其转矩测量计安置于卷带盘座上。
- 2.触按倒带(REW)键,置盒室控制机构于倒带状态。
- 3. 缓慢地旋转卷带盘座, 置移行器于倒带状态。

●倒带状态时的转矩检测

- 1.用手缓慢地沿卷带方向旋转转矩测量计(2~3秒/转)。
- 2. 检查所测卷带转矩值是否大于69mN·m (700gf·cm)。




图4-8

●快进状态时的转矩调整

 如果所测卷带转矩超出或不及规定值范围, 则需用清洗液清擦主导轴直接驱动马达皮带 轮、带盘皮带及其皮带轮。然后,再测量之。 2. 如果清擦后所测卷带转矩仍不符合规定要求,则需更换传动皮带。

注意:

- 1.设置及计测时,须用手向下按住转矩测量计, 以免卷带盘的旋转甩飞安置于其上的转矩测 量计。
- 2.作卷带转矩检测时,不宜让带盘座锁扣时间过长。

倒带状态时卷带转矩的 检测和调整


- 拆去磁带盒室控制机构。
- ●电源接通之前,短接工作电路印刷电路板上的 TP5005与TP5006之间。

●转矩测量计的设置

- 1 设转矩测量计的刻度于(), 然后将其转矩测量计安置于卷带盘座上。
- 2.触按倒带(REW)键,置盒室控制机构于倒带 状态。
- 3.缓慢地旋转卷带盘座,置移行器于倒带状态。

●倒带状态时的转矩检测

- 1.用手缓慢地沿卷带方向旋转转矩测量计 (2~3秒/转)。
- 2.检查所测卷带转矩值是否大于69mN·m (700gf·cm)。



●倒带状态时的转矩调整

1. 如果所测卷带转矩超出或不及规定值范围, 则需用清洗液清擦主导轴直接驱动马达皮带 轮、传动皮带及限幅皮带轮。然后,再测量 之。 2. 如果清擦后所测卷带转矩仍不符合规定要求,则需更换传动皮带。

注意:

- 1.设置及计测时,须用手向下按住转矩测量计, 以免卷带盘的旋转甩飞安置于其上的转矩测 量计。
- 2. 作卷带转矩检测时,不宜让带盘座锁扣时间 过长。

再现状态时卷带转矩的 检测和调整

- 1 拆去磁带盒室控制机构。
- 2. 电源接通之前,短接工作电路印刷电路板上的TP5005与TP5006之间。
- 3. 用手揭开盒匣磁带式转矩测量计端口盒盖, 用两张胶带张贴之以保持其开盖状态。
- 4. 装填盒匣磁带式转矩测量计于录象机中。

规定值为LP 10.5±3.8 mN·m (107±39 gf·cm)




图4-10

- 5.加一500克的重物于盒匣磁带式转矩测量计上。
- 6. 触按录象(REC)键,设录象机于录象状态。
- ●再现状态时卷带转矩的检测
- 1. 检查所测转矩值是否于10.5 ± 3.8 mN·m (107 ± 39 gf·cm)。
- 2.由于带盘旋转的不均匀性,所测转矩值有可能产生波动现象。这时应取波动值的中心值为其测定值。
- 3. 触按录象(REC)键,置录象机为LP录象状态, 检查这时的卷带转矩是否满足上述要求。
- ●再现状态时卷带转矩的调整 如果所测卷带转矩超出或不及其规定值范围, 则需更换限幅皮带轮组件。

注:压一重物于测量计之上,以防其翘起。

视频搜索倒带状态时卷带转矩的检测和调整

- ●拆去磁带盒室控制机构。
- ●电源接通之前,短接工作电路印刷电路板上的 TP5005与TP5006之间。

●设置

- 1.触按再现(PLAY)键、设录象机于再现状态。
- 2. 触按倒带(REW)键,设录象机于视频搜索倒带 状态。
- ●视频搜索倒带状态时的转矩检测
- 1.置转矩测量计于供带盘座之上,逆时针方向缓慢地旋转之(1~2秒/转),检查所测转矩值是否于14.0±3.9mN·m(144±40gf·cm)的规定范围内。



图4-11

如果所测视频搜索倒带状态时的卷带转矩超出 或不及其规定值范围,则需更换限幅皮带轮组 件。

注意

应将转矩测量计牢固地安置于供带盘座之上,否则,所测值并非真实。

注意:

由于限幅皮带轮旋转的不均匀性,所测转矩值 有可能产生波动现象。这时应取波动值的中心 值为其测定值。

视频搜索倒带状态时的 反向张力的检测

- ●拆去磁带盒室控制机构
- ●电源接通之前,短接工作电路印刷电路板上的 TP5005与TP5006之间。

●检测反向张力

- 1.触按再现(PLAY)键,设录象机于再现状态。
- 2.触按倒带(REW)键,设录象机于视频搜索倒带状态。
- 3.置转矩测量计于卷带盘座之上,逆时针方向缓慢地旋转之(2~3秒/转),检查所测转矩值是否于2.7±1mN·m(28±10gf·cm)的规定范围内。




图4-12

注意:

- 1.应将转矩测量计牢固地安置于卷带盘座之上, 否则,所测值并非真实。
- 2.在加负荷于带盘座之状态下,转矩测量计所示的数值是真实的转矩测量值。

紧带轮压力的检测

- ●拆去磁带盒室控制机构。
- ●电源接通之前,短接工作电路印刷电路板上的 TP5005与TP5006之间。

●检测

触按再现(PLAY)键,设录象机于再现状态。




图4-13

- 1. 拨移紧带轮, 使之与主导轴分离。
- 2.通过套挂张力测量计接续器将张力测量计设置于紧带轮轴之上。
- 3.慢慢放松压力,让紧带轮渐渐靠拢主导轴。 在紧带轮与主导轴相触的瞬间,测量计上的 读数就是所要计测的压力值。
- 4. 检查所测压力值是否在900~1,200克的规定范围内。

张力杆位置的检测和调整

- ●拆去磁带盒室控制机构。
- ●电源接通之前,短接工作电路印刷电路板上的TP5005与TP5006之间。

●设置

- 1.揭开录象带(E-180)盒盖,用两片胶带将开盖固定。
- 2. 装入开盖的录象带带盒于盒室机构。
- 3.在录象带带盒上加500克的重物。
- 4.用E-180录象带的带头部份进行检调。




图4-14

●调整

1. 安置好录象带带盒,触按录象(REC)键,让 挂带机构挂好磁带后,检查张力杆的位置。

- 2. 通过观察检查张力杆中心是否位于与供带侧导轴左侧离开1.3mm之位置。其重调方法如下。
- ③张力杆调整器的调整范围
- ④张力杆调整凸轮的调整范围





图4-15






图4-16

插一字口螺丝刀于张力杆调整器,顺时针旋转之。

②张力杆左端偏移至虚线的右侧时:




图4-17

插一字口螺丝刀于张力杆调整器,逆时针旋转之。




图4-18

调整张力杆调整器,使凸轮上的圆型标志处于 左右90°范围内。

录象/再现状态时反向 张力的检测和调整

- 拆去磁带盒室控制机构。
- ●电源接通之前,短接工作电路印刷电路板上的 TP5005与TP5006之间。
- ●设置
- 1. 揭开录象带转矩计盒盖,用两片胶带将开盖固定。
- 2. 装入开盖的录象带转矩计于盒室机构。
- 3.在转矩计盒盖上加500克重物。




图4-19

- ●反向张力的检测
- 1.触按录象(REC)键,设录象机于录象状态。
- 2. 检查所测反向张力值是否在31~38g·cm的规 定范围内。

注意:

- 1. 确认走带时,不发生磁带高出定位导杆的现象。
- 2. 确认磁带自始至终不发生松弛或损伤现象。

VC-ML3W

- ●反向张力的调整
- 1.录象带转矩计所测读数小于规定值时,向A 方向移动张力弹簧。
- 2. 录象带转矩计所测读数大于规定值时,向B 方向移动张力弹簧。





图4-20

制动力矩的检测

●供带侧制动力矩的检测




逆时针方向:5.9~9.8mN.m(60~100gf.cm) 顺时针方向:10~32mN.m(100~330gf.cm)

图4-21

- ●拆去磁带盒室控制机构。
- ●电源接通之前,短接工作电路印刷电路板上的 TP5005与TP5006之间。
- ●设定方法
- 1. 设转矩测量计的刻度于0,置其于供带盘座之上。
- 2.转换快进(FF)状态为停止(STOP)状态。
- 3. 拔出交流电源插头。
- ●检测方法
- 1.用手沿供带制动的顺时针方向和逆时针方向旋转转矩测量计(约每2秒旋转一次),使转矩测量计的刻度盘与供带盘以同样的转速旋转。然后,检查所测值是否满足其规定要求:顺时针方向制动力矩=10~32mN.m(100~330gf.cm);逆时针方向制动力矩=5.9~9.8mN.m(60~100gf.cm)。另外,两者所测值还得满足顺时针方向制动力矩至少等于逆时针方向制动力矩的两倍之规定要求。

●卷带侧制动力矩的检测



逆时针方向:9.8~34mN.m(100~340f.cm) 顺时针方向:4~8.3mN.m(40~85gf.cm)

图4-22

- ●拆去磁带盒室控制机构。
- 电源接通之前,短接工作电路印刷电路板上的 TP5005与TP5006之间。
- ●设定方法
- 1.设转矩测量计的刻度于0,置其于卷带盘座之上。
- 2.转换快进(FF)状态为停止(STOP)状态。
- 3. 拔出交流电源插头。
- ●检测方法 #
- 1.用手沿卷带制动的顺时针方向和逆时针方向旋转转矩测量计(约每2秒旋转一次),使转矩测量计的刻度盘与卷带盘以同样的转速旋转。然后,检查所测值是否满足其规定要求:逆时针方向制动力矩=9.8~34mN.m(100~340gf.cm);顺时针方向制动力矩=4~8.3mN.m(40~85gf.cm)。另外,两者所测值还得满足逆时针方向制动力矩至少等于顺时针方向制动力矩的两倍之规定要求。
- ●供帶侧以及卷带侧制动力矩的调整
- 1. 如果供带侧或卷带侧制动力矩所测值不符合规定要求,则应清擦供带盘座或卷带盘座制动杆及其垫圈,然后重新检测之。
- 2. 如果清擦后重测制动力矩还不符合规定要求,则需更换主制动器组件。

注意:

主制动器一经更换,则需进行高度的检测与调整(见第79页所述),以及制动力矩的检测。

音频/控制(A/C)磁头的 更换

- 1. 拆去磁带盒室控制机构。
- 2. 设录象机于磁带卸挂状态后,拔去其电源引线插头。

2

- ●A/C磁头的拆卸
- 1.松开螺丝A、B、C、①及②。
- 2. 松焊A/C磁头印刷电路板与A/C磁头的连线。 注意:
- 1. 拆裝更换后,必须进行磁带走行检查调整 (见第66页所述)。拆装过程中,无论是什么情况,都不得用手或他物触碰A/C磁头。

2. 松去 A、 B、 © 螺丝时,注意防止其弹 簧弹出遗失。





图4-23

- ●A/C磁头的更换
- 1.焊接拆下的A/C磁头印刷电路板与更换用新A/C磁头的连线。
- 2. 用滑动式卡钳,使A/C磁头臂(底面)与A/C磁 头基板(螺丝位置)间的高度调至10.3mm(3处) (见下图)







图4-24

VC-ML3W

3. 将A/C磁头臂齿轮左侧的标志与机芯底盘上的标志对齐,暂时旋紧螺丝①和②,直至A/C磁头臂顺利旋转为止。

(注:暂时旋紧时的力矩以0.2N.m为宜)




注意:

如果螺丝①与②的夹紧力矩不一致,正式旋紧时可能难以调整A/C磁头的高度。

[A/C磁头的高度粗调]

●设置







图4-26

- ①装入录象带于机芯底盘中。
- ②触按再现(PLAY)键,设录象机于再现状态。
- ③旋转螺丝 ② ,以对A/C磁头高度进行粗调, 使磁带达至下面所示位置为宜。



●调整

调节螺丝 \bigcirc ,使控制磁头底边缘低于磁带底边缘 $0.3\sim0.5$ mm为宜。

反转导杆的高度调整

[反转导杆的高度调整]





图4-28

- ①拆下开盖柄。(图4-29(a))
- ②先于录象带装挂状态下调整13.38mm端,然 后再沿逆时针方向旋转反转导杆的高度调整 螺母至36°。
- ③录象带装挂动作结束后,设录象机于再现状态,检查靠近反转导杆处的录象带是否皱折。

④用一般市场上贩卖的套管改锥旋转高度调整 螺母。






图4-29

走带情况的调整

- 1.拆去磁带盒室控制机构。
- 2. 电源接通之前,短接工作电路印刷电路板上的 TP5005与TP5006之间。
- 3.检测和调整张力杆的位置。(见第82页)
- 4.检测和调整视频搜索状态时的反向张力。 (见第82页)
- 5.设定A/C磁头于规定位置。(见第85页)
- 6 按下述步骤对走带情况进行粗调。
 - a)连接示波器于再现色彩包络线输出(TP501) 的测试点。设示波器同步于外接。这样, 再现色彩信号便会被磁头转换脉冲(TP502) 所触发。
 - b) 先松开导辊底部的固定螺丝,然后再用 六角扳手(JIGHW0009)调节该固定螺 丝,直至能轻松圆滑地旋动导辊之程度 为止。(切勿把固定螺丝过松紧,否则 会造成导辊不稳定状态。)(见图4-30)




图4-30




图4-31

c)将校正用磁带(单象管图案)盒匣安置于 带盘座上,然后,将录象机设定于再现状 态

(施加—500克的重物于带盒之上,以防走带时带盒的翘起)。

d)于X位置调整状态(见电路调整有关章节 所述),触按跟踪键(+)和(-),调输出 包络线波形从最大至最小,以及从最小至 最大。同时观察其波形是否达至平坦状态。

- e)如通过上述调节,其输出包络线波形无法 达至平坦状态,则需用导辊调整用螺丝刀, 对供带侧和卷带侧的导辊进行粗调,直至 输出包络线波形达至平坦。
- f)旋转螺丝 (A) ,以防由定位导杆法兰在磁带上起皱。

将磁带转回至原始位置后,检查在定位导 杆法兰部位有无发生起皱现象。

(1)无起皱时

顺时针方向旋转螺丝 (A) ,以在法兰部位产生起皱现象,然后松开螺丝 (A) ,直至完全消除起皱现象为止。

(2)起皱时

, 逆时针方向旋转螺丝 A ,直至完全消 除起皱现象为止。

参考:

顺时针方向旋转螺丝 A 时,在下部法 兰上会产生起皱现象。



图4-32



图4-33

注意

- 1. 将跟踪调节控制钮设定于其中间位置,然后 调整 X 位置,使再现色彩包络线波形达至最 大,以便进行走带情况的粗调。
- 2.粗调过程中,应特别注意触电等之危险。




图4-34

- 7.A/C磁头高度和方位角的调整
 - a)连接示波器于音频输出端。
 - b) 裝入预先录有1kHz线性音频信号的校正用磁带,调节螺丝 B 和 ©,使音频输出达至最大。然后,调节螺丝 A,以消除定位导杆法兰上产生的起皱现象。(见第87页-6-f)。按螺丝 B、 © 及 A 之顺序重复进行该调整,使音频输出达至最大。
 - c)装入预先录有6kHz线性音频信号的校正用 磁带,最后,调节螺丝®,使音频输出 达至最大。
- 8. 走带系统以及X位置的调整
 - a)连接示波器于测试点TP501,作再现彩色包络线输出。设示波器同步于外接。这样, 再现彩色信号将被磁头开关脉冲 (TP502) 所触发。

- b)再现走带检查用校正磁带。
- c)触按跟踪键的(+)或(-),使输出包络线波形从最大转至最小,然后又从最小转为最大。用高度调整用螺丝刀调整供带盘侧和卷带盘侧导辊的高度,使输出包络线尽可能达至平坦。
- d)如果走行中的磁带低于或高于螺旋扫描导 前,再现彩色输出便会呈现图4-35所示波 形。
- e)按第87页步骤6的项目e)要求,调节输出 包络线的最大平坦度。
- f)触按跟踪键的(+)或(-),检查包络线波形的平坦度反应。
- g)于磁带卸挂状态,用导辊设定螺丝紧固导 辊。
- h)再现走带检查用校正磁带,检查输出包络 线波形是否发生变化。

9.A/C磁头X位置的调整

- a)在X位置的调整状态下(见各电路的调试 之项),短接工作电路印刷电路板上的TP 5005与TP5006之间,使跟踪控制处于中央 位置。
- b)用调整螺丝刀移动A/C磁头臂,然后调节 A/C磁头位置,使磁头开关脉冲高侧的包 络线达至最大。 最后,旋转螺丝①和②。(此时,应按螺 丝①和②之顺序进行)。(见图4-36①和②)。


(参考:最后的旋紧力矩以0.6N.m为宜)。

c)调节再现转换点。

	磁带高于螺	旋扫描导前	磁带低于螺	旋扫描导前
	供带侧	卷 带 侧	供帯側	卷 带 侧
	顺时针方向旋转供带 盘侧导辊(导辊降低), 使其输出波形包络线 达至平坦。	顺时针方向旋转卷带 盘侧导辊(导辊降低), 使其输出波形包络线 达至平坦。	逆时针方向旋转供带 盘侧导辊(导辊升高), 让磁带高过螺旋扫描 导前。然后,顺时针	逆时针方向旋转卷带盘侧导辊(导辊升高),让磁带高过螺旋扫描导前。然后,顺时针
调整			方向旋转供带盘侧导 辊,使其输出波形包 络线达至平坦。	方向旋转卷带盘侧导 辊,使其输出波形包 络线达至平坦。

图4-35

d)再现已录有内容的磁带,以检查包络线波 形和音频信号波形的状态。



主导轴直接驱动马达的 拆卸和组装

- 拆去磁带盒室控制机构。
- ●直接驱动马达的拆卸(按图中所示顺号进行)
- 1. 拔开主印刷电路板上的板间插接器的连接。
- 2. 拆去带盘皮带①。
- 3. 松去螺丝②。




图4-37

●直接驱动马达的组装

- 1.将主导轴直接驱动马达就位于机芯底盘。这时,应注意不要让主导轴磕碰机芯底盘。 然后,用三支螺丝将其紧固。
- 2. 套好带盘皮带。连接好主印刷电路板上的板 间插接器。

注意:

- 1.组装完毕,转动主导轴直接驱动马达,检查 其转动是否圆滑。
- 2.检测、调整其伺服电路。

主导轴直接驱动马达的装拆

- 1.设装置于磁带出盒状态。
- 2. 拔出电源插头。
- ●直接驱动马达的拆卸(组装时按此相反顺序 进行)
- 1. 拨开FFC电缆线的插接(1)。
- 2. 松去直接驱动马达定子组件的固定螺丝(2)。
- 3.取出直接驱动马达定子组件(3)。
- 4. 取出直接驱动马达转子组件的固定螺丝(4)。
- 5.取出直接驱动马达转子组件(5)。

注意:

- 1. 拆卸直接驱动马达定子组件时, 磁鼓接地弹 簽会弹出接地弹簧的压扣环。 注意切勿丢失其接地弹簧。
- 2. 安装时,必须先将直接驱动马达转子组件的 安装孔与下部磁鼓组件的安装孔对齐,然后 紧密固定之。

接着再按类似要领安装上部磁鼓。

- (将上部磁鼓的槽口与直接驱动马达转子的 安装孔对齐。)
- 3.操作中, 切勿碰伤上部磁鼓和视频磁头。
- 4. 安装时,必须小心谨慎,切勿损伤霍尔效应器、直接驱动马达定子、转子以及其它组成部件。
- 5. 更换组装完毕, 必须进行再现转换点的调试。





图4-38

需要进行下述配相调整 的机械部件的组装

- 1.组装紧带轮组件、反转导杆组件和紧带轮传 动凸轮。(于机芯底盘前面)
- 2. 安装移行器。(于机芯底盘背面)
- 3.安装主凸轮。(于机芯底盘背面)
- 4. 安装连接齿轮、慢放制动器以及磁带挂装马 达。(于机芯底盘背面)
- 1. 紧带轮组件、反转导 杆组件与紧带轮传动 凸轮(机芯底盘前面) 的组装






图4-40-1

③插入紧带轮和紧带双动杆组件

④插入开盖柄




图4-40-2





图4-40-3

2.移行器(机芯底盘背面)的组装



- 1.检查磁带装挂齿轮是否于下图所示的插孔处 ①。
- 2. 按要求安装移行器。这时,必须注意移行器 的6个插孔和3个松解钉。
- 3. 为在插孔①处进行配相调整,请见下图的配相点②的说明。
- 4.在插孔①和④处加上垫圈,紧固移行器。




图4-42

3.主凸轮(机芯底盘背面)的安装


(1)首先检查移行器位置是否满足下图所示要求。

(2)按下图所示要求安装主凸轮。

注意:

如下图所示,调整主凸轮与盒室控制机构传动。 齿轮间的配相点。

(3)加弹簧垫圈,固定主凸轮。



将传动齿轮的较宽齿条对准主凸轮的槽孔, 插入传动齿轮。

主凸轮

图4-43

VC-ML3 VC-ML3W

磁带装挂马达的更换

●马达的拆卸

松去两支紧固螺丝。




图4-44

●马达的更换

①取出旧的磁带装挂马达。按上图(图4-44) 所示要求装换新的磁带装挂马达。




图4-45

用小于98N(10kgf)的力压入磁带装挂马达皮带轮。检查皮带轮是否离马达的间距是否满足7.7-%.1mm的要求。

盒室控制机构的组装 ①框架组件




图4-46

VC-ML3 VC-ML3W

②同步齿轮、左侧传动齿轮和右侧传动齿轮




图4-47




图4-48

5 各电路的调试

注:

●调试前 在更换录象机磁头之类的电子元件以及机械部件之后,经常需要进行本节所述的电气调试。 在调试之前,检查机械装置以及所有的电子元件是否处于良好的工作状态,否则,调试不能顺利完成。

- ●需要的检测用仪器
 - O彩色电视机监视器
 - O音频信号发生器
 - O直流伏特计
 - O空白录象带
 - O调试用螺丝刀
 - O彩条信号发生器
 - O计频器

- ○双踪示波器
- O交流毫伏特计
- ○校正用磁带(VROCPSV)
- ○校正用磁带(VROATSV)
- ○校正用磁带(VROCBFFS)
- ○校正用磁带(VROCPZJS)

☆调整注意事项:

定时器电路中的IC703静电可编程式只读寄存器E²PROM发生更换时,应按下述要求重编其 记忆程序。

按录象机型号而导,IC703的 E^2 PROM的记忆程序已于出厂前按规定加以设定。

因此,应根据录象机型号要求,正确设定其记忆功能。

此外,对伺服电路还应进行磁头转换点、慢动作演放以及静止画面的调整。

●主电路控制调节与测试点的位置




图 5-1

伺服电路的调整

PAL制式磁头转换点的调试

检测仪器	双轨迹示波器 监控用彩色电视机
工作状态	再现
使用磁带	校正用磁带(VROCPSV)
漁送 廣	TP502(磁头转换点)接频道-1 视频输出插孔端接频道-2 (頻道-1触发倾斜开关于 (+),内触发于频道-1)
規定要求	6.5±0.5H(线路)

1. 松开前面板。插入校正用磁带(VROCPSV), 再现之。

(再见图象表示于监测用电视机莹屏。)

- 2.对工作电路印刷电路板上的TP5001与TP5002 之间进行瞬间短接处理。 短接测试点后,检查REC LED和定时器LED是 否点亮。(见下注①)
- 3.设录象机于自动调整状态,触按再现(PLAY) 键。
- 4. 在自动调试中,检查RED LED是否闪动。
- 5.在自动调试完毕后,检查RED LED是否熄灭。
- 6. 触按停止(STOP)键, 让录象机返回至正常工作状态。
- 7. 磁头开关转换点的调整完毕后,再现校正用磁带,以检查示波器上呈现的波形是否符合图5-2 所示的规定要求。

所测值不符合规定要求之场合,再次呼出测试点,触按快进(FF)键或倒带(REW)键以调至规定要求之范围内。

注:

- ①调试状态的设定。
 - 磁头转换点的调整过程中, 自动跟踪功能无效。
- ②盒室控制机构被取出状态下,机械工作状态的设定。
- 1) 几分钟后再重新插入电源引线插头。
- 2)短接工作电路印刷电路板上的TP5005与 TP5006之间,使跟踪控制处于中央位置。
- _3) 插入电源引线插头。
 - 4) 这样, 便可得机械动作状态。

CH-2: 1V/段、50樹科/段

图 5-2

PAL制式SP(标准)/LP(慢速)方式跟踪预设的调试

检测仪器	监控用彩色电视机
工作状态	再现
使用磁带	自录磁带(SP/LP方式) (见下注)
调整点	磁迹跟踪键(+)或 ()
规定要求	监控用彩色电视机荧 屏上噪声线最小程度。

- 1. 设录象机于电视台节目接收状态, 或向其视频输入端输入视频信号。
- 2. 用遥控器设录象机于SP(标准)走带方式, 装入自录磁带录象之。
- 3. 录象后, 倒带, 再现其录象信号。
- 4. 触按遥控器上的慢放(SLOW)键,慢动作再现之。
- 5.对工作电路印刷电路板上的TP5001与TP5002 之间进行瞬间短接处理。 短接测试点后,检查REC LED和定时器LED是 否点亮。
- 6.观察监控用电视机荧屏,触按磁迹跟踪键(+) 或(一),将荧屏上呈现的噪声线(雪花) 调至最小程度。
- 7. 触按再现(PLAY)键, 让录象机返回至正常工作状态。
- 8. 以标准状态再现录象带数秒后, 再触按慢放 (SLOW)键, 检查电视荧屏上的噪声线是否明 显。

(LP方式的调整亦按与SP方式的调整方法相同进行之)。

注:

自录磁带意指于电路调整状态时录象用磁带。

PAL制式静止画面FV(虚假垂直同步)的调试。

检测仪器	监控用彩色电视机
工作状态	再现状态静止画面
使用磁带	自录磁带(SP方式) (见下注)
调整点	磁迹跟踪键(+)或()
规定要求	电视荧屏上无垂直晃抖

- 1. 装入自录磁带, 用SP方式录象后, 再现之。
- 2. 触按暂停/静止(PAUSE/STILL)键, 静止再现图象。
- 3. 观察监控用电视机炭屏,触按磁迹跟踪键(十) 或(一),将炭屏上呈现的噪声线(雪花) 调至最小程度。
- 4. 用SP方式再现自录磁带, 静止再现图象, 检查电视荧屏上的噪声线是否明显。 (LP方式的调整亦按与SP方式的调整方法相

同进行之)。

注:

自录磁带意指于电路调整状态时录象用磁带。

NTSC制式磁头转换点的调试

检测仪器	双轨迹示波器 监控用彩色电视机
工作状态	再现
使用磁带	校正用磁带(VROATSV)
点近誤	TP502(磁头转换点)接频道-1 视频输出插孔端接频道-2 (頻道-1触发倾斜开关于 (+),内触发于频道-1)
规定要求	6.5±0.5H (线路)

1. 松开前面板。插入校正用磁带(VROATSV), 再现之。

(再见图象表示于监测用电视机莹屏。)


- 2.对工作电路印刷电路板上的TP5001与TP5002 之间进行瞬间短接处理。 短接测试点后,检查REC LED和定时器LED是 否点亮。(见下注①)
- 3.设录象机于自动调整状态,触按再现(PLAY) 键。

- 4.在自动调试中、检查RED LED是否闪动。
- 5.在自动调试完毕后,检查RED LED是否熄灭。
- 6. 触按停止(STOP)键, 让录象机返回至正常工作状态。
- 7. 磁头开关转换点的调整完毕后,再现校正用磁带,以检查示波器上呈现的波形是否符合图5-3 所示的规定要求。

所测值不符合规定要求之场合, 触按快进 (FF)键或倒带(RFW)键以调至规定要求之范围内。

注:

- ①调试状态的设定。
 - 磁头转换点的调整过程中, 自动跟踪功能无效。
- ②盒室控制机构被取出状态下,机械工作状态的设定。
- 1) 几分钟后再重新插入电源引线插头。
- 2)短接工作电路印刷电路板上的TP5005与 TP5006之间,使跟踪控制处于中央位置。
- 3) 插入电源引线插头。
- 4) 这样, 便可得机械动作状态。
- ③如果已经调整过PAL制式磁头转换点,即不需调整NTSC制式磁头转换点。 边观察测试点上显示出的波形边检查是否符合规定要求。



NTSC制式SP(标准)/EP(慢速)方式跟踪预设的调试。

检测仪器	监控用彩色电视机
工作状态	再现
使用磁带	自录磁带(SP/EP方式) (见下注)
调整点	磁迹跟踪键(+)或 ()
规定要求	监控用彩色电视机荧 屏上噪声线最小程度。

- 1. 设录象机于电视台节目接收状态,或向其视频输入端输入视频信号。
- 2. 用遥控器设录象机于SP(标准)走带方式, 装入自录磁带录象之。
- 3. 录象后, 倒带, 再现其录象信号。
- 4. 触按遥控器上的慢放 (SLOW) 键, 慢动作再 现之。
- 5. 对工作电路印刷电路板上的TP5001与TP5002 之间进行瞬间短接处理。 短接测试点后,检查REC LED和定时器LED是 否点亮。(见下注①)
- 6. 观察监控用电视机荧屏,触按跟踪键(+)或 (一),将荧屏上呈现的噪声线调至最小程度。
- 7. 触按再现(PLAY)键, 让录象机返回至正常工作状态。
- 8. 以标准状态再现录象带数秒后,再触按慢放 (SLOW)键,检查电视荧屏上的噪声线是否明 显。

(BP方式的调整亦按与SP方式的调整方法相同进行之)。

注:

自录磁带意指于电路调整状态时录象用磁带。

NTSC制式静止画面FV(虚假垂直同步)的调试

检测仪器	监控用彩色电视机
工作状态	再现状态静止画面
使用磁带	自录磁带(SP/EP方式) (见下注)
调整点	磁迹跟踪键(+)或()
规定要求	电视荧屏上无垂直晃抖

- 1. 装入自录磁带,用SP方式录象后,再现之。
- 2. 触按暂停/静止(PAUSE/STILL)键, 静止再现图象。
- 3. 观察监控用电视机荧屏,触按磁迹跟踪键(+)或(一),将荧屏上呈现的噪声线(雪花)调至最小程度。
- 4. 用SP方式再现自录磁带,静止再现图象,检 查电视荧屏上的噪声线是否明显。 (EP方式的调整亦按与SP方式的调整方法相 同进行之)。

注:

自录磁带意指于电路调整状态时录象用磁带。

NTSC制式歪斜补偿的调整

检测仪器	监控用彩色电视机
工作状态	再现状态静止画面(SP方式)
使用磁带	校正用磁带 (VROATSV)
调整点	R5410 (闪烁控制)
规定要求	监控用电视机荧屏上无闪烁 现象

- 1.装入校正用磁带(VROATSV),设录象机于再 现静止状态。
- 2.观察监控用电视机荧屏,调节R5410,使荧屏 上的图象闪烁现象调至最小程度。

亮度/色度信号电路的调整

视频 E-E 增益的调整

测量仪器	示波器
工作状态	E-E 或录象
输入信号	EIA 彩条(1.0 Vp_p PAL 和 NTSC)
测试点	视频输出端
规定要求	1.0 ±0.2 Vp-p

- 1. 将 75Ω 端电阻接到视频输出端,再接示波器两探 针于该电阻两端。(见下注)
- 2. 输入彩条信号到视频输入端。
- 3. 让 E—E 信号的振幅达到如图 5—4 所示的1.1 Vp_p 的规定要求。
- 4. 对 NTSC 制式而言,其调整方法与 PAL 制式相同。





图 5-4

注:如果不接 75Ω 端电阻,则输出波形幅值应为上述 值的两倍。

白色限幅的调整

测量仪器	示波器
工作状态	E-E 或录象(PAL LP/NTSC EP方式)
输入信号	EIA 彩条(1.0 Vp_p PAL 和 NTSC)
测试点	IC401的(48)脚,GND
规定要求	190±5%(见下注)

- 1. 在 IC401 芯片的(48) 脚与 GND 之间接示波器。
- 2. 设录象机于 E—E 或录象状态。向视频输入端输入 彩条信号。
- 3. 检查视频信号过调量的限幅是否符合图 5-5 所示的 190%的规定要求。
- 4. 对 NTSC 制式而言,其调整方法与 PAL 制式相同。




注:从同步峰值至白色峰值,其电平为100%。于白色 电平之上,白色限幅电平为90%。

记录电平的调整

	- · · ·
测量仪器	双踪示波器
工作状态	记录(录象)方式 (PAL LP/NTSC EP 状态)
输入信号	EIA 彩条 (1.0 Vp_p PAL 和 NTSC)
測 试 点	色度(红) R514 电阻与 L509 的连接点~ GND 同步信号峰值 R225 电阻与 L210 的连接点~
规定要求	色度(红): 170±230 mVp-p 同步信号峰值: 720±880 mVp-p


- 1. 设录象机于记录状态。向视频输入端输入彩条信号。
- 2. 用双踪示波器测量上表中的每一点。
- 3. 让色度(红)及同步信号顶部的振幅达到如图 5-6 所示的规定要求。
- 4. 对 NTSC 制式而言,其调整方法与 PAL 制式相同。



再现增益的调整

检测仪器	示波器
工作状态	记录/再现(PAL LP/NTSC EP 状态)
输入信号	EIA 彩条(1.0Vp-p PAL 和 NTSC)
测试点	视频输出端
规定要求	1.0 ±0.2 Vp-p

- 1. 先确认 E-E 电平的调试已符合规定要求。
- 2. 在视频输出插孔端接一只 75Ω 终端电阻。示波器 跨接此终端电阻。(见下注)
- 3. 向视频输入插孔端输入彩条信号。设录象机于记录状态。
- 4. 再现记录有输入彩条信号部分的磁带内容。
- 5. 检查这时的输出信号幅值是否符合图 5—7 所示的 1.1Vp-p 的规定要求。
- 6. 对 NTSC 制式而言,其调整方法与 PAL 制式相同。
- 注:如果不接 750 端电阻,则输出波形幅值应为上述 之两倍。



超高画质图象的调试

检测仪器	单象管图案
工作状态	记录/再现(PAL SP 状态)
使用磁带	校正用磁带(VROCPSV)
测试点	TP402 (信号) ~TP403 (接地)
调整点	R430 (超高画质图象控制)
规定要求	

- 1.在SP状态下记录PAL制式单象管图案信号,再 现之。
- 2.接1兆Ω电阻器于测试点TP402(信号)与TP403 (接地)之间。
- 3.在监控用彩色电视机荧屏上呈现无瑕的图象 后,缓慢地旋转R430(超高画质图象控制), 直至其无瑕的图象呈杂乱状态为止。
- 4 拆开电阻器,最后检查荧屏上呈现的图象是 否回复至无瑕的图象。

Hi-Fi音频电路的调试 Hi-Fi音频电路调整的注意要点

 下述各项调整步骤均以左声道的调整为说明 对象。右声道的调整基本与其相同,步骤说 明在此省略。


记于括号"[]"中的数值、代号等是右声道省略了说明的调整数值、代号等。

- 2. Hi-Fi音频电路模块的测试调整
 - 1)记录工作状态 在此工作状态下用录象带记录电视节目的 立体声信号,并为其作控制调节。
 - 2) 再现工作状态 在此工作状态下演放录有Hi-Fi内容的录 象带,并为其作控制调节。

(可通过遥控器上的项目(MENU)键或录象 机前面的设定(SET UP)键选定音频输出声 道于再现工作状态。

再通过(+)或(一)键对音频输出方式进行选定。触按(+)或(一)键选定音频输出方式于"Hi-Fi L+R"(左右两声道Hi-Fi)。这样,左右两声道均被设定于Hi-Fi输出方式。选定结束后,多功能显示器上左右声道指示器分别点亮。)

●控制调节与测试点的位置



E-E电平的调试

检测仪器	交流毫伏特计
工作状态	E-E或记录 (录象)
输入信号	1kHz,-8dBs
测试点	音频输出插孔
规定要求	-8 ± 2dBs

- 1. 向音频输入插孔的左声道终端输入上表所述 的音频信号。
- 2. 接交流毫伏特计于音频输出插孔的左右声道 终端。
- 3. 设录象机于E-E或记录(录象)状态。检查 交流毫伏特计所测的读数是否符合上表所述 的规定要求。

(检查其电平是否满足规定值-2dB的规定要求)。

M载波频率的调试

检测仪器	计频器
工作状态	E-E或记录 (录象)
输入信号	无规定要求
测试点	TP6301(信号)~TP6302(接地)
调整点	R6310 (R6363) NTSC制式 载波频率控制 R6308 (R6365) PAL制式 载波频率控制
规定要求	1.3 (1.7) MHz ± 5kHz (NTSC制式) 1.4 (1.8) MHz ± 5kHz (PAL制式)

- 1.设录象机于A/V(声象)输入状态。切勿向 视频输入插孔输入任何信号。(拆去视频输 入端的所有接线。)
- 2. 设录象机于E-E或记录(录象)状态。接计 频器于测试点TP6301(信号)和TP6302(接地)。
- 3. 设录象机于NTSC制式,调节R6310 [R6363] (NTSC制式载波频率控制),使计频器所测 的读数达至上表所述的规定要求。
- 4. 再设录象机于PAL制式,调节R6308 (R6365) (PAL制式载波频率控制),使计频器所测的 读数达至上表所述的规定要求。

VC-ML3W

线性音频再现电平的调试

检测仪器	交流毫伏特计
工作状态	再现
输入信号	校正用磁带(VROCPZJS)
测试点	音频输出插孔
规定要求	-12.0 ± 2dBs

- 1. 接交流毫伏特计于音频输出插孔。
- 2. 装入校正用磁带(VROCPZJS), 再现之。
- 3. 检查交流毫伏特计所测的音频输出电平值是 否符合规定要求。

所测值不符合规定要求之场合, 则检查偏流。

Hi-Fi音频再现电平的调试

检测仪器	交流毫伏特计
工作状态	再现
输入信号	校正用磁带(VROCBFFS)
测试点	音频输出插孔
规定要求	-8. 0dBs ± 2dBs

- 1. 接交流毫伏特计于音频输出插孔。
- 2. 装入校正用磁带(VROCBFFS), 再现之。
- 3. 检查交流毫伏特计所测的音频输出电平值是 否符合规定要求。

注意:检查左右声道的再现电平值均为不大于 2.0dB。

Hi-Fi/标准音频自录/再现电平的调试

检测仪器	交流毫伏特计
工作状态	记录(录象)/再现
输入信号	1kHz, -8.0dBs
测试点	音频输出插孔
规定要求	-8.0dBs ± 3dBs

- 1. 向音频输入插孔的左声道终端输入上表所述 的音频信号。
 - 2. 接交流毫伏特计于音频输出插孔的左声道和右声道终端。
 - 3. 检查交流毫伏特计所测的读数是否符合规定要求。

注意:检查左右声道的再现电平值均为不大于 2.0dB。

消磁电压和振荡频率的调试

检测仪器	示波器
工作状态	记录 (录象)
测试点	完全消磁磁头
调整点	T6301
规定要求	70 ± 5kHz,大于40Vp-p


- 1. 设录象机于记录(录象)状态。
- 2. 接示波器于完全消磁磁头之两端。
- 3. 检查其磁头两端的消磁电压是否近似于或大于40Vp-p. 以及频率为70 ± 5kHz。

液晶显示器(LCD)电路的 调试

对比度电路的调试

检测仪器	示波器
工作状态	E-E
输入信号	PAL制式视频信号 (50%白色)
测试点	TP8941 (绿色信号输出端) ~GND (接地端)(TP8943)
控"制	R8902 (对比度控制)
规定要求	亮度信号电平应为相同程度 (+0.1 Vp-p)。

- 1.在声象(A/V)状态下,向视频输入端输入 PAL制式视频信号(50%白色)。
- 2.接示波器于TP8941 (绿色信号输出端) 与 GND (接地端) 之间。调节R8902 (对比度控制),使标准白色信号部分与翻转的绿色信号输出波形部分的电平达至相同程度。



旋转R8902, 以达 至相同程度的电平值。

图 5-9

水平位置的调试

检测仪器	彩色电视机监视器
工作状态	再现状态
使用磁带	校正用磁带(VROCPSV)
控 制	R9021 (水平位置控制)
规定要求	单象管图案应位于荧屏的 中央部

- 1.装入校正用磁带(VROCPSV),再现之。
- 2.边观察监控用彩色电视机边旋转R9021 (水平位置控制),直至单象管图案移至荧屏的中央部为止。

共用偏转的调试 (精调)

检测仪器	直流伏特计
工作状态	E-E
输入信号	PAL制式视频信号 (50%白色)
测试点	TP9045 (共用偏转控制)
控制	R9061 (共用偏转控制)
规定要求	1.5 ± 0.1 Vp-p

- 1.在声象(A/V)状态下,向视频输入端输入 PAL制式彩条信号。接直流伏特计于TP9045 (共用偏转控制)与GND(接地端)之间。
- 2.旋转R9061 (共用偏转控制),使直流伏特计所测的读数达至 $1.5V\pm0.1Vp$ -p的规定要求。

白色平衡的调试

检测仪器	示波器
工作状态	E-E
输入信号	PAL制式视频信号 (50%白色)
测试点	TP8941 (绿色信号输出端) ~GND (接地端), TP8940 (绿色信号输出端)~GND (接地端),TP8942 (蓝色信 号输出端)~GND (接地端)
控制	R8966 (副亮度红色控制) R8961 (副亮度蓝色控制)
规定要求	亮度信号电平应为相同程度 (+0.1 Vp-p)。

- 1.该调整应在对比度调整完毕后进行。
- 2. 调录象机于声象信号输入状态,向视频输入端输入PAL制式视频信号(白色50%)。
- 3.接示波器于TP8940与GND(接地端)之间。再接示波器于TP8942与GND(接地端)之间。然后调节8966(前者)和R8961(后者),使各亮度信号电平达至相同程度。




图5-10

VC-ML3 VC-ML3W

彩色同步信号的调试 (仅限于PAL制式)

	<u> </u>
检测仪器	示波器
工作状态	E-E (蓝色背景状态)
输入信号	无信号
控制	C8911 (PAL制式彩色同步信号 控制)
规定要求	调至水平噪声线消失为止。

- 1.设液晶显示板荧屏于PAL制式的蓝色背景状态
- 2.观察液晶显示板荧屏,调节C8911,直至完全 消失水平噪声线为止。

(必须设定于PAL制式。在NTSC制式的蓝色背景状态下旋转C8911亦不会出现变化。)

共用偏转的调试 (微调)

检测仪器	彩色电视机监视器
工作状态	E-E
输入信号	NTSC制式10阶梯波视频信号
控 制	R9021 (水平位置控制)
规定要求	消去荧屏上的垂直线条

- 1. 在声象 (A/V) 状态下,向视频输入端输入 NTSC制式10阶梯波视频信号。
- 2. 边观察监控用彩色电视机边缓慢地旋转 R9061 (共用偏转控制), 直至荧屏上消去 垂直线条为止。

注意

切勿快速地旋转控制旋钮, 否则不能观察 进行变化的图象。

射频电路

射频 AGC 电路调试

检测仪器	示波器
工作状态	良好的电视工业广播接收方式
测试点	TP1553 (信号) TP1554(地) (位于主印刷电路板中)
控 制	VR101 射頻 AGC 控制 (位于中頻包电路中)
规定要求	恰好在收缩之前(见图 59)

- 1. 让录象机接收到电视工业广播信号。(输入场强: 85dBμV 天线端)。
- 2. 接示波器于测试点 TP1553(信号)与 TP1554(地) 之间。
- 3. 在示波器上观察视频输出端的波形。调节位于中频 包电路中的 VR101(射频 AGC 控制),直到示波器 屏上的噪声消失为止,且该波形几乎进入同步。







图5-11


音频电平调谐器的检查


- 1. 在 TV Through 方式或 VCR E—E 方式下,对其音量进行比较是否相同。
- 2. 如果音量不相同,则调节中频包电路中的 VR102, 使得两者音量完全相同。



















(, 11.)


























(n)








乍


佢












注意:只使用PALANYSC3.58制式时,在液晶显示板变屏上会出现色彩。在使用SECAM制式、NTSC4.43制式及NTSC制式的YY→PAL电视状态下不会出现色彩。



IC703(EEPROM)的更换

《更换时的注意事项》


IC703(EEPROM)经更换后,必须重新编写设定其记忆数据。


- 1. 设录象机的电源开关于切断状态。(电源开关处于备用状态)
- 2.瞬间短接工作电路印刷电路板上的TP5001与TP5002之间。检查REC LED与定时器LED便点亮, 以便进入调试状态,并在液晶显示器荧屏上显示出跨接销的编号(JP-0)。
- 3.触按频道上移(+)或下移(一)键,连续输入EEPROM地址码上的JPO至JP-31的功能编号(显示在液晶显示器荧屏上)。触按DISPLAY(显示)键以启动选定的功能,或者,触按CLEAR(取消)键以取消其功能。
 - *触按DISPLAY(显示)键,便启记忆功能,REC LED和定时器LED会熄灭。
 - *触按CLEAR (取消) 键,便停止记忆功能,REC LED和定时器LED会点亮。
- 4.继续输入JP-1至JP-31的功能编号。最后,再次瞬间短接测试点TP5001与TP5002之间,取 消调试状态设定,使录象机返回至标准状态(时钟显示状态)。


	序号	功能	ML3/ML3W/NL3	MH330				
定时器	JP0	COROUR 0	0	0				
	1	COROUR 1	0	0				
	2	VPS PDC	0	0			•••••••••••••••••••••••••••••••••••••••	·
	3	SPATIALIZER	0	1	***************************************			-
	4	VCR 0	0	0				·
	5	VCR 1	0	0				
	6	SYSTEM 0	1	1				
	7	SYSTEM 1	1	1				
	8	R/C CODE	0	1				
	9	P-IN-P	0	0				
	10	LCD	1	0		}		
	11		0	0				
	12	DUAL SCART	1	1				
	13	FRONT A/V	0	0				
	14	ĹP/EP	1 ,	1				
	15	(0: 00) OEM	1	1				
系统控制器	16	G-CODE0	1	1				·
	17	G-CODE1	0	0				
	18	NICAM 0	1	1				
	19	NICAM 1	0	0				
	20	S. PICTURE	0	0	***************************************		,	
	21	DECODER	0	0				
	22	AUTO CLOCK/SORT	0	0				
	23	Hi-Fi	1	1	***************************************			
	24	HEAD0	0	1		***************************************		
	25	HEAD1	1	0		***************************************		
	26	NTSC SKEW	1	1				
	27	INSTANT REPLAY	1	1				
	28		0	0		•••••		
	29		0	0				
	30		0	0		••••		
	31		0	0		····		


(注意: "1" 意为;录象用发光二极管(REC LED)和定时器用发光二极管(TIMER LED)熄灭, "0" 意为;录象用发光二极管(REC LED)和定时器用发光二极管(TIMER LED)点亮)

8. BLOCK DIAGRAM 方框图 SERVO PROCESS/SYSTEM CONTROL BLOCK DIAGRAM 伺服处理/系统控制电路方框图










()



SCHEMATIC DIAGRAM

IMPORTANT SAFETY NOTICE:

BE SURE TO USE GENUINE PARTS FOR SE-CURING THE SAFETY AND RELIABILITY OF THE

PARTS MARKED WITH " A " AND PARTS SHADED (IN BLACK) ARE ESPECIALLY IMPOR-TANT FOR MAINTAINING THE SAFETY AND PROTECTING ABILITY OF THE SET.

BE SURE TO REPLACE THEM WITH PARTS OF SPECIFIED PART NUMBER.

电路原理图

安全使用注意要点:

为了保证本装置的安全性及可靠性, 务请 使用该型号装置的原配零件。

注有 本标记, 以及打有黑色阴影线的部分, 对于保护本装置的安全、保持其使用性能及使 用寿命极其重要.

更换这些部件时, 务请使用规定编号者。

SAFETY NOTES:

- 1. DISCONNECT THE AC PLUG FROM THE AC OUTLET BEFORE REPLACING PARTS.
- 2. SEMICONDUCTOR HEAT SINKS SHOULD BE REGARDED AS POTENTIOL SHOCK HAZARDS WHEN THE CHASSIS IS OPERATING.

安全使用注意事项:

- 1.在进行部件更换之前,务请拔出电源插头。
- 2. 本装置工作时, 机芯底盘的半导体散热片有 触电之虑、务请注意。

NOTES:

- 1. The unit of resistance "ohm" is omitted (k=1000 ohm, M=1 Meg ohm).
- 2. All resistors are 1/8 watt, unless otherwise noted.
- 3. The unit of capacitance "F" is omitted ($\mu=\mu F$, $p=\mu\mu F$).
- 4. The values in parentheses are the ones in the PB mode; the values without parentheses are the ones in the REC mode.

VOLTAGE MEASUREMENT CONDITIONS:

- 1. DC voltages are measured between points indicated and chassis ground by VTVM, with AC110~240V, 50/60Hz supplied to unit and all controls are set to normal viewing picture unless otherwise noted.
- 2. Voltages are measured with 10000µV B & W or colour noted.

WAVEFORM MEASUREMENT CONDITIONS: 10000µV 87.5 percent modulated colour bar signal is fed into tuner.

电路单位说明:

- 1. 电阻 "欧姆" (Ω) 单位予以略记(K=千欧,M= 兆欧姆)。
- 2. 除特别说明者外,图中电阻功率均为1/8瓦
- 3. 电容"法拉"(F)单位予以略记(μ=微法 拉. P=微微法拉)。
- 4.在括弧内的数值为PB状态,无括弧的数值 为REC状态。

电压测定条件

- 1.除特别说明者外, 直流电压是以AC110~ 240V, 50/60Hz交流电源供给本装置时,将 所有控制调节都调至正常状态后,把VTVM (电子管电压表)连接于测点与底盘接地之间 所得的读数。
- 2. 电压由10000 μ V黑白或彩色信号测定。


油形测定条件:


向调谐器输入10000 u V的87.5%调制色带 信号的状态时进行测量。

CAUTION:

This circuit diagram is original one. Therefore there may be a slight difference from yours.

这里的电路原理图均为最初设计原图,与您的机器 的电路原理图可能有不同之处。






* VOLTAGE MEASUREMENT MODE PB Parentheses ()

REC Without Parentheses

再现:括弧内的数值 记录:无括弧的数值


REC Without Parentheses


记录:无括弧的数值




PB Parentheses () REC Without Parentheses

再现:括弧内的数值 记录:无括弧的数值








PB Parentheses () REC Without Parentheses

再现:括弧内的数值 记录:无括弧的数值 155




····· Parentheses ()


C..... Without Parentheses

再现:括弧内的数值 记录:无括弧的数值

157



159




* VOLTAGE MEASUREMENT MODE PB Parentheses ()

REC Without Parentheses


再现:括弧内的数值 记录:无括弧的数值


161

VC-ML3 VC-ML3 VC-ML3W VC-ML3W



PWB FOIL PATTERN 印刷电路板图案 **مره**





10. REPLACEMENT PARTS LIST PARTS REPLACEMENT


Many electrical and mechanical parts in video cassette recorder have special safety-related characteristics. These characteristics are often not evident from visual inspection nor can the protection afforded by them necessarily be obtained by using replacement components rated for higher voltage, wattage, etc. Replacement parts which have these special safety characteristics are identified in this manual; electrical components having such features are identified by and shaded areas in the Replacement Parts Lists and Schematic Diagrams. The use of a substitute replacement part which does not have the same safety characteristics as the factory recommended replacement parts shown in this service manual may create shock, fire or other hazards.

"HOW TO ORDER REPLACEMENT PARTS"

To have your order filled promptly and correctly, please furnish the following informations.

- 1. MODEL NUMBER
- 2. REF. NO.
- 3. PART NO.
- 4. DESCRIPTION
- 5. PRICE CODE

HOW TO IDENTIFY CHIP TRANSISTORS AND DIODES BY ITS MARKING



- (1) Base/Input
- (2) Emitter/Ground
- (3) Collector/Output

Package		Marking	Parts No.
Fig. 1	ñ	15	VSDTA124EK/-1
Fig. 1	ř.	25	VSDTC124EK/-1
Fig. 1		24	VSDTC114EK/-1
Fig. 1		26	VSDTC144EK/-1
Fig. 1		16	VSDTA144EK/-1
Fig. 1		BQ	VS2SC2412KQ-1
Fig. 1		FQ	VS2SA1037KQ-1

MARK ★: SPARE PARTS-DELIVERY SECTION.

•				
Ref. No.	Part No.	*	Description	Code

PRINTED WIRING BOARD ASSEMBLIES

(NOT REPLACEMENT ITEM)

DUNTK5349XM50	-	Main Unit (VC-ML3)	
DUNTK5349XM53	-	Main Unit (VC-ML3W)	
DUNTK5350XM50	-	Operation Unit	_
DUNTK5354XM50	-	Rec Tip Unit	_
DUNTK5356XM50	-	Hi-Fi Unit	_
DUNTK5357XM50	-	MPX Unit	

Ref. No.	Part No.	*	Description	Code
	DUNTK5359XM50	-	LCD Unit	
	DUNTK5369XJ6B	-	Relay Unit	

DUNTK5349XM50 (VC-ML3) DUNTK5349XM53 (VC-ML3W) MAIN UNIT

TUNER AND ASSEMBLY

CNV4451	RCNVR0146GEN9	J	Converter (VC-ML3)	ВВ
CNV4451	RCNVR0146GEZZ	J	Converter (VC-ML3W)	вс
TU1551	VTUVTSR6HZ53/	J	Tuner	BD
UNT1501	RiFU-0655GEZZ	J	IF-Pack	BH

INTEGRATED CIRCUITS

AMERICATION A LINCHITATO

IC202	VHIMSM/4/0M-1	J	MSM/4/0	RD
IC291	VHiMM1111XF1E	J	MM1111	ΑE
1C301	VHiAN3366S/-1	J	AN3366S	AP
IC401	VHiHA8201CF-1	J	HA8201CF	AW
IC701	RH-iX1208GEZZ	J	IX1208GE	ΑZ
IC702	VHIS806HZ//-1	J	S806HZ	AC
IC703	VHiXL24C02F-1	J	XL24C02F	AH
IC704	VHiBA6209//1E	J	BA6209	AG
IC705	VHiBA15218F1E	J	BA15218F	ΑF
IC951	VHiUZT33///-1	J	UZT33	AC
IC2401	VHiLA7217M/-1	J	LA7217M	AG
IC5901	RH-iX1343GEZZ	J	IX1343GE	AQ
IC5902	VHiNJM2533M-1	J	NJM2533M	AF
1C5950	VHiTC4S66F/-1	J	TC4S66F	ΑĎ

TRANSISTORS

Q204	V\$2SC2412KQ-1	J	2SC2412KQ	AA
Q205	VS2SA1037KQ-1	J	2SA1037KQ	AA
Q208	VSDTC144EK/-1	J	DTC144EK	AB
Q301	VS2SC2412KQ-1	J	2SC2412KQ	AA
Q302	VSDTC124EK/-1	J	DTC124EK	AB
Q303	VSDTC124EK/-1	J	DTC124EK	AB
Q304	VSDTC124EK/-1	J	DTC124EK	AB
Q305	VS2SC2412KQ-1	J	2SC2412KQ	AA
Q306	VS2SC2412KQ-1	J	2SC2412KQ	AA
Q308	V\$2\$C2412KQ-1	J	2SC2412KQ	AA
Q341	VS2SC2412KQ-1	J	2SC2412KQ	AA
Q342	VSDTA124EK/-1	J	DTA124EK	AB
Q343	VSDTC124EK/-1	J	DTC124EK	AB
Q345	VSDTC124EK/-1	J	DTC124EK	AB
Q401	V\$2SC2412KQ-1	J	2SC2412KQ	AA
Q402	VS2SC2412KQ-1	J	2SC2412KQ	AA
Q403	VS2SC2412KQ-1	J	2SC2412KQ	AA
Q404	VS2SC2412KQ-1	J	2SC2412KQ	AA
Q405	VS2SC2412KQ-1	J	2SC2412KQ	AA
Q406	VS2SC2412KQ-1	J	2SC2412KQ	AA
Q407	VS2SC2412KQ-1	J	2SC2412KQ	AA
Q408	VS2SC2412KQ-1	J	2SC2412KQ	AA
Q409	VS2SA1037KQ-1	J	2SA1037KQ	AA
Q410	VS2SA1037KQ-1	J	2SA1037KQ	AA
 Q411	VSDTC144EK/-1	لِ	DTC144EK	AB

Ref. No.	Part No.	*	Description	Code	Ref	. No.	Part No.	*		Description	Code
	TRANSISTO		(Continued)	<u> </u>			DIODES	(Cc	n	tinued)	·
				AA		D344	VHD1SS119//-1	J	1	ISS119	AB
Q412	VS2SC2412KQ-1	J		AA		D401	VHD1SS119//-1	J	1	ISS119	AB
Q413	VS2SA1037KQ-1	J		AB			VHD1\$\$119//-1	ل	1	ISS119	AB
Q417	VSDTC144EK/-1	ال		AA			VHD1SS119//-1	J	1	ISS119	AB
Q418	VS2SC2412KQ-1	J		AB		D405	VHD1SS119//-1	ل	•	ISS119	AE
Q501	VSDTC144EK/-1	J	DTC144EK	AB		D406	VHD1SS119//-1	J	-	1SS119	AE
Q530	VSDTC144EK/-1	J,		AB		D408	VHD1\$\$119//-1	ل	-	1SS119	AE
Q540	VSDTC144EK/-1	J		AB		D540	VHD1SS119//-1	L		188119	AE
Q543	VSDTC144EK/-1	J	_	AB		D701	VHDDA204K//1E		1 1	DA204K	AE
Q544	VSDTC144EK/-1	J		AB		D703	VHD1SS119//-1		j ·	1SS119	ΑE
Q550	VSDTC144EK/-1	J		AB		D705	VHD1SS119//-1]	188119	Αl
Q551	VSDTC144EK/-1	J		AB		D708	RH-PX0234GEZ	Z.	J	Photo Diode	Al
Q565	VSDTC144EK/-1	J		AC		D709	RH-PX0233GEZ		J	Photo Diode	Al
Q603	VS2C3939SQR-1	J				D710	RH-PX0233GEZ			Photo Diode	A
Q701	VS2SA1037KQ-1	J		AA		D711	RH-PX0252GEZ		_	Photo Diode	Α
Q702	VSDTC114EK/-1	ل		AB		D711	RH-PX0252GEZ			Photo Diode	А
Q703	VS2SA1037KQ-1	J		AA			RH-PX0253GEZ		-	Photo Diode	Α
Q705	VS2SA1037KQ-1	ل		AA		D713	RH-PX0253GEZ		-	Photo Diode	A
Q901	VS2SC4300//-1	J		AM		D714				188119	A
Q902	VS2SC3377-Q-1	J	2SC3377-Q	AC		D715	VHD1SS119//-1			188119	A
Q921	VS2SA1015Y/1E	J	2SA1015Y	AC		D716	VHD1SS119//-1				Α
	VS2SC2412KQ-1	j	J 2SC2412KQ	AA		D717	VHD1SS119//-1			188119	Α
Q951	VS2SD468-C/-1	J	2SD468-C	AD		D718	VHD1SS119//-1			188119	, and a second
Q952	VSDTA124EK/-1		J DTA124EK	AB		D721	VHD1SS119//-1			188119	
Q953	VSDTC124EK/-1		J DTC124EK	AB	\triangle	D901	RH-DX0083GEZ		J	Diode Bridge	P
Q954	VS2SD468-C/-1		J 2SD468-C	AD	\triangle	D902	RH-DX0220CEZ		J	Diode	<i>F</i>
Q955	VS2SD468-C/-1		J 2SD468-C	AD	\triangle	D903	RH-DX0321CEZ	Z	J		F
Q956	VS2SD468-C/-1		J 2SD468-C	AD	Δ	D904	VHDERA1802/-	1		ERA1802	
Q957	VSDTA124EK/-1		J DTA124EK	AB	\triangle	D905	VHDERA1802/-	1		ERA1802	F
	VSDTC124EK/-1		J DTC124EK	AB	Δ	D906	VHD1SS119//-1		J	1SS119	,
Q958			J 2SC2001LK	AA	\triangle	D907	RH-EX0001AEZ	Z	J	Zener Diode	A
Q960	VS2G1740SQR1		J 2SC1740SQR	AC	\triangle	D908	RH-EX0722GEZ	ZZ	J	Zener Diode	,
Q961			J 2SD468-C	AD	$\overline{\mathbb{A}}$	D921	VHDERA1804/-	1	J	ERA1804	
Q962			J 2SD468-C	AD	Δ	D923	VHDRL3Z////-1		J	RL3Z	,
Q963			J 2SD468-C	AD	\triangle	D924	VHDRK34////-1		J	RK34	
Q964			J DTC144EK	AB	$\stackrel{\sim}{\mathbb{A}}$	D925	RH-EX0807GE	ZZ.	J	Zener Diode	,
Q150				AB	Δ	D926	VHD1SS244//-1	1	J	1SS244	
Q150			J DTC144EK	AC	دنے آگ	D928	RH-EX0619GE		J	Zener Diode	
Q150			J DTA144EK			D929	VHD1SS119//-1			188119	
Q240			J 2SA1037KQ	AA	Δ	D930	RH-EX0615GE			Zener Diode	
Q240)2 VS2SC2412KQ-		J 2SC2412KQ	AA AB	Δ		VHD1SS119//-			155119	
Q240			J DTC144EK	AB	Δ	D951	VHD1SS119//-			15\$119	
Q240)4 VSDTA144EK/-1		J DTA144EK	AC			VHD1SS119//-			188119	
Q590)1 V\$2SA1037KQ-	1	J 2SA1037KQ	AA		D952	RH-EX0634GE			Zener Diode	
Q590)2 VS2SC2412KQ-	1	J 2SC2412KQ	AA		D954				18\$119	
Q590	3 V\$2SA1037KQ-	1	J 2SA1037KQ	AA		D955	VHD1SS119//-			Zener Diode	
Q59	50 VSDTC144EK/-	1	J DTC144EK	AB		D956	RH-EX0617GE			188119	
Q59	70 VSDTA124EK/-	1	J DTA124EK	AB		D957	VHD1SS119//-				
Q59	71-VSDTA124EK/-	1	-J- DTA124EK	AB	<u> </u>		RH-DX0064GE			I AK04	
						D240				188119	
						D5970				J 1SS119	
	Ī	DIO	DES			D597				155119	
			J 1SS119	AB	Δ	C901	RH-FX0004GE	ZZ	-	J Photo Coupler	
D20			J 1SS119	AB							
D30				AB							
D34			J 188119	AB							
D34			J 188119								
D34	3 VHD1SS119//-1	l	J 15S119	AB	_						

Ref. N	o.	Part No.	*	Description	Code	Ref. No.	Part No.	*		Descri	ption	Code
		PACKAGE	D (CIRCUIT			СО	NTR	OLS			
X5	01	RCRSB0166GEZZ		Crystal, 4.43MHz	AG	R430	RVR-M4782GEZ	Z J	2.2k (3), Hai	d Adj.	AB
X5		RCRSB0188GEZZ		Crystal, 3.58MHz	AG							
X7		RCRSB0214GEZZ		Crystal, 10MHz	AG							
X7		RCRSB0138GEZZ		Crystal, 32KHz	AD		CAP	ACI	TORS			
	901	RCRSB0215GEZZ		Crystal, 17.73MHz	AG	C210	VCKYCY1HF103	BZ J	0.01	50V	Ceramic	AA
	970	RCRSB0222GEZZ		Crystal, 14.32MHz	AF	C211	VCCCCY1HH27		27p	50V	Ceramic	ДД
712	0.0	HOHODDEZZGZZZ	Ī			C212	VCEAEM1HW47			50V	Electrolytic	: AB
						C214	VCKYCY1CF224	IZ J	0.22	16V	Ceramic	AA
		COILS AND TE	RAN	ISFORMERS		C215	VCCCCY1HH10	1J J	100p	50V	Ceramic	AA
	0404			Filter	AD	C216	VCCCCY1HH10	OD J	10p	50V	Ceramic	AA
		RFILA0020CEZZ	-		AB	C217	VCKYCY1AF105	5Z J	1	10V	Ceramic	AC
L21		VP-XF101K0000		100μH	AB	C218	VCKYCY1HF103		0.01	50V	Ceramic	AA
L2		VP-DF470K0000	J	47μH	ΑB	C219	VCCCCY1HH12			50V	Ceramic	AA
L2		VP-XF560J0000		56μH	AB	C220	VCEAEM1HW33			50V	Electrolytic	
L2		VP-XF151K0000		150µH	AB	C221	VCKYCY1CB47				Ceramic	AA
L2		VP-XF560J0000		56μH	AB	C222	VCKYCY1CF10			16V	Ceramic	AA
L2		VP-XF151K0000		150μH	AB	C223	VCEAEM1HW3			50V	Electrolytic	
L2		VP-ZK101K0000		100μH	AB	C224	VCEAF 1HW2			50V	Electrolytic	
L3	01	VP-ZK180K0000	J	18μH		C224 C226	VCEAEA1HW47			50V	Electrolytic	
L3		VP-ZK180K0000	J	18μΗ	AB	C228	VCKYCY1CF22			16V	Ceramic	AA
L4		VP-DF221K0000	ال	220μH	AB	C229	VCKYCY1CF10		J 0.1	16V	Ceramic	A/
L4	02	VP-XF151K0000		150µH	AB						Electrolytic	
L4	03	VP-XF150J0000	J	15μH	AB	C230	VCEAEA0JW10				•	A.
L4	04	VP-XF330J0000	J	33μΗ ,	AB	C234	VCKYCY1CB47			7 16V		
L4	0 5	VP-XF2R7J0000	J	2.7µH	AC	C235	VCEAEM1CW1			16V	Electrolytic	
L4	06	VP-XF560J0000	J	56μH	AB	C236	VCKYCY1EF10				Ceramic	A.
L4	07	VP-XF5R6K0000	J	5.6µH	AB	C237	VCCCCY1HH33		J 33p		Ceramic	A
L4	08	VP-XF101K0000	J	100µH	AB	C238	VCCCCY1HH5F		•		Ceramic	A/
L5	01	VP-MK561K0000	J	560μ H	AB	C239	VCCCCY1HH56				Ceramic	A.
L5	02	VP-XF560K0000	J	56μH	AB	C240	VCKYCY1HB39				Ceramic	A,
L5	04	VP-XF150J0000	J	15μΗ	AB	C241	VCKYD41HB15	1K	J 150p		Ceramic	A
L5	05	VP-XF100K0000	J	10μH	AB	C244	VCKYCY1HB22		J 220F	50V	Ceramic	A
L5	06	VP-XF470K0000	J	47μΗ	AB	C260	VCKYCY1EB10		J 0.01	25V	Ceramic	A
L5	07	VP-XF101K0000	J	100μΗ	AB	C281	VCEAEM1CW2	26M	J 22	16V	-	
L5		VP-XF151K0000	J	150μΗ	AB	C289	VCEAEM1HW1	06M	J 10	50V	Electrolyti	c A
L5		VP-XF6R8K0000	J	6.8µH	AB	C291	VCKYCY1HF10)3Z	J 0.01	50V	Ceramic	Α
L6		VP-2K221K000K		220μH	AB	C292	VCEAEM1CW1	06M	J 10	16V	Electrolyti	c A
L9		RCILF0277GEZZ	J		AG	C293	VCEAEM1CW2			16V	Electrolyti	c A
L9		RCiLP0232CEZZ		Coil	AD	C294	VCEAEM1AW2	26M	J 22	10V	Electrolyti	ic A
L9		RCiLP0232CEZZ		Coil	AD	C301	VCEAEM0JW1	07M	J 100	6.3\	/ Electrolyti	ic A
L9		RCILP0232CEZZ		Coil	AD	C302	VCKYCY1HF10	03 Z	J 0.01	50V	Ceramic	A
	20 551	VP-XF120K0000		12μH	AB	C303	VCEAEM1HW1	05M	J 1	50V	Electrolyti	ic A
		VP-XF120K0000		12μH	AB	C304	VCKYCY1HF10	03Z	J 0.01	50V	Ceramic	A
	553			220µH	AB	C305	VCKYCY1CF22	24Z	J 0.22	16V	Ceramic	Α
	401	VP-MK221K0000		33µH	АВ	C306	VCKYCY1CF2	24Z	J 0.22	16V	Ceramic	A
	402	VP-XF330K0000			AB	C307	VCKYCY1CF2	24Z	J 0.22	16V	Ceramic	А
	451	VP-DF100K0000		10μH 15μH	AB	C308	VCKYCY1CF2		J 0.22	16V	Ceramic	А
	901	VP-XF150J0000		15µH 100uH	AB	C309	VCCCCY1HH2		J 27p	50V		Д
	902	VP-DF101K0000		100μH 100μH	AB	C310	VCCCCY1HH2		J 27p	50V		
	903	VP-DF101K0000		100µH 13∪H	AB	C311	VCCCCY1HH2		J 27p	50V		A
	950	VP-XF120K0000		12µH 100∪H	AB	C312	VCCCCY1HH2		J 27p	50V		í
L5	970	VP-XF101K0000		100μH	AB	C312	VCKYCY1HF1		J 0.01			
L5	971	VP-XF101K0000		100µH	AB AB	C314	VCKYCY1HF1		J 0.01			A
L5	972	VP-XF101K0000		100μH								ia A
Te	801	RTRNH0053GEZZ			AE	C315	VOLVOVILLE1			50V	•	
T9	01	RTRNZ0029AJZZ	V	Transformer	AP	C316	VCKYCY1HF1		J 0.01			Α
						C317	VCKYCY1HF2	23Z	J 0.02	2 50V	Ceramic	Α

ef. No.	Part No.	*	7)escr	iption	Code	Ref. No.	Part No.	*		Descr	iption C	ode
	CAPACITO	DRS	((Conti	nuec	1)			CAPACITO	RS (Conti	nuec	1)	
C318	VCEAEM0JW47		-			Electrolytic	AB	C526	VCCCCY1HH680.	J	68p	50V	Ceramic	ΑA
C319	VCKYCY1HF103	3Z .	J	0.01	50V	Ceramic	AA	C527	VCCCCY1HH470.	J	47p	50V	Ceramic	AA
C320	VCKYCY1HF223		j	0.022	50V	Ceramic	AB	C528	VCCCCY1HH560.	J	56p	50V	Ceramic	AΑ
C321	VCKYCY1HF223		J	0.022	50V	Ceramic	AB	C529	VCEAEM1HW475	МJ	4.7	50V	Electrolytic	ΑB
C322	VCCCCY1HH68					Ceramic	AA	C530	VCCCCY1HH121	J	120p	50V	Ceramic	AΑ
C323	VCKYCY1HF103			•	50V	Ceramic	AA	C531	VCCSD41HL010M	1 J	1p	50V	Ceramic	AA
C324	VCKYCY1HF103				50V	Ceramic	AA	C532	VCCCCY1HH470	J	47p	50V	Ceramic	AΑ
C325	VCKYCY1EF104					Ceramic	AA	C533	VCCCCY1HH470	J	47p	50V	Ceramic	AA
C329	VCKYCY1HF103					Ceramic	AA	C535	VCCCCY1HH680	J	68p	50V	Ceramic	AA
C330	VCKYCY1HF103	-			50V	Ceramic	AA	C536	VCKYCY1HB681F	(J	680p	50V	Ceramic	AA
C331	VCKYCY1CF104		-		16V	Ceramic	AA	C537	VCKYCY1HF103Z	J	0.01	50V	Ceramic	AA
C342	VCKYCY1HF103		-		50V	Ceramic	AA	C538	VCCCCY1HH101	J	100p	50V	Ceramic	ДА
C342	VCKYCY1HF103				50V	Ceramic	AA	C541	VCKYCY1CF104Z		0.1	16V	Ceramic	ΑА
	VCEAEM1CW47				16V	Electrolytic		C550	VCCCCY1HH120		12p	50V	Ceramic	ΑА
C401			-		50V	Ceramic	AA	C621	VCEAEA1CW476		47	16V	Electrolytic	AB
C402	VCKYCY1HF100				50V	Ceramic	AA	C622	VCKYCY1EB103h		0.01	25V	Ceramic	AΑ
C403	VCCCCY1HH12			•			AA	C623	VCKYCY1EB103F		0.01	25V	Ceramic	A٨
C404	VCKYCY1HB39		J		50V	Ceramic	AA	C624	VCQPYA2AA562				Mvlar	AC
C405	VCCCCY1HH39				50V	Ceramic		C625	VCCSPA1HL221J			50V	Ceramic	AA
C406	VCCCD41HH15		J	15p	50V	Ceramic	AA	C626	VCKYCY1HF1032		0.01	50V	Ceramic	A/
C407	VCCCCY1HH33		J	1	50V	Ceramic	AA		VCKYCY1HF1032		0.01	50V	Ceramic	Α/
C408	VCCCCY1HH56		J	56p	50V	Ceramic	AA	C702	VCEAEM1HW105		1	50V	Electrolytic	AE
C410	VCKYCY1HB10		J	1000p		Ceramic	AA	C703			0.1	50V	Mylar	AE
C411	VCKYCY1HB22			•	50V	Ceramic	AA	C705	VCFYSA1HB104			16V	Ceramic	A/
C412	VCKYCY1HB68		J	680p	50V	Ceramic	AA	C709	VCKYD41CY103l		0.01			
C414	VCKYCY1HF10	3Z	J	0.01	50V	Ceramic	AA	C710	VCKYCY1HF103		0.01	50V	Ceramic	A
C417	VCCCCY1HH33	30J	J	33p	50V	Ceramic	AA	C711	VCEAEM0JW476		47	6.3V	•	A!
C418	VCEAEM1HW47	74M	J	0.47	50V	Electrolytic		C712	VCKYD41CX682I		6800r		Ceramic [,]	A/
C419	VCKYCY1HB39	2K	J	3900p	50V	Ceramic	AA	C715	VCEAEM1CW106		10	16V	Electrolytic	AI
C422	VCKYCY1EB10	зк	j	0.01	25V	Ceramic	AA	C718	VCEAEM1CW226			16V	Electrolytic	Al
C423	VCKYCY1HF10	3Z	J	0.01	50V	Ceramic	AA	C722	VCCCCY1HH180		18p	50V	Ceramic	A,
C424	VCKYCY1HF10	3 Z	J	0.01	50V	Ceramic	AA	C724	VCCCCY1HH180		18p	50V	Ceramic	A
C425	VCKYCY1HF10	3Z	J	0.01	50V	Ceramic	AA	C725	VCKYCY1HF103		0.01	50V	Ceramic	A
C427	VCKYCY1HF10	3Z	J	0.01	50V	Ceramic	AA	C726	VCCCCY1HH220	J	22p	50V	Ceramic	A
C501	VCKYD41CX33	2N	J	3300p	16V	Ceramic	AA	C727	VCCCCY1HH220	J J	22p	50V	Ceramic	A
C502	VCKYCY1HB27	1K	J	270p	50V	Ceramic	AA	C728	VCKYCY1HF103	Z J	0.01	50V	Ceramic	A
C503	VCKYCY1HF10			0.01	50V	Ceramic	AA	C729	VCKYCY1HB472	K J	إ4700	50V	Ceramic	A
C504	VCEAEM0JW10	07M	J	100	6.3V	Electrolytic	c AB	C730	VCEAEM0JW336	M J	33	6.3V	Electrolytic	Α
C505	VCKYCY1CB47	зк	J	0.047	16V	Ceramic	AA	C731	VCKYCY1HF103	ΖJ	0.01	50V	Ceramic	A.
C506	VCKYCY1HF10			0.01	50V	Ceramic	AA	C732	VCKYCY1HF103	Z J	0.01	50V	Ceramic	A.
C508	VCKYCY1HF10			0.01	50V	Ceramic	AA	C733	VCKYCY1HB472	K J	4700	p 50V	Ceramic	Α
C509	VCKYCY1EB15					Ceramic	AA	C734	VCEAEM0JW107	M J	100	6.3V	Electrolytic	Α
C510	VCEAEM1HW3			3.3	50V	Electrolyti		C735	VCEAEM1HW10	5M J	1	50V	Electrolytic	Α
C511	VCCCCY1HH33			33p	50V	Ceramic	AA	C736	VCKYCY1HF103	Z J	0.01	50V	Ceramic	A.
C512	VCKYCY1HF10			0.01	50V	Ceramic	AA	C737	VCCCCY1HH470			50V	Ceramic	Α
C512	VCKYCY1EF10		J	0.1	25V	Ceramic	AA	C738	VCCCCY1HH470			50V	Ceramic	Α
	VCKYCY1CB33						AA	C739	VCCCCY1HH470		'	50V		Α
C514									VGKYGY1HB102					A
C515	VCKYCY1CB47						c AB	C740	VCKYCY1HB102					A
C516	VCEAEM1HW4			4.7	50V	•		C741	VCKYCY1HF103			50V		A
C517	VCCCCY1HH1			15p	50V	Ceramic	AA						Electorolytic	
C518	VCCCCY1HH2		J	22p	50V	Ceramic	AA	C743	RC-EZ0425GEZZ				-	
C519	VCKYCY1HF10			0.01	50V	Ceramic	AA	C744	VCKYD41HB102			•	Ceramic Caramic	A
C520	VCEAEM1HW4			0.47	50V	Electrolyti		C746	VCKYCY1HF103					A
C521	VCKYCY1HF22	23Z	J	0.022		Ceramic	AB	C747	VCKYCY1HF103					A
C522	VCKYCY1AF10)5Z	J	1	10V	Ceramic	AC	C749	VCKYCY1HB102					A
C523	VCEAEM1CW1	06M	J	10	16V	Electrolyti	c AB	C750	VCKYCY1HB102	K .	1000	p 50V	Ceramic	Α

Ref	. No.	Part No.	*	0	escri	otion C	ode	Ref. No.	Part No.	*	-		escri	ption Co	ode
		CAPACITO	BS (Conti)		<u> </u>	CAPACI	TORS	((Contir	nued	1)	
	C751	VCKYCY1HF103				Ceramic	AA	C1510	VCQYTA1HM	1333J J	J.	0.033	50V	Mylar	ΑА
	C752					- Ceramic	AA	C1511	VCEAEM1CV	V106M J	J	10	16V	Electrolytic	ΑB
	C753	VCKYCY1HF103				Ceramic	AA	C1515	RC-EZ0459C	EZZ .	j			Electorolytic	ΑE
	C754	VCKYCY1EF104 VCE9EM1HW105	_	•••		Elect.(N.P.)	AB	C1551	VCKYCY1EF	104Z .	J	0.1	25V	Ceramic	ΑA
	C755	VCESEM1CW47		,		Electrolytic	AB	C1552	VCEAEA1HW	√106M √	J	10	50V	Electrolytic	ΑĐ
	C756	VCKYCY1EF104				Ceramic	AΑ	01553	ACKACATHE	103Z .	J	0.01	50V	Ceramic	Δ
	C758	VCKYCY1HB102				Ceramic	AA	C1554	VCKYCY1HF	103Z .	J	0.01	50V	Ceramic	A
	C759	VCKYCY1HF103				Ceramic	AA	C1555	VCEAEM1CV	V476M -	J	47	16V	Electrolytic	Α
	C760	VCEAEM1CW47		47		Electrolytic	AB	C1556	VCKYPA1HF	103Z -	J	0.01	50V	Ceramic	A
	C761	VCKYCY1HB222		2200p		Ceramic	AA	C1557	VCEAEM1CV	M106M	J	10	16V	Electrolytic	Α
	C762	VCKYCY1EF104				Ceramic	AA	C1560	VCCCCY1H	1470J	J	47p	50V	Ceramic	Α
	C763	VCKYCY1EF104		0.1		Ceramic	AA	C1561	VCEAEM1C\	N106M	J	10	16V	Electrolytic	Α
	C764	VCKYCY1EF104		-		Ceramic	AA	C2202	VCEAEA1HV	V335M	J	3.3	50V	Electrolytic	A
	C765	VCFYSA1HB334				Mylar	AB	C2401	VCKYCY1HF	F103Z	J	0.01	50V	Ceramic	Α
	C766	VCEAEM1CW47			-	Electrolytic	AB	C2402	VCEAEM1C\	W106M	J	10	16V	Electrolytic	Α
	C767	VCKYCY1HB102				Ceramic	AA	C2403	VCKYCY1HF	-103Z	J	0.01	50V	Ceramic	Α
		VCKYCY1EF104				Ceramic	AA	C2404	VCEAEM1H1			1	50V	Electrolytic	A
	C769	VCFYSA1HB104				Mylar	AB	C2405	VCKYCY1HE	3102K	J	1000p	50V	Ceramic	A
	C770	VCEAEM0JW47				Electrolytic	AB	C2406	VCKYCY1HI	F223Z	J	0.022	50V	Ceramic	F
	C771 C772	VCKYCY1EB18				Ceramic	AA	C2407	VCFYSA1HE	3563J	J	0.056	50V	Mylar	A
	C774	VCKYCY1EF104			25V	Ceramic	AA	C2408	VCEAEM1H	W105M	J	1	50V	Electrolytic	A
		VCKYCY1HF10			50V	Ceramic	AA	C4404	VCEAEM1C	W476M	J	47	16V	Electrolytic	1
	C780	VCKYCY1HF10			50V	Ceramic	AA	C4452		F104Z	J	0.1	25V	Ceramic	1
	C781	VCKYCY1EF104			25V	Ceramic	AA	C5901	VCCCCY1H	H151J	J	150p	50V	Ceramic	1
	C782	RC-FZ071SGEZ					AF	C5902			J	18p	50V	Ceramic	1
<u>N</u>	C901			0.047		Mylar	AE	C5903			J	150p	50V	Ceramic	,
λ	C904	RC-FZ063SGEZ				Ceramic	AC	C5905				0.1	25V	Ceramic	,
Δ	C905	RC-KZ0310CEZ				Ceramic	AC	C5906			J	1	50V	Electrolytic	,
Δ	C906	RC-KZ0310CEZ		٠'		' Electorolyti		C5908			J		25V	Ceramic	,
Δ	C907	RC-EZ0437GEZ				' Ceramic	AC	C5909			J	6p	50V	Ceramic	,
Λ	C908	RC-KZ0310CEZ		•		Ceramic Ceramic	AC	C5910					50V	Ceramic	
Δ	C909	RC-KZ0310CEZ		'		' Electrolytic		C5911				•	10V	Electrolytic	ı
Δ	C910	VCEAGA2AW10				∕ Mylar	, AC AC	C5912					50V	Ceramic	
<u>^</u>	C911	VCFYZP2GA47				Ceramic	AC		VCCCCY1F				50V	Ceramic	
Δ	C912	RC-KZ0037GEZ		J 220p			AB	C5916							
Λ	C913	VCFYSA1HB10		J 0.1 J 0.047	50V	Mylar Mylar	AA	C5917					50V		
Δ	C914	VCFYSA1HB47	_			•	AA	C5918					16V		
Δ	C915	VCFYSA1HB47		J 0.047			AA	C5921					16V		
Λ	C916	VCQYTA1HM2			p 50V	•	AC	C5922					16V		
Δ	C924	RC-QZ0104GE			•	/ Mylar		C5923							
Δ	C925	RC-EZ0439GE				Electoroly		C5924					50V		
≙	C926	VCEAGA1CW1			16V	Electrolytic		C592					16V		
Δ	C927	VCEAGA1JW1			63V	Electrolytic		C5926							
Δ	C929	RC-EZ0439GE		J 2200				C592							
Λ	C930	VCEAGA1AW4			10V	-		C593	·					V Electrolytic	
Δ	C931	VCEAGA1HW4			50V			C595					50\	•	
Δ	C935	VCEAEM1HW1			50V	-		C595							
Δ	C936	VCKYCY1EF10		J 0.1	25V		AA AA	C595					50\		
Δ	C937	VCKYCY1EF10		1.0 L	25V		AΑ ΔΔ'	C593					50\		
	C951	VCFYSA1HB22		J 0.02			AA	C597					50\		
	C952	VCEAEM1CW			16V			C397.	Z V000011	HUMUL	, ,	oh .	ວບ\	/ Ceramic	
	C953	VCEAEM1CW2				Electrolyti			1						
	C954	VCEAEM1CW2			16V	-				DEC	c-	TOPO			
	C955	VCEAEM1AW4			10V	-				HESI	<u>ت</u>	TORS			
Δ	C956	VCEAGA1CW4			16V	•		R211	VRS-CY1J	F152J		J 1.5k	1/16	W Metai Oxida	e
Δ	C957	VCEAGA1CW	107M	J 100	16V	Electrolyti	ic AB	R212	VRS-CY1J	F472J	,	J 4.7k	1/16	W Metal Oxid	е

Ref. No.	Part No.	*		Description	Co	de	Ref. No.	Part No.	*		Description	Со	de ——
	RESISTOR	S (C	ontii	nued)				RESISTORS	S (C	onti	nued)		
5010	VRS-CY1JF272J			1/16W Metal O	xide	AA	R415	VRS-CY1JF103J	j	10k	1/16W Metal (Oxide	AA
R213	VRS-CY1JF103J	_		1/16W Metal C		AA	R416	VRS-CY1JF472J	J	4.7k	1/16W Metal (Oxide	AA
R214	VRS-CY1JF272J			1/16W Metal C		AA	R417	VRS-CY1JF182J	J	1.8k	1/16W Metal (Oxide	AA
R215	VRS-CY1JF102J		,	1/16W Metal C		AA	R418	VRS-CY1JF222J	J	2.2k	1/16W Metal (Oxide	AA
R216	VRS-CY1JF471J	ن ل		1/16W Metal C		AA	R419	VRS-CY1JF152J	J	1.5k	1/16W Metal (Oxide	AA
R217	VRS-CY1JF122J			1/16W Metal C		AA	R420	VRS-CY1JF562J	J	5.6k	1/16W Metal (Oxide	AA
R219	VRS-CY1JF152J			1/16W Metal C			R421	VRS-CY1JF102J	J	1k	1/16W Metal (Oxide	AA
R220	VRS-CY1JF392J			1/16W Metal C		AA	R422	VRS-CY1JF153J	J	15k	1/16W Metal (Oxide	AA
R224	VRS-CY1JF271J	J		1/16W Metal C		AA	R423	VRS-CY1JF392J	J	3.9k	1/16W Metal	Oxide	AA
R228	VRS-CY1JF223J	ل		1/16W Metal C		AA	R424	VRS-CY1JF471J	J	470	1/16W Metal	Oxide	AA
R229 R230	VRS-CY1JF223J	J		1/16W Metal C		AA	R425	VRD-RA2BE272J	J	2.7k	1/8W Carbo	n	AA
	VRS-CY1JF562J	ن		1/16W Metal C		AA	R426	VRS-CY1JF822J	J	8.2k	1/16W Metal	Oxide	AA
R265	VRS-CY1JF123J	J		1/16W Metal C		AA	R427	VRS-CY1JF104J	J	100k	1/16W Metal	Oxide	AA
R301	VRD-RA2BE224J	J		1/8W Carbon		AA	R428	VRS-CY1JF471J	J	470	1/16W Metal	Oxide	AA
R303	VRS-CY1JF182J	J		1/16W Metal C		AA	R429	VRS-CY1JF681J	J	680	1/16W Metal	Oxide	AA
R304 R305	VRS-CY1JF222J	J		1/16W Metal C		AA	R431	VRS-CY1JF102J	J	1k	1/16W Metal	Oxide	AA
	VRD-RA2BE473J	-	47k	1/8W Carbon		AA	R432	VRS-CY1JF122J	J	1.2k	1/16W Metal	Oxide	AA
R307	VRS-CY1JF473J		47k	1/16W Metal 0		AA	R433	VRS-CY1JF123J	J	12k	1/16W Metal	Oxide	AA
R308	VRS-CY1JF470J	_	47	1/16W Metal (AA	R434	VRS-CY1JF103J	J	10k	1/16W Metal	Oxide	AA
R309	VRS-CY1JF470J	_	47	1/16W Metal (AA	R435	VRS-CY1JF681J	J	680	1/16W Metal	Oxide	AA
R310	VRS-CY1JF822J	-		1/16W Metal (AA	R436	VRS-CY1JF333J	J	33k	1/16W Metal	Oxide	AA
R311	VRS-CY1JF152J	J		1/16W Metai (AA	R438	VRS-CY1JF472J	J	4.7k	1/16W Metal	Oxide	AA
R312	VRS-CY1JF152J	ı	1.5k			AA	R439	VRS-CY1JF153J	J	15k	1/16W Metal	Oxide	AA
R314	VRS-CY1JF822J	ں ل		1/16W Metal (ÁΑ	R440	VRS-CY1JF123J	J	12k	1/16W Metal	Oxide	AA
R315	VRD-RA2BE103J	J		1/8W Carboi		AA	R441	VRS-CY1JF332J	J	3.3k	1/16W Metal	Oxide	AA
R316	VRS-CY1JF181J	J		1/16W Metal (AA	R442	VRS-CY1JF122J	J	1.2k	1/16W Metal	Oxide	AA
R317	VRS-CY1JF223J	J		1/16W Metal (AA	R443	VRS-CY1JF473J	J	47k	1/16W Metal	Oxide	AA
R318 R319	VRS-CY1JF183J		18k	1/16W Metal		AA	R444	VRS-CY1JF224J	J	2201	< 1/16W Metal	Oxide	AA
	VRS-CY1JF180J	J		1/16W Metal		AA	R446	VRS-CY1JF105J	J	1M	1/16W Metal	Oxide	AA
R320 R323	VRD-RA2BE103J	J		1/8W Carbo		AA	R447	VRS-CY1JF105J	J	1M	1/16W Metal	Oxide	AA
R326	VRD-RA2BE682J	J		1/8W Carbo		AA	R501	VRS-CY1JF151J	J	150	1/16W Metal	Oxide	AA
R330	VRS-CY1JF153J	J		1/16W Metal		AA	R502	VRS-CY1JF821J	J	820	1/16W Metal	Oxide	AA
R331	VRS-CY1JF561J	J		1/16W Metal		AA	R506	VRS-CY1JF103J	J	10k	1/16W Metal	Oxide	AA
	VRS-CY1JF123J	J	401.	1/16W Metal		AA	R507	VRS-CY1JF103J	J	10k	1/16W Metal	Oxide	AA
R332	VRS-CY1JF123J		12k	1/16W Metal		AA	R508	VRS-CY1JF272J	J	2.7	1/16W Metai	Oxide	AA
R333	VRS-CY1JF152J			1/16W Metal			R510	VRS-CY1JF273J	·	27k	1/16W Metal	Oxide	AA
R334 R341	VRS-CY1JF470J		47	1/16W Metal			R511	VRS-CY1JF272J		2.7	1/16W Meta	Oxide	AA
R342	VRS-CY1JF152J			1/16W Metal			R513	VRS-CY1JF102J	Ļ	l 1k	1/16W Meta	Oxide	AA
R343	VRS-CY1JF392J			1/16W Metal			R515	VRS-CY1JF102J		1 1k	1/16W Meta	l Oxide	AA
R344	VRS-CY1JF472J			1/16W Metal			R516	VRS-CY1JF561J	,	560	1/16W Meta	l Oxide	AA
R346	VRD-RA2BE822J			1/8W Carbo		AA	R 517	VRS-CY1JF222J		2.2	c 1/16W Meta	l Oxide	AA
R401	VRS-CY1JF122J			1/16W Metal		AA	R520	VRS-CY1JF102J		J 1k	1/16W Meta	I Oxide	AA
R402	VRS-CY1JF272J			1/16W Metal			R523	VRS-CY1JF103J	,	J 10k	1/16W Meta	l Oxide	AA
R403	VRS-CY1JF273J		J 27k				R525	VRS-CY1JF123J		J 12k	1/16W Meta	l Oxide	AA
R403	VRS-CY1JF103J		J 10k				R530	VRD-RA2BE473	ϳ,	J 47k	1/8W Carb	on	AA
R405	VRS-CY1JF561J		J 560				R540	VRS-CY1JF103J	١,	J 10k	1/16W Meta	l Oxide	AA
				1/.16W Metal			R547	VRS-CY1JE154J		J150	k_1/16W.Meta	l Oxide	_AA_
	VRS-CY1JF471J		J 470				R551	VRD-RA2BE123		J 12k	1/8W Carb	on	AA
R407	VRS-CY1JF152J			1/16W Metal			R565	VRS-CY1JF222J	} .	J 2.2	k 1/16W Meta	d Oxide	AA
R408	VRS-CY1JF101J		J 100				R631	VRS-CY1JF470.	J.	J 47	1/16W Meta	d Oxide	AA
R409	VRS-CY1JF472J			< 1/16W Metal			R632	VRS-CY1JF682J		J 6.8	k 1/16W Meta	մ Oxide	AA
R410	VRS-CY1JF271J		J 270				R633	VRG-SC2EB4R7	J	J 4.7	1/4W Fuse	Resist	orAB
R411			J 820				R635	VRS-CY1JF333.	J	J 33l	1/16W Meta	ıl Oxide	AA
R412			J 820				R643	VRS-CY1JF272,	j	J 2.7	k 1/16W Meta	ıl Oxide	AA
R413				1/16W Meta			R679	VRD-RA2BE820		J 82	1/8W Carb	on	AA
R414	VIIO-0110F2/30												

Ref. No.	Part No.	*		Descrip	otion	Code	е	Ref.	No.	Part No.	*		De	escrip	tion Co	ode
	RESISTOR	S (C	 Contii	nued)						RESISTOF	S (Col	ntinı	ıed)		
H701	VRS-CY1JF273J	, J		1/16W N	detal Oxid	le A	Α	F	R766	VRS-CY1JF102J	J	1k	: 1/	16W N	letal Oxide	AΑ
R702	VRD-RA2BE562J	J		1/8W (Α	Α	F	767	VRS-CY1JF102J	J	1k	: 1/	16W N	Metal Oxide	AΑ
R704	VRS-CY1JF681J	J			Metal Oxid	le A	Α	F	7769	VRS-CY1JF222J	J	2.	2k 1/	16W N	letal Oxide	A.
R705	VRD-RA2BE102J	j		1/8W (Α	Α	F	3771	VRS-CY1JF103J	J	10)k 1/	16W N	Metal Oxide	A
R713	VRS-CY1JF471J	J			Metal Oxid	le A	Α	F	7772	VRD-RA2BE223J	J	22	2k 1/	8W C	Carbon	A
R714	VRS-CY1JF471J	J			Metal Oxid		Α	F	7773	VRS-CY1JF103J	J	10)k 1/	16W N	/letal Oxide	A.
R715	VRS-CY1JF102J	J			Metal Oxic		A	F	7774	VRD-RA2BE334J	J	33	30k 1/	8W (Carbon	A
R716	VRS-CY1JF183J	j			Metal Oxid		A	F	R775	VRS-CY1JF103J	J	10	0k 1/	16W N	Metal Oxide	A
R717	VRS-CY1JF393J	J			Metal Oxio		A	F	R776	VRS-CY1JF104J	J	10	00k 1/	16W N	Metal Oxide	Α
R718	VRS-CY1JF223J	J			Metal Oxio		A	1	R777	VRS-CY1JF104J	J	10	00k 1/	16W N	Metal Oxide	Α
R719	VRS-CY1JF153J	J			Metal Oxid		ιA	I	R778	VRS-CY1JF185J	J	1.	.8M 1	16W	Metal Oxide	A
R720		j			Metal Oxid		λA	ı	R779	VRS-CY1JF473J	J	4	7k 1	/16W I	Metal Oxide	Α
R721	VRS-CY1JF564J	J			Metal Oxid		ιA	1	P781	VRD-RA2BE223	ا ا	2	2k 1.	/8W (Carbon	Α
R722	VRS-CY1JF224J VRS-CY1JF104J	J			Metal Oxid		λA	!	R782	VRS-CY1JF103J		1	0k 1.	/16W I	Metal Oxide	Α
R723	VRS-CY1JF104J	ا.			Metal Oxid		λA	1	R784	VRS-CY1JF272J		2	.7k 1	/16W I	Metal Oxide	A
R724	VRS-CY1JF684J	J			Metal Oxid		λA		R785	VRS-CY1JF103J		1	0k 1	/16W !	Metal Oxide	A
R725	VRS-CY1JF103J	J			Metal Oxi		۱A		R786	VRS-CY1JF103J		1	0k 1	/16W	Metal Oxide	A
R726	VRS-CY1JF683J	J			Metal Oxi		λA		R788	VRD-RA2BE102	J.	1 1	k . 1	/8W	Carbon	A
R720	VRS-CY1JF224J	J			Metal Oxi		λA		R789	VRD-RA2BE331	Ι,	3	30 1	/8W	Carbon	A
	VRS-CY1JF274J	J			Metal Oxi		AΑ		R790	VRS-CY1JF101J		, 1	00 1	/16W	Metal Oxide	
R728	VRS-CY1JF392J	ن ال			Metal Oxi		۸A		R791	VRS-CY1JF101		J 1	00 1	/16W	Metal Oxide	A
R729	VRS-CY1JF223J	J			Metal Oxi				R792	VRS-CY1JF102		J 1	k 1	/16W	Metal Oxide	, ,
R730	VRD-ŘA2BE182J				Carbon		AA		R794	VRS-CY1JF822.	١,	J 8	.2k 1	/16W	Metal Oxide	, <i>A</i>
R731	VRD-RA2HD680J				Carbon		AA		R 7 97	VRS-CY1JF102.			.k 1	/16W	Metal Oxide	. /
R732	VRS-CY1JF473J	J			Metal Oxi				R801	VRS-CY1JF822			3.2k 1	/16W	Metal Oxide	. /
R733	VRS-CY1JF102J		1 1k		Metal Oxi		AA		R802	VRS-CY1JF822		JE	3.2k 1	/16W	Metal Oxide	. /
R734	VRS-CY1JF102J		1 1k		Metal Oxi		AA		R803	VRD-RA2BE102	ل	J 1	ık -	/8W	Carbon	1
R735	VRD-RA2BE102J		J 1k		Carbon		AA		R804	VRS-CY1JF102	J	J -	k ·	1/16W	Metal Oxide	3 /
R736	VRD-RA2BE102J) 1k		Carbon		AA		R805	VRS-CY1JF101	j	j -	100	I/16W	Metal Oxide	9 /
R737	VRD-RA2BE102J) 1k		Carbon		AA		R807	VRD-RA2BE104	J	J .	100k ⁻	1/8W	Carbon	1
R738	VRS-CY1JF102J		J 1k		/ Metal Ox		AA		R810	VRD-RA2BE471		J 4	470 ·	1/8W	Carbon	,
R739	VRS-CY1JF471J		J 470		/ Metal Ox		AA		R811	VRD-RA2BE102		j.	1k	1/8W	Carbon	,
R740	VRB-RA2BE102J		J 1k		Carbon		AA		R812	VRS-CY1JF102		j ·		1/16W	Metal Oxide	е.
R741	VRD-RA2BE102	_	J 1k		Carbon		AA		R813	VRD-RA2BE102		J		1/8W	Carbon	
F1742	VRD-RA2BE102		j 1k		Carbon		AA		R823	VRS-CY1JF102		J		1/16W	Metal Oxide	е.
R743	VRD-RA2BE104				Carbon		AA		R824	VRS-CY1JF103				1/16W	Metal Oxide	e .
R745	VRD-RA2BE102		J 1k		Carbon		AA		R834	VRS-CY1JF102		J		1/16W	/ Metal Oxide	е
R746	VRD-RA2BE472				Carbon		AA		R837	VRD-RA2BE10		J		1/8W	Carbon	
R747	VRS-CY1JF103J		J 10k		V Metal Ox	ride	AA		R842	VRD-RA2BE10					Carbon	
R748	VRS-CY1JF154J				V Metal Ox		AA		R845	VRD-RA2BE10					Carbon	
R749	VRD-RA2BE102		J 1k		Carbon		AA		R846	VRS-CY1JF105			1M		/ Metal Oxid	
R750	VRD-RA2BE154				Carbon		AA		R847	VRS-CY1JF103					Metal Oxid	
R751	VRD-RA2BE102		J 1k		Carbon		AA		R848	VRS-CY1JF103					V Metal Oxid	
R752	VRS-CY1JF123J		ე (K ე 12k		V Metal Ox	vide	AA		R849	VRS-CY1JF100				1/16V	V Metal Oxid	
R753	VRS-CY1JF123J		J 12k		V Metal O		AA	Α	R901	VRD-RA2HD10					Carbon	•
F754	VRD-RA2BE102		J 1k		Carbon		AA	\triangle	R902	RR-WZ0002GE		J		2W	Cement	
R755			J 150		Carbon		AA	<u> </u>	R903	VRC-UA2HG68		J		1/2W		
R756	VRD-RA2BE104				Carbon		AA	Δ	R904	VRC-UA2HG68		J		1/2W		
R757			J 270		Carbon		AA	<u> </u>	R905	VRS-VV3AB10		J	100k		Metal Oxid	le
R758	DAGDE404				Carbon		AA		R906	VRS-VV3AB10			100k		Metal Oxid	
R759	100 BA00E074		J 270		Carbon		AA	Δ	R907			J				F
R760			J 1k		Carbon			<u> </u>		VRD-RA2EE33		j		1/4W		l
R761					Fuse Re	aciete	AA \rAC	Δ	R908	RR-SZ0006GE		J	68k	3W	Acid metal	
R762	1100 OVA (E400		J 2.2					Δ	R909			j	100	2W	Acid metal	
R764			J 10		W Metal O		AA	\triangle	R910			J	47	3W	Acid metal	I
R765	VRS-CY1JF103	J.	J 101	v 1/36)	W Metal O	xiae	AA	Δ	R911	VRD-RA2EE10	11J	J	100	1/4W	Carbon	

Re	ef. No.	Part No.	*		Descr	iption	Cod	le 	Ref	. No.	Part No.	*		Description	Code
		RESISTOR	S (0	Conti	inued))					RESISTO	RS (Со	ntinued)	
Δ	R912	VRD-RA2EE821J	J	820	1/4W	Carbon	А	A		R2409	VRD-RA2BE224	J J	2	20k 1/8W Carbon	A
Δ	R921	VRD-RA2HD100J	J	10	1/2W	Carbon	А	A		R2410	VRD-RA2BE684	J	6	80k 1/8W Carbon	A
7	R923	VRG-SC2EB100J	J	10	1/4W	Fuse Res	istorA	В		R2411	VRD-RA2BE154	J	13	50k 1/8W Carbon	A
7	R925	VRD-RA2BE221J	J	220	1/8W	Carbon	А	·Α		R4401	VRD-RA2BE151	J	1	50 1/8W Carbon	A
<u>1</u>	R926	VRS-CY1JF103J	J	10k	1/16W	Metal Oxi	de A	·Α		R5904	VRD-RA2BE391) J	3	90 1/8W Carbon	Α
Δ	R927	VRS-CY1JF153J	Ĵ	15k	1/16W	Metal Oxi	de A	λA		R5905	VRD-RA2BE153	J	1:	5k 1/8W Carbon	Α
Δ	R928	VRD-RA2BE221J	j	220	1/8W	Carbon	Δ	ιA		R5906	VRD-RA2BE103	J	1	0k 1/8W Carbon	Α
<u>1</u>	R929	VRS-CY1JF221J	J		1/16W	Metal Oxi	de A	ιA		R5908	VRD-RA2EE181	J	1	80 1/4W Carbon	Α
Δ	R930	VRD-RA2BE272J	J		1/8W	Carbon	Α	λA		R5909	VRS-CY1JF332J	J	3	.3k 1/16W Metal Oxid	e A
Δ	R931	VRD-RA2BE272J	J			Carbon	A	λ Α		R5910	VRD-RA2EE151	j J	1.	50 1/4W Carbon	Α
<u></u>	R932	VRS-CY1JF392J	J			Metal Oxi	de A	۱A		R5924	VRS-CY1JF122J		1	.2k 1/16W Metal Oxid	le A
::7	R934	VRS-CY1JF682J		6.8k		Metal Oxi		ΙA		R5925	VRS-CY1JF332J		3	.3k 1/16W Metal Oxid	le A
	R952	VRS-CY1JF180J	J			Metal Oxi		١A		R5950	VRS-CY1JF104J		1	00k 1/16W Metal Oxid	le A
	R953	VRS-CY1JF823J	_	82k		Metal Oxi		\A		R5963	VRS-CY1JF101J		1	00 1/16W Metal Oxid	le A
	R954	VRD-RA2HD6R8J	J			Carbon		\A		R5970	VRD-RA2BE272	ي ل	2	.7k 1/8W Carbon	A
	R955	VRD-RA2HD6R8J		6.8		Carbon	A	\A						•	
	R956	VRD-RA2BE1R0J		1	1/8W	Carbon		۱A							
	R957	VRD-RA2BE1R0J		1	1/8W	Carbon		۱A			MISCELLA	NE	οu	IS PARTS	
	R958	VRD-RA2BE1R0J	J		1/8W	Carbon		۱A	٨		QACCV2005AJZ			C Cord (VC-ML3)	Α
	R959	VRD-RA2HD561J	J	•		Carbon		۱A	Δ		QACCB5010GE			AC Cord (VC-ML3W)	A
		VRS-CY1JF100J	J			/ Metal Oxi		۱A	\triangle	E004				Fuse, T2AL/250V	A
	R961		J		.,	Metal Oxi		λA	Δ	F901	QFS-C2023CEZ			•	A
	R962	VRS-CY1JF223J	J			Carbon		AA		FB701	RBLN-0043CEZ			Balun	
	R963	VRD-RA2BE221J				Metal Oxi		٩A		FB1501	RBLN-0043CEZ			Balun Turan Malalan	Α
	R964	VRS-CY1JF181J	J			/ Metal Oxi		AA	Δ	FH901	QFSHD1010CE			use Holder	A
	R965	VRS-CY1JF563J	ل ر			/ Metal Ox		~^ 4A	Δ	FH902	QFSHD1009CE			Fuse Holder	A
	R966	VRS-CY1JF331J	J			/ Metal Oxi		AA		P201	QPLGN0278GE			Plug, 2pin	A
	R967	VRS-CY1JF391J	J		.,					P203	QPLGN0759RE			Plug, 7pin	Δ.
	R968	VRS-CY1JF273J	J			/ Metal Ox		Α Α • •		P204	QPLGN0378GE			Plug, 3pin	Α.
	R969	VRS-CY1JF470J	J			/ Metal Ox		4 Α		P401	QPLGN0347RE			Plug, 3pin	A
	R970	VRS-CY1JF822J	J		., , , ,	/ Metal Ox		4A * *		P501	QPLGN0347RE			Plug, 3pin	Δ.
	R971	VRS-CY1JF470J	J			/ Metal Ox				P601	QPLGN0247RE			Plug, 2pin	A
	R972	VRS-CY1JF100J	J			/ Metal Ox		AA		P603	QPLGN0578GE			Plug, 5pin	A
	R973	VRS-CY1JF103J	J			/ Metal Ox				P701	QPLGZ0974GE	ZZ	JF	Plug, 9pin	A
	R974	VRD-RA2BE271J		270		Carbon		AA		P702	QPLGN0247RE	ZZ		Plug, 2pin	Α
	R975	VRD-RA2BE1R0J		1		Carbon		AA 		P704	QPLGN0278GE	ZZ	JF	Plug, 2pin	P
	R976	VRD-RA2BE1R0J	J	1		Carbon		AA	\triangle	P901	QPLGN0269GE	ZZ	JF	Plug, 2pin	F
	R977	VRD-RA2BE1R0J	J	1		Carbon		AA		P4401	QPLGN0859RE	ZZ	j F	⊃lug, 8pin	A
	R978	VRD-RA2HD561J	J	560		Carbon		AA		P4402	QPLGZ0531GE	ZZ	J F	Plug, 5pin	A
	R979	VRD-RA2HD561J		560		Carbon		AA		P4403	QPLGZ1231GE	<u>77</u>	JF	Plug, 12pin	A
Δ	R980	VRG-SC2EBR47J	J	0.47	1/4W	Fuse Rea	sistor	AB		P4404	QPLGZ1231GE	ZZ	j F	Plug, 12pin	F
	R1501	VRS-CY1JF822J	J	8.2k	1/167	V Metal Ox	ide i	AA		P4405	QPLGZ0831GE	77	J F	Plug, 8pin	F
	R1502	VRD-RA2BE392J	J	3.9k	1/8W	Carbon		AA		P5901	QPLGN1178GE	ZZ	J	Plug, 11pin	A
	R1510	VRD-RA2BE182J	_			Carbon		AA		SC301	QSOCN1194RE	ZZ	J S	Socket, 11pin	A
	R1551	VRS-CY1JF472J	J	4.7k	1/16V	V Metal Ox	ide .	AA		SC302	QSOCN0884RE	ZZ	J	Socket, 8pin	A
	R1552	VRS-CY1JF474J	J	4701	k 1/16V	V Metal Ox	dde .	AA		SC303	QSOCN0884RE	ZZ	J	Socket, 8pin	A
	R1553	VBS-CY1JF101J	J	100	_1/16V	V MetaLOx	ide	AA		-SG601-	-QSOGN0604RE	N4	J{	Socket, 6pin	
	R1554	VRS-CY1JF472J	J	4.7k	1/16V	V Metal Ox	ide .	AA		SC701	QSOCN0704RE	N1	؛ ل	Socket, 7pin	J
	R2401	VRD-RA2BE392J	ل	3.9k	1/8W	Carbon		AA		SC702	QSOCN0704RE	N1	J :	Socket, 7pin	,
	R2402	VRD-RA2BE681J	J	680	1/8W	Carbon		AA		TP601	QPLGZ0252GE			Plug, 2pin	,
	R2403	VRD-RA2BE154J	J	150	k 1/8W	Carbon		AA		TP701	QPLGN0247RE			Plug, 2pin	,
	R2404	VRD-RA2BE273J	J	27k	1/8W	Carbon		AA			QPLGN0447RE			Plug, 4pin	į
	R2405	VRD-RA2BE273J		27k		Carbon		AA						U - 1	
	R2406	VRD-RA2BE272J				Carbon		AA							
	R2407	VRS-CY1JF102J		1k		V Metal Ox		AA					_	—— End of Mair	ı
						Carbon							_	EIIG OI IMBII	4

ef. No.	Part No.	* 	Descr	iption Co	de	Ref. No.	Part No.	*	Description	Code
	DUNTK5	350	XM50)			RESISTO	RS (C	Continued)	
	OPERAT	ION	TINU			R5054	VRS-CY1JF101J	J	100 1/16W Metal O	xide A
	OF ETIAL					R5055	VRS-CY1JF750J	J	75 1/16W Metal O	xide A
	INTEGRATE	D CI	RCUITS	S						
IC5001	VHiUPD16312-1		D16312		AQ		MISCELLA	NEO	US PARTS	
						J5001	QJAKG0020GEZ	Z J	Jack	A
						J5002	QJAKE0043GEZ	ΖJ	Jack	Al
	TRANS	ISTC	RS			P5001	QPLGN0580GEZ	ΖJ	Plug, 5pin	Al
Q5001	VSDTA114ES/-1	J D	TA114ES		AB	P5002	QPLGN0578GEZ	ΖJ	Piug, 5pin	A
Q5002	VSDTA114ES/-1	J D	TA114ES		AB	RMC5001	RRMCU0052GE	ZZ J	R/C Receiver	Α
						S5002	QSW-K0094GEZ	Z J	Switch	A
						S5003	QSW-K0094GEZ	ΖJ	Switch	Α
	DIO	DES				S5004	QSW-K0095GEZ	Z J	Switch	A
D5001	VHD1SS119//-1	J 18	SS119		AB	S5006	QSW-K0095GEZ	ΖJ	Switch	A
D5002	VHD1SS119//-1		SS119		AB	S5007	QSW-K0094GEZ	Z J	Switch	A
D5003	VHD1SS119//-1	-	SS119		AB	S5009	QSW-K0095GEZ		Switch	A
D5004	VHD1SS119//-1	J 1	SS119		AB	S5012	QSW-K0094GEZ	Ζj	Switch	Α
D5006	RH-PX0204GEZZ	JΡ	hoto Diod	ė	AB	55014	QSW-K0094GEZ	ΖJ	Switch	A
D5007	RH-PX0268CEZZ		hoto Diod		AC	\$5015	QSW-K0094GEZ	ΖJ	Switch	A
D5008	RH-PX0216GEZZ	JP	hoto Diod	е	AB	S5016	QSW-Z0001AJZ	z v	Switch	A
D5010	VHD1SS119//-1	J 1	SS119		AB	SC5001	QSOCN0704RE	V1 J	Socket, 7pin	Α
	,					SC5003	QSOCN0403RE	V1 J	Socket, 4pin	Α
						TP5001	QPLGN0247REZ	Z J	Plug, 2pin	Α
	CONT	rol	_S			TP5005	QPLGN0247REZ	Z J	Plug, 2pin	Α
R5050	RVR-B4373GEZZ									
113000	CAPA	СІТО		i e	AD					
C5003 C5005 C5008 C5009		CITO J 5 J 2 J 4	60p 50V 2 16V	Ceramic Electrolytic Electrolytic	AA AB AB AA					
C5003 C5005 C5008 C5009 C5015	CAPA VCKYD41HB561K VCEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K	CITO J 5 J 2 J 4 J 0 J 2	60p 50V 2 16V 7 16V .01 50V 20p 50V	Ceramic Electrolytic Electrolytic Ceramic Ceramic	AA AB AB AA AA			- Enc	d of Operation U	nit —
C5003 C5005 C5008 C5009	CAPA VCKYD41HB561K VCEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z	CITO J 5 J 2 J 4 J 0 J 2	60p 50V 2 16V 7 16V .01 50V 20p 50V	Ceramic Electrolytic Electrolytic Ceramic Ceramic	AA AB AB AA		W			nit —
C5003 C5005 C5008 C5009 C5015	CAPA VCKYD41HB561K VCEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K	CITO J 5 J 2 J 4 J 0 J 2 J 2	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V	Ceramic Electrolytic Electrolytic Ceramic Ceramic	AA AB AB AA AA		DUNTI		54XM50	nit —
C5003 C5005 C5008 C5009 C5015 C5016	CAPA VCKYD41HB561K VCEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K	J 5 J 2 J 2 J 2 STOI	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V RS	Ceramic Electrolytic Electrolytic Ceramic Ceramic Ceramic	AA AB AB AA AA		DUNTI REC	(53: TIP	54XM50 UNIT	nit —
C5003 C5005 C5008 C5009 C5015 C5016	CAPA VCKYD41HB561K VCEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K VRS-CY1JF393J VRD-RA2BE123J	CITO J 5 J 2 J 2 J 2 STOI J 3 J 1	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V RS 9k 1/16V 2k 1/8W	Ceramic Electrolytic Electrolytic Ceramic Ceramic Ceramic	AA AB AA AA AA		DUNTI REC	(53 TIP	54XM50 UNIT DUS PARTS	nit —
C5003 C5005 C5008 C5009 C5015 C5016 R5001 R5002 R5003	CAPA VCKYD41HB561K VCEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K VRS-CY1JF393J VRS-CY1JF393J VRS-CY1JF223J	J 5 2 3 4 4 J 0 2 J 2 2 STOI J 3 1 1 J 2 2	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V RS 9k 1/16V 2k 1/8W 2k 1/16V	Ceramic Electrolytic Electrolytic Ceramic Ceramic Ceramic V Metal Oxide Carbon V Metal Oxide	AA AB AA AA AA AA	P801	DUNTI REC	(53 TIP	54XM50 UNIT	
C5003 C5005 C5008 C5009 C5015 C5016 R5001 R5002 R5003 R5004	CAPA VCKYD41HB561K VCEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K VRS-CY1JF393J VRD-RA2BE123J VRS-CY1JF223J VRD-RA2BE472J	J 5 J 2 J 2 STOI J 3 J 4 J 2 J 4	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V RS 9k 1/16V 2k 1/16V 2k 1/16V	Ceramic Electrolytic Electrolytic Ceramic Ceramic Ceramic W Metal Oxide Carbon W Metal Oxide Carbon	AA AB AA AA AA AA	P801 \$701	DUNTI REC MISCELLA QPLGN0278GE	(53 TIP	54XM50 UNIT DUS PARTS	Α
C5003 C5005 C5008 C5009 C5015 C5016 R5001 R5002 R5003 R5004 R5005	CAPA VCKYD41HB561K VCEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K VRS-CY1JF393J VRD-RA2BE123J VRD-RA2BE472J VRS-CY1JF223J VRS-CY1JF223J	J 5 J 2 J 4 J 0 J 2 J 2 STOI J 3 J 1 J 2 J 2 J 2 J 2 J 2 J 2 J 2 J 2 J 2	60p 50V 2 16V 7 16V 20p 50V 20p 50V 20p 50V 38 1/16V 2k 1/16V 2k 1/16V 2k 1/16V 2k 1/16V 20 1/16V	Ceramic Electrolytic Electrolytic Ceramic Ceramic Ceramic W Metal Oxide Carbon W Metal Oxide Carbon W Metal Oxide	AA AB AA AA AA AA AA		DUNTI REC MISCELLA QPLGN0278GE	(53 TIP	54XM50 UNIT DUS PARTS Plug, 2pin (EF)	Α
C5003 C5005 C5008 C5009 C5015 C5016 R5001 R5002 R5003 R5004 R5005 R5006	CAPA VCKYD41HB561K VCEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K VRS-CY1JF393J VRD-RA2BE123J VRS-CY1JF223J VRS-CY1JF221J VRS-CY1JF221J VRD-RA2BE473J	CITO J 5 J 2 J 4 J 0 J 2 STOI J 3 J 1 J 2 J 4 J 2 J 4	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V RS 9k 1/16V 2k 1/16V .7k 1/8W 20 1/16V 7k 1/8W	Ceramic Electrolytic Electrolytic Ceramic Ceramic Ceramic W Metal Oxide Carbon W Metal Oxide Carbon W Metal Oxide	AA AB AA AA AA AA AA AA		DUNTI REC MISCELLA QPLGN0278GE	(53 TIP	54XM50 UNIT DUS PARTS Plug, 2pin (EF)	Α
C5003 C5005 C5008 C5009 C5015 C5016 R5001 R5002 R5003 R5004 R5005 R5006 R5008	CAPA VCKYD41HB561K VCEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K VRS-CY1JF393J VRD-RA2BE123J VRS-CY1JF223J VRD-RA2BE472J VRS-CY1JF221J VRD-RA2BE473J VRD-RA2BE473J VRS-CY1JF472J	CITO J 5 5 1 2 2 3 4 4 J 0 2 2 3 4 4 J 2 2 3 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V RS 9k 1/16V 2k 1/16V .7k 1/8W 20 1/16V 7k 1/8W	Ceramic Electrolytic Electrolytic Ceramic Ceramic Ceramic V Metal Oxide Carbon V Metal Oxide	AA AB AA AA AA AA AA AA		DUNTI REC MISCELLA QPLGN0278GE	(53 TIP	54XM50 UNIT DUS PARTS Plug, 2pin (EF)	A
C5003 C5005 C5008 C5009 C5015 C5016 R5002 R5003 R5004 R5005 R5006 R5008 R5009	CAPA VCKYD41HB561K VCEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K VRS-CY1JF393J VRD-RA2BE123J VRS-CY1JF223J VRD-RA2BE472J VRS-CY1JF221J VRD-RA2BE473J VRS-CY1JF472J VRS-CY1JF472J	CITO J 5 J 2 J 4 J 0 J 2 STOI J 3 J 1 J 2 J 4 J 4 J 4 J 4	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V RS 9k 1/16V 2k 1/8W 2k 1/16V .7k 1/8W .7k 1/16V .7k 1/16V	Ceramic Electrolytic Ceramic Ceramic Ceramic W Metal Oxide Carbon W Metal Oxide W Metal Oxide W Metal Oxide	AA AB AA AA AA AA AA AA AA		DUNTI REC MISCELLA QPLGN0278GE	(53 TIP	54XM50 UNIT DUS PARTS Plug, 2pin (EF)	A
C5003 C5005 C5008 C5009 C5015 C5016 R5001 R5002 R5003 R5004 R5005 R5006 R5008 R5009 R5010	CAPA VCKYD41HB561K VCEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K VRS-CY1JF393J VRD-RA2BE123J VRS-CY1JF223J VRD-RA2BE472J VRS-CY1JF221J VRD-RA2BE473J VRS-CY1JF472J VRS-CY1JF472J VRS-CY1JF472J VRD-RA2BE331J	CITO J 5 J 2 J 4 J 0 J 2 STOI J 3 J 1 J 2 J 4 J 4 J 4 J 3	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V RS 9k 1/16V 2k 1/16V .7k 1/8W .7k 1/16V	Ceramic Electrolytic Electrolytic Ceramic Ceramic Ceramic W Metal Oxide Carbon W Metal Oxide Carbon W Metal Oxide Carbon W Metal Oxide Carbon W Metal Oxide	AA AB AA AA AA AA AA AA AA AA		DUNTI REC MISCELLA QPLGN0278GE	(53 TIP	54XM50 UNIT DUS PARTS Plug, 2pin (EF)	Α
C5003 C5005 C5008 C5009 C5015 C5016 R5001 R5002 R5003 R5004 R5005 R5006 R5008 R5009 R5010 R5011	CAPA VCKYD41HB561K VCEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K VRS-CY1JF393J VRD-RA2BE123J VRD-RA2BE472J VRS-CY1JF223J VRD-RA2BE472J VRS-CY1JF472J VRS-CY1JF472J VRS-CY1JF472J VRD-RA2BE331J VRD-RA2BE473J VRD-RA2BE473J	CITO J 5 J 2 J 4 J 0 J 2 STOI J 1 J 2 J 4 J 4 J 4 J 4 J 4 J 4 J 4	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V RS 9k 1/16V .7k 1/8W .7k 1/8W .7k 1/16V	Ceramic Electrolytic Electrolytic Ceramic Ceramic Ceramic W Metal Oxide Carbon Carbon Carbon Carbon Carbon Carbon	AA AB AA AA AA AA AA AA AA AA		DUNTI REC MISCELLA QPLGN0278GE	(53 TIP	54XM50 UNIT DUS PARTS Plug, 2pin (EF)	A
C5003 C5005 C5008 C5009 C5015 C5016 R5001 R5002 R5003 R5004 R5005 R5006 R5008 R5009 R5010 R5011 R5011	CAPA VCKYD41HB561K VGEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K VRS-CY1JF393J VRD-RA2BE123J VRS-CY1JF223J VRS-CY1JF223J VRS-CY1JF221J VRD-RA2BE472J VRS-CY1JF472J VRS-CY1JF472J VRD-RA2BE331J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J	CITO J 5 2 2 3 4 4 J 2 2 5 5 T O I 3 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 4 J 4 J 4 4 J 4 J 4 J 4 J 4 J 4 J 4 J 4 J 4 J 4 J 4 J 4 J 4 J 4 J 4 J 4 J 4 J 4 J 4 J 4 J	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V RS 9k 1/16V .7k 1/8W 20 1/16V .7k 1/16V .7k 1/16V .7k 1/16V .7k 1/16V .7k 1/16V .7k 1/8W	Ceramic Electrolytic Electrolytic Ceramic Ceramic Ceramic W Metal Oxide Carbon W Metal Oxide	AA AB AA AA AA AA AA AA AA AA		DUNTI REC MISCELLA QPLGN0278GE	(53 TIP	54XM50 UNIT DUS PARTS Plug, 2pin (EF)	Α
C5003 C5005 C5008 C5009 C5015 C5016 R5001 R5002 R5003 R5004 R5005 R5006 R5008 R5009 R5010 R5011 R5012 R5013	CAPA VCKYD41HB561K VGEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K VRS-CY1JF393J VRD-RA2BE123J VRS-CY1JF223J VRS-CY1JF223J VRD-RA2BE472J VRS-CY1JF472J VRS-CY1JF472J VRD-RA2BE331J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J	CITO J 5 2 2 3 4 4 J 2 2 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 J 3 4 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V RS 9k 1/16V .7k 1/8W .7k 1/16V .7k 1/16V .7k 1/8W .7k 1/16V .7k 1/8W .7k 1/16V .7k 1/8W .7k 1/16V .7k 1/8W	Ceramic Electrolytic Electrolytic Ceramic Ceramic Ceramic W Metal Oxide Carbon W Metal Oxide W Carbon W Metal Oxide Carbon W Metal Oxide Carbon W Metal Oxide Carbon W Metal Oxide	AA AB AA A		DUNTI REC MISCELLA QPLGN0278GE	(53 TIP	54XM50 UNIT DUS PARTS Plug, 2pin (EF)	Α
C5003 C5005 C5008 C5009 C5015 C5016 R5002 R5003 R5004 R5005 R5006 R5008 R5009 R5010 R5011 R5012 R5013 R5014	CAPA VCKYD41HB561K VGEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K VRS-CY1JF393J VRD-RA2BE123J VRS-CY1JF223J VRS-CY1JF223J VRS-CY1JF221J VRD-RA2BE472J VRS-CY1JF472J VRS-CY1JF472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE221J VRD-RA2BE221J	CITO J 5 2 3 4 4 J 2 2 5 5 T O I J 4 4 J 2 3 4 4 J 2 4 J 2 4 J 2 4 J 2 4 J 2 4 J 2 5 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6 J 2 6	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V RS 9k 1/16V 2k 1/8W 2k 1/16V .7k 1/8W .7k 1/16V .7k 1/8W	Ceramic Electrolytic Electrolytic Ceramic Ceramic Ceramic W Metal Oxide Carbon W Metal Oxide W Metal Oxide Carbon W Metal Oxide Carbon W Metal Oxide Carbon W Metal Oxide Carbon Carbon W Metal Oxide Carbon Carbon Carbon	AA AB AA		DUNTI REC MISCELLA QPLGN0278GE	(53 TIP	54XM50 UNIT DUS PARTS Plug, 2pin (EF)	Α
C5003 C5005 C5008 C5009 C5015 C5016 R5002 R5003 R5004 R5005 R5006 R5008 R5009 R5010 R5011 R5012 R5013 R5014 R5015	CAPA VCKYD41HB561K VCEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K VRS-CY1JF393J VRD-RA2BE123J VRS-CY1JF223J VRD-RA2BE472J VRS-CY1JF221J VRD-RA2BE473J VRS-CY1JF472J VRS-CY1JF472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE221J VRD-RA2BE221J VRD-RA2BE221J	CITO J 5 2 3 4 4 J 2 2 5 5 T O I J 4 4 J 2 2 4 J 2 2 3 4 4 J 2 2 3 4 4 J 2 2 3 4 4 J 2 2 3 4 4 J 2 2 3 4 4 J 2 2 3 4 4 J 2 2 3 4 4 J 2 2 3 4 4 J 2 2 3 4 4 J 2 2 3 4 4 J 2 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 2 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4 J 3 4	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V RS 9k 1/16V .7k 1/8W .7k 1/16V	Ceramic Electrolytic Electrolytic Ceramic Ceramic Ceramic W Metal Oxide Carbon Carbon W Metal Oxide Carbon Carbon W Metal Oxide Carbon Carbon W Carbon Carbon Carbon	AA AB AA A		DUNTI REC MISCELLA QPLGN0278GE	(53 TIP	54XM50 UNIT DUS PARTS Plug, 2pin (EF)	Α
C5003 C5005 C5008 C5009 C5015 C5016 R5002 R5003 R5004 R5005 R5006 R5008 R5009 R5010 R5011 R5012 R5013 R5014	CAPA VCKYD41HB561K VGEAEA1CW226M VGEAEA1CW476M VCKYCY1HF103Z VCKYD41HB221K VCKYD41HB221K VCKYD41HB221K VRS-CY1JF393J VRD-RA2BE123J VRS-CY1JF223J VRS-CY1JF223J VRS-CY1JF221J VRD-RA2BE472J VRS-CY1JF472J VRS-CY1JF472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE472J VRD-RA2BE221J VRD-RA2BE221J	CITO J 5 2 3 3 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4 4	60p 50V 2 16V 7 16V .01 50V 20p 50V 20p 50V RS 9k 1/16V 2k 1/8W .7k 1/8W .7k 1/16V .7	Ceramic Electrolytic Electrolytic Ceramic Ceramic Ceramic W Metal Oxide Carbon W Metal Oxide W Metal Oxide Carbon W Metal Oxide Carbon W Metal Oxide Carbon W Metal Oxide Carbon Carbon W Metal Oxide Carbon Carbon Carbon	AA AB AA A		DUNTI REC MISCELLA QPLGN0278GE	(53 TIP	54XM50 UNIT DUS PARTS Plug, 2pin (EF)	nit —

Ref. No.	Part No.	*	Descript	ion Code	•	Ref. No.	Part No.	*		Descri	otion C	ode
1161.110.			6XM50				CAPACITO	ORS (Cont	nued)	
						C6309	VCKYCY1EB103	sk J	0.01	25V (Deramic	AA
	H	i-Fi U	NI I			C6310	VCKYCY1EB103	₿K J	0.01	25V (Ceramic	AA
						C6311	VCFYSA1HB153	i Li	0.015	50V I	Mylar	AA
	INTEGR	ATED	CIRCUITS			C6312	VCEAEM0JW10	7M. J	100	6.3V I	Electrolytic	AB
IC6301	VHIAN3965F/-		AN3965F	А	V	C6313	VCEAEM1HW22	25M J	2.2	50V	Electrolytic	AB
	VHIBA7755AF	•	BA7755AF	Д	E		VCEAEM1CW33		33		Electrolytic	AB
1C6502			M5222FP	А	G	C6315	VCKYCY1CB47	зк Ј	0.047		Ceramic	AA
	VHiBA15218F		BA15218F	A	F	C6316	VCKYCY1AF10		1	-	Ceramic	AC
100000	VI IIBA TOLIG					C6318	VCKYCY1AF10	5Z J	1	,	Ceramic	AC
						C6320	VCKYCY1CF33				Ceramic	AA
	TR.	ANSIS	TORS			C6322	VCEAEA0JW47				Electrolytic	AB
			DTC144EK	Į.	ιВ	C6323	VCEAEA1CW10			16V	Electrolytic	AB
Q6302	VSDTC144EK				λB	C6324	VCEAEM1CW1	06M J	10		Electrolytic	AB
Q6305	VSDTA124EK		DTC363TK		\B	C6325	VCEAEM1CW1				Electrolytic	AB
Q6306	VSDTC363TK		DTC363TK		\B	C6326	VCEAEM1CW1				Electrolytic	AB
Q6307	VSDTC363TK		DTC363TK		.~ \В	C6327	VCEAEM1CW2	26M J	22		Electrolytic	AB
Q6308	VSDTC363TK				. <u>.</u> ∖B	C6328	VCEAEA1CW1	06M J	10	16V	Electrolytic	AB
Q6311	VSDTC144EK				AB	C6329	VCCCCY1HH5	50J J	56p	50V	Ceramic	AA
Q6312					AB	C6330	VCEAEA1HW3			50V	Electrolytic	AB
Q6315					AB	C6331	VCFYSA1HB15		0.01		Mylar	AA
Q6316					AB	C6332	VCEAEM1CW1			16V	Electrolytic	
Q6317					AB	C6333	VCKYCY1HB6				Ceramic	AA
Q6318					AB	C6334	VCEAEM1CW1	06M		16V	Electrolytic	
Q6321		-			AA	C6337	VCFYSA1HB22			2 50V	Mylar	AA
Q6323					AB	C6338	VCKYCY1HB6			p 50V	Ceramic	AA
Q6504		-			AB	C6339	VCKYCY1HB6)p 50V	Ceramic	AA
Q6507					ÁB	C6340	VCKYCY1HB2		J 2200	•	Ceramic	AA
Q6508				3	AC	C6341	VCKYCY1AF1		J 1	10V	Ceramic	AC
Q6511	VS2C174050	KUIF O	200 (7 (00 a.	•		C6342	VCKYCY1HB1				Ceramic	AA
						C6343	VCKYCY1HB3)p 50V	Ceramic	AA
		DIOD	FS			C6344	VCCCCY1HH				Ceramic	AA
					AB	C6345					Electrolytic	
D6309			J 188119		AA	C6349				50V	Electrolytic	
D6501	RH-EX06340	iEZZ .	J Zener Diode		, , ,	C6350	VCKYCY1CF3				Ceramic	AA
						C6352					Ceramic	AC
	00110.43	ID TD	NCEODNE	DC		C6354			J 1	10V		AC
	COILS AF		NSFORME	ΠO		C6356			J 0.3			AA
L6301			J 68µH		AB	C6357				17 16V		AA c AB
L6303	3 VP-YF822J0	000	J 8200µH		AC	C6358				16V 50V	•	
						C6359					Electrolyti / Electrolyti	
			2010			C6360					-	AA
		CONT				C6361				15 50V 1 25V		AA
R630			J 22k (B), PAL		AD	C6362				1 25V 16V		
R631			J 10k (B), NTS		AD	C6376					Ceramic	AA
R636			J 10k (B), NTS		AD	C6385						AA
R636	5 RVR-M4500	CEZZ	J 47k (B), PAI	_ Adj.	AF	C6388						
······································						C6389						AA
						C6390						AA
	(CAPAC	ITORS			C639					/ Ceramic	AA
C630	1 VCCCCY1H	H101J	J 100p 50V	Ceramic	AA	C639					/ Ceramic	AA
C630				Electrolytic	AB	C639						
C630				Ceramic	AA	C652					-	
C630	_			Electrolytic	AB	C652						AA AA
C630	•			Ceramic	AA	C652						
				Ceramic	AA	C652	/ VICEAEATOV	V LOOK	با سی	10		

Ref. No.	Part No.	*		Descr	iption	Cod	e	Ref. No.	Part No.	*		Description	Cod	de
	CAPACITORS	 S ((Cont	inue	 d)				RESISTOR	S (C	onti	nued)		
C6528	VCEAEM1CW106M			16V	Electrolytic	A	В		VRS-CY1JF223J	J	22k	1/16W Metal Oxid		AA
C6529	VCCCCY1HH181J			50V	Ceramic		ιA	R6355	VRD-RA2BE393J	J	39k	1/8W Carbon		AA
C6530	VCEAGA1AW107M		100	10V	Electrolytic	, A	В	R6356	VRS-CY1JF223J	J	22k	1/16W Metal Oxid	-	AA
C6531			100	10V	Electrolytic	, A	В	R6357	VRD-RA2BE393J	J	39k	1/8W Carbon		AA
C6532	VCCCCY1HH181J	_		50V	Ceramic		λA	R6358	VRS-CY1JF471J	J	470	1/16W Metal Oxid	et	AA
C6533	VCEAEM1CW106M		10	16V	Electrolytic	, A	λB	R6359	VRS-CY1JF472J	J	4.7k	1/16W Metal Oxid	et	AA
C6536			100p	50V	Ceramic		λA	R6360	VRS-CY1JF123J	J	12k	1/16W Metal Oxid	ət	AA
C6537	VCCCCY1HH101J	Ī.	100p	50V	Ceramic	A	λA	R6361	VRS-CY1JF392J	J		1/16W Metal Oxi		AA
C6538	VCCCCY1HH101J		100p	50V	Ceramic	F	AΑ	R6362	VRS-CY1JF103J	J		1/16W Metal Oxi		AA
			100p	50V	Ceramic	ļ	AΑ	R6364	VRS-CY1JF152J	J	1.5k	1/16W Metal Oxi	de	AA
C6539	VCCCCY1HH101J		0.1	16V	Ceramic	Á	٩A	R6371	VRS-CY1JF104J	J	100k	1/16W Metal Oxi	de	AA
C6540	VCKYCY1CF104Z			16V	Electrolytic		ΑВ	R6372	VRS-CY1JF104J	J	100k	: 1/16W Metal Oxi	de	AA
C6545	VCEAEA1CW106M	-	10	16V	Electrolytic		AB	R6378	VRS-CY1JF224J	J	220k	1/16W Metal Oxi	de	AA
C6546	VCEAEA1CW476M	J	47	100	Clockon	•		R6389	VRS-CY1JF562J	J	5.6k	1/16W Metal Oxi	de	AA
								R6390	VRS-CY1JF272J	J	2.7k	1/16W Metal Oxi	de	AA
	RESIS	2 T /	npe					R6391	VRS-CY1JF562J	J	5.6k	1/16W Metal Ox	ide	AA
	RESI							R6392	VRS-CY1JF272J	J	2.7k	1/16W Metal Ox	ide	AA
R6303	VRS-CY1JF101J	J	100		V Metal Oxi			R6393	VRS-CY1JF472J	J	4.7k	1/16W Metal Ox	ide	AA
R6306	VRS-CY1JF331J	_	330		V Metal Oxi		AA	R6394	VRD-RA2BE333J	J	33k	1/8W Carbon		AA
R6307	VRS-CY1JF331J	J	330		V Metal Oxi		AA	R6396	VRS-CY1JF154J	J	150	k 1/16W Metal Ox	ide	AA
R6309	VRS-CY1JF151J	J	150		V Metal Oxi		AA	R6521	VRS-CY1JF473J	J	47k	1/16W Metal Ox	ide	AA
R6311	VRD-RA2BE153J	j	15k		Carbon		AA	R6522	VRD-RA2BE333			1/8W Carbon		AA
R6312	VRS-CY1JF392J	J	3.9k	1/16\	W Metal Oxi		AA	R6523	VRS-CY1JF473J			1/16W Metal Ox	ide	AA
R6313	VRS-CY1JF123J	J	12k		W Metal Oxi		AA	R6524	VRS-CY1JF104J	-		k 1/16W Metal Ox		AA
R6314	VRD-RA2BE393J	٦	39k		Carbon		AA	R6525	VRS-CY1JF104J			k 1/16W Metal Ox		
R6315	VRS-CY1JF223J	J	22k		W Metal Ox	ide	AA		VRS-CY1JF822J		. ,	(1/16W Metal Ox		
R6317	VRD-RA2BE393J	J	39k	1/8W	Carbon		AΑ	R6526	VRS-CY1JF332J			(1/16W Metal O)		
R6318	VRS-CY1JF223J	J	22k	1/16	W Metal Ox	ide	AA	R6527	VRS-CY1JF473L) 47k			
R6320	VRS-CY1JF472J	J	4.7k	1/16	W Metal Ox	ide	AA	R6528	VRS-CY1JF101		, -, J 100			
R6321	VRS-CY1JF471J	J	470	1/16	W Metal Ox	ide	AA	R6529	VRS-CY1JF101		J 100			
R6322	VRS-CY1JF821J	j	820	1/16	W Metal Ox	ide	AA	R6530	VRS-CY1JF473		J 47k			
R6323	VRS-CY1JF473J	J	47k	1/16	W Metal Ox	ide	AA	R6531				k 1/16W Metal O		
R6324	VRS-CY1JF821J	J	820		W Metal Ox			R6532				k 1/16W Metal O:		
R6325	VRS-CY1JF473J	J	47k	1/16	W Metal Ox	kide	ĄĄ	R6533				1/16W Metal O		
R6326	VRS-CY1JF821J	j	820	1/16	W Metal Ox	cide	AA	R6537			J 75 J 270		1100	AA.
R6327	VRS-CY1JF473J	J	47k	1/16	W Metal Ox	kide	ΑĄ	R6538				1/8W Carbon		AA
R6328	VRS-CY1JF333J	J	33k	1/16	W Metal O	xide	AA	R6539	VRD-RA2BE271	J	J 2/1) (/avv Galbon		
R6329	VRS-CY1JF223J	J	22k	1/16	W Metal O	xide	AA							
R6331		J	22k	1/16	W Metal O	xide	AΑ		MISCELL	A RIE	:OUS	PARTS		
R6332			180	1/16	W Metal O	xide	AA							۸.
R6333			5.6	k 1/16	SW Metal O	xide	AA	J6301						AQ
R6337			390	1/16	SW Metal O	xide	AA	P6301						AB
R6338	3 VRD-RA2BE221J		220	1/8\	N Carbon		AA	P6302						AB
R6339			J 180	1/16	SW Metal O	xide	AA	P6303						AB
R634			5.6	k 1/16	SW Metal O	xide	AA		01 QSOCZ0531GE			cket, 5pin		AD
R6342					5W Metal O				02 QSOCZ1231GE			cket, 12pin		AC
R6340		,	J 10H	c 1/10	6W Metal O	xide	AA		03 QSOCZ1231GE			ocket, 12pin		AC
R634			J 10k	c 1/10	6W Metal C	xide	AA	SC63	04 QSOCZ0831GE	ZZ	J Sc	ocket, 8pin		AE
R634					6W Metal C	xide	AA							
R634					W Carbon		AA							
					6W Metal C		AA				•			
R634	ALE AND DEFOOL				6W Metal C									
R634					6W Metal C									
R634	0344 15000 1				6W Metal C									
R635					6W Metal C					_	:	End of Hi-Fi U	nit	
R635					6W Metal C									
R635	2 VRS-CY1JF335J		J 3.3	ו 17 ואונ	UTV IVICIAL C		, (//							

Ref. No.	Part No.	*	Description	Code	Ref. No.	Part No.	*		1	Descr	iption (Code
	DUNTK5	3:	57XM50			CON	TR	ìC	LS			
	MPX				R1961	RVR-M4809GEZZ	j		4.7k (E	3), Sui	CH Level A	Adj.AC
	IVIPA		<u> </u>		R5410	RVR-M4803GEZZ			470k (-		AC
										-		
	INTEGRATE	D	CIRCUITS									
IC1701	VHISA7283G2-1	J	SA7283G2	BM		CAPA	CI	Ţ	ORS			
IC1901	RH-iX0055GEZZ	J	IX0055GE	AG	C1701	VCKYCY1HF103Z	J	ı	0.01	50V	Ceramic	AA
IC1902	VHiTDA9840T-1	J	TDA9840T	AS	C1702	VCKYCY1HF103Z	ل	ŧ	0.01	50V	Ceramic	AA
IC5402	VHiMM1115XF1E	J	MM1115XF	AH	C1704	VCCCCY1HH391J	ل	,	390p	50V	Ceramic	AA
IC5403	VHiTL8828P/-1	J	TL8828P	AL	C1705	VCCCCY1HH100E) J	J	10p	50V	Ceramic	AA
					C1706	VCEAEA1CW106N	ΛJ	J	10	16V	Electrolytic	AB
					C1707	VCKYCY1EF104Z	J	J	0.1	25V	Ceramic	AA
	TRANS	ıs	TORS		C1708	VCEAEM1CW106			10	16V	Electrolytic	AB
				AC	C1709	VCEAEA1HW105	И.	J	1	50V	Electrolytic	AB
Q1701	VS2SC2735//1E	-	2SC2735	AD	C1710	VCEAEA1CW106N	И.	J	10	16V	Electrolytic	AB
Q1702	VS2SA950-Y/1E	-	2SA950-Y		C1713	VCKYCY1EF104Z	·	ſ	0.1	25V	Ceramic	AA
Q1703	VSDTC124EK/-1	_	DTC124EK	AB	C1716	VCEAEA1CW106	vi u	J	10	16V	Electrolytic	AB
Q1901	VS2SC2412KQ-1	-	2SC2412KQ	AA	C1717	VCEAEA1HW105	И.	j	1	50V	Electrolytic	AB
Q1902	VS2C1740SQR1E	-	2SC1740SQR	AC	C1718	VCFYSA1HB473J		J	0.047	50V	Mylar	AA
Q5401	VS2SA1037KQ-1	-	2SA1037KQ	AA	C1720	VCEAEA1CW106	vI.	J	10	16V	Electrolytic	AB
Q5402	VSDTC124EK/-1	_	DTC124EK	AB	C1721	VCKYCY1HF103Z			0.01	50V	Ceramic	AA
Q5403	VS2SA1037KQ-1	-	2SA1037KQ	AA	C1722	VCEAEM0JW476		J	47	6.3V	Electrolytic	AΒ
Q5404	VS2SA1037KQ-1		2SA1037KQ	AA	C1723	VCCCCY1HH221			220p	50V	Ceramic	AA
Q5405	VS2SC2412KQ-1	_	2SC2412KQ	AA	C1724	VCFYSA1HB104J		J	0.1	50V	Mylar	AB
Q5406	VS2SC2412KQ-1	J	2SC2412KQ	AA	C1725	VCEAEA1CW106		j	10	16V	Electrolytic	AB
					C1726	VCKYCY1EF104Z		J	0.1	25V	Ceramic	AA
	D10	_	-0		C1727	VCEAEA1HW105				50V	Electrolytic	AB
	DIC	וטי	- 5		C1728	VCKYCY1HF103Z		J	0.01	50V	Ceramic	AA
D1701	VHD1SS119//-1	J	188119	AB	C1729	VCEAEA1CW106			10	16V	Electrolytic	AB
D1720	VHDOF4076//-1	J	OF4076	AC	C1730	VCEAEA1HW334			0.33	50V	Electrolytic	AB
TH5401	RH-HZ0031GEZZ	J	Thermistor	AB	C1731	VCFYSA1HB223J			0.022		Mylar	AA
					C1732	VCCCPA1HH101			100p		Ceramic	AA
					C1732	VCCCPA1HH101		j	100p	50V	Ceramic	AA
	PACKAGE	D	CIRCUIT		C1734	VCKYCY1HF103Z			0.01	50V	Ceramic	AA
X1701	RCRSB0183GEZZ	ڶ	Crystal, 8.192MHz	AM	C1735	VCEAEA1CW106		_	10	16V	Electrolytic	AB
X1901	RCRSB0174GEZZ			AF	C1736	VCEAEA1HW474		_	0.47	50V	Electrolytic	
X5403			Crystal, 13.571MHz	AG	C1737	VCKYCY1HF1032			0.01	50V	Ceramic	AA
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,			•		C1738	VCEAEA1CW106			10	16V	Electrolytic	
					C1739	VCKYCY1EF104Z			0.1	25V	Ceramic	AA
	COILS AND TR	łΑ	NSFORMERS		C1740	VCEAEA0JW476			47		Electrolytic	
001001			Filter	AG	C1748	VCEAEM0JW476					Electrolytic	
CF1901				AB	C1748	VCEAEM1AW336				10V	Electrolytic	
L1701	VP-2K6R8K000K		6.8µH	AB	C1749	VCCCCY1HH100			10p	50V	Ceramic	AA
L1702	VP-2K6R8K000K		6.8µH 6.8µH	AB	C1906	VCCCCY1HH100			10p	50V	Ceramic	AA
L1704	VP-XF6R8K0000		6.8µH	AB	C1907	VCEAEA1CW106			10	16V	Electrolytic	
L1706	VP-2K6R8K000K			AB AB	C1908	VCEAEM0JW227				6.3V		
L1901	VP-DF101K0000		100µH	AB	C1909	VCEAEM1CW106				16V	Electrolytic	
L1902	VP-DF221K0000		220μH 	AB		VEKYCY1EB103				-25∀	•	- AA
L1903-	VP-XF-101K0000		100µH	AB	C1917	VCFYSA1HB104			0.01	50V	Mylar	AB
L5403	VP-DF680K0000		68µH 47⊔	AB	C1912	VCCCCY1HH470		J		50V	Ceramic	AA
L5406	VP-XF470J0000		47μH	AB	C1913	VCEAEM1CW106			47P	16V	Electrolytic	
L5407	VP-XF330K0000		33µH	AB		VCEAEA1CW106			10	16V	Electrolytic	
L5408	VP-DF6R8K0000		6.8μH 100πΗ	AB AB	C1915	VCEAEA1CW106			10	16V	Electrolytic	
L5409	VP-DF101K0000		100μH 10⊔	AB AB	C1916	VCEAEA1CW106			10	16V	Electrolytic	
L5412	VP-ZK100K0000		10μH	AD	C1917	VCQYTA1HM103		J	0.01	50V	Mylar	AA
T1901	RCILIO089GEZZ		Coil		C1918						-	AA
T1902	RCiLi0489CEZZ		Coil	AE	C1919	VCQYTA1HM103	J	J	0.01	50V	Mylar	

Ref. No.	Part No.	*	ļ	Descri	iption	Code	Ref. No.	Part No.	*		Description	Co	de
	CAPACITO	 3S (Conti	nuec	 l)			RESISTOF	S (0	Conti	nued)		
C1000					Ceramic	AA	R1716	VRD-RA2BE102J	J	1k	1/8W Carbon		AΑ
C1920	VCKYCY1HF103Z				Electrolytic	: AB	R1719	VRD-RA2BE102J	J	1k	1/8W Carbon		ΑA
C1921	VCEAEA1AW476			16V	Electrolytic		R1721	VRS-CY1JF152J	J	1.5k	1/16W Metal O	xide	AA
C1930	VCEAEA1CW106				Electrolytic		R1909	VRS-CY1JF562J	J	5.6k	1/16W Metal O	xide	AA
C1931	VCEAEA1CW106			50V	Ceramic	AA	R1913	VRS-CY1JF331J	J	330	1/16W Metal C	xide	AΑ
C1939	VCCSD41HL100J		10p 10p	50V	Ceramic	AA	R1914	VRS-CY1JF333J	J	33k	1/16W Metal C	xide	AΑ
C1940	VCCSD41HL100J			50V	Ceramic	AA	R1915	VRS-CY1JF332J	J	3.3k	1/16W Metal C	xide	AA
C1951	VCKYCY1HF103Z		0.01	50V	Ceramic	AA	R1916	VRS-CY1JF222J	J	2.2k	1/16W Metal C	xide	AΑ
C1952	VCKYCY1HF103Z			50V	Ceramic	AA	R1918	VRS-CY1JF331J	J	330	1/16W Metal C	xide	AΑ
C1953	VCKYCY1HF103Z			25V	Ceramic	AA	R1920	VRS-CY1JF104J	J	100	c 1/16W Metal C	xide	AΑ
C1954	VCKYCY1EB103h			50V	Ceramic	AA	R1922	VRS-CY1JF104J	J	100k	< 1/16W Metal C)xide	AΑ
C1955	VCKYCY1HF103Z			16V	Electrolytic		R1951	VRS-CY1JF561J	J	560	1/16W Metal C	xide	ΑA
C1956	VCEAEA1CW106			50V	Ceramic	AA	R1952	VRS-CY1JF681J	J	680	1/16W Metal C	xide	AΑ
C1957	VCCCCY1HH120				Ceramic	AA	R1953	VRS-CY1JF153J	J	15k	1/16W Metal C	Oxide	AΑ
C1958	VCKYCY1HB562			50V	Ceramic	AA	R1954	VRS-CY1JF392J	J	3.9k	: 1/16W Metal C	Oxide	AΑ
C5401	VCKYCY1HF103			16V	Electrolyti		R1955	VRS-CY1JF331J	J	330	1/16W Metal C	Oxide	ΑA
C5402	VCEAEM1CW106			50V	Ceramic	AA	R1956	VRS-CY1JF4R7		4.7	1/16W Metal (Oxide	AA
C5403	VCCCCY1HH180				Ceramic	AA	R1957	VRS-CY1JF151J		150	1/16W Metal (Oxide	ΑA
C5404	VCCCCY1HH101				Ceramic	AA	R1958	VRS-CY1JF152J		1.5	1/16W Metal (Oxide	A.
C5405	VCCCCY1HH331		· · '		Ceramic	AA	R1960	VRS-CY1JF182J		1.8	c 1/16W Metal (Oxide	A.
C5406	VCCCCY1HH151		•	16V	Electrolyt		R1963	VRS-CY1JF822	. ا	8.2	c 1/16W Metal (Oxide	A
C5407	VCEAEM1CW47				Electrolyt		R5401	VRS-CY1JF472		4.71	c 1/16W Metal (Oxide	A
C5408	VCEAEA1HW105			50V	Electrolyt		R5402	VRS-CY1JF332		3.3	c 1/16W Metal (Oxide	A
C5409	VCEÁEM1HW10			50V	Electrolyt		R5404	VRS-CY1JF183		J 18k	1/16W Metal (Oxide	A
C5410	VCEAEM1CW22			16V	Ceramic	AA	R5405	VRS-CY1JF183		J 18k	1/16W Metal	Oxide	A
C5411	VCKYCY1HF103			50V			R5406	VRS-CY1JF100		J 10	1/16W Metal	Oxide	A
C5412	VCEAEM1CW10			16V	Electrolyl	AA	R5407	VRS-CY1JF102		1 1k	1/16W Metal	Oxide	A
C5413	VCCCCY1HH180			50V	Ceramic	AA	R5409	VRS-CY1JF561		J 560	1/16W Metal	Oxide	A
C5414	VCCCCY1HH680			50V		AA	R5411	VRS-CY1JF102		J 1k	1/16W Metal	Oxide	A
C5415	VCCCCY1HH18		J 18p	50V			R5412		_	J 12H	1/16W Metal	Oxide	A
C5416	VCEAEMOJW10			6.3			R5413			J 331	1/16W Metal	Oxide	A
C5417	VCCCCY1HH15		•	50V			R5414			J 680			
C5418	VCEAEA1HW47				•		R5415			J 390		Oxide	Α
C5419				16V	-		R5416			J 100	1/16W Metal	Oxide	A
C5420	VCCCCY1HH12				Ceramic		R5417	14mm 0144 IE004		J 22			
C5424					Elect.(N.		R5418				k 1/16W Metal		
C5425					Electroly Coronic		R5419		-		0 1/16W Metal		
C5426					/ Ceramic		R5420			J 82	0. 1/16W Metal	Oxide	3 A
C5427					/ Ceramic		R5421				0 1/4W Carbo		Α
C5428			-		/ Ceramic		R5422				k 1/16W Metal		. A
C5429	VCFYSA1HB10	4.)	J 0.1	50\	/ Mylar	AB	R5423			J 47	0 1/16W Metal	Oxide	э A
	DE	cie	TORS	•			R5425			J 3.3	BM 1/16W Metal	Oxide) A
					SAZ N B materil (C)	vido AA				•			
R1701					W Metal O								
R1702					W Metal O W Metal O			MISCELL	ANE	EOUS	SPARTS		
R1703			J 330		sw Metal O		P1701	1 QPLGN0478GE	<u> 77</u>	J Ph	ug, 4pìn		Д
R1704			J 10		SW Metal O		SC17	01 QSOCN0809RI			ocket, 8pin		م
R1705			J 150		W Metal O		SC19	81 QSOCN2407RI	EN1		ocket, 24pin		<u> </u>
R1706			J 100		W Metal O			82 QSOCN1838T/			cket, 18pin		A
R1707			J 1k		W Metal O			83 QSOCN0786T/			ocket, 7pin		A
P1710			J 33k		W Metal O	xide AA		01 QSOCN0709R			ocket, 7pin		A
R1711			J 10k		W Metal O			01 QLUGP0101GI					,
R1712			J 22k		W Metal O			03 QLUGP0101GI					,
R1713			J 1M		W Metal O				' ' '	J 16	JOLI OII R		,
R1714					SW Metal O					:	End of MPX	Unit	
R1718	5 VH3-01101001												

Ref. No.	Part No.	*	Description	Code	Ref. No.	Part No.	*	•	Desc	ription	Code
	DUNTK	53	59XM50			PACKAG	ED	CIRC	UIT		
	LCD) U	NIT		X8930	RCRSB0168GEZZ	J	Cryst	al, 4.4	3MHz	AF
					X8931	RCRSB0216GEZZ	J	Cryst	al, 3.5	8MHz	AG
	INTEGRAT	ED	CIRCUITS								
IC8901	VHiiR3Y29AP-1	J	iR3Y29AP	ΑU							
IC9001	VHILZ95NA1M-1	J	LZ95NA1M	AP		COILS AND T	RA	NSFC	RME	ERS	
IC9002	VHiNJM2107F-1	J	NJM2107F	ΑE	L8901	VP-XF390K0000	J	39µH			AB
IC9060	VHiNJM4565V-1	J	NJM4565	AF	L8910	VP-XF680K0000	J	68µH			AB
IC9101	VHiBA15218F1E	J	BA15218F	AF	L8930	VP-2K101K000K	J	100µl	⊣		АВ
IC9102	VHiBA15218F1E	J	BA15218F	AF	L8931	VP-2K101K000K	ل	100μΙ	4		AB
IC9103	VHiPQ30RV11-1	J	PQ30RV11	AF	L9001	VP-ZK220K0000	J	22μΗ			AB
					L9002	VP-ZK1R2K0000	J	1.2µF	1		AB
					L9013	VP-XF100K0000	J	10μΗ			AB
	TRANS	SIS	TORS		L9060	VP-2K101K000K	J	100μ	4		AB
Q8901	VSDTC124EK/-1	J	DTC124EK	AB	L9101	VP-2K470K000K	J	47μΗ			AB
Q8905	VSDTC144EK/-1		DTC144EK	AB	L9102	VP-2K100K000K	J	10μH			AB
Q8912	VSDTC144EK/-1	J	DTC144EK	AB	L9104	VP-2K470K000K	J	47μΗ			AB
Q8913	VSDTA144EK/-1	J	DTA144EK	AC						•	
Q8920	VSDTC144EK/-1	J	DTC144EK	AB							
Q8930	VSDTA124EK/-1	J	DTA124EK	AB		CON	TR	OLS			
Q8931	VS2SC2412KQ-1	J		AA	R8902	RVR-M4339GEZZ	J	33k (l	٦)		AB
Q8932	VS2SC2412KQ-1	j		AA	R8961	RVR-M4343GEZZ		100k	•		AB
Q8980	VS2SC2412KQ-1	J		AA	R8966	RVR-M4343GEZZ		100k			AB
Q8985	VS2SA1037KQ-1	J		AA	R9021	RVR-M4343GEZZ		100k			AB
Q9001	VSDTC144EK/-1	.1	DTC144EK	AB	R9061	RVR-M4346GEZZ			(0)		AB
Q9061	V\$2\$A1037KQ-1	J		AA	N9001	n v n-ivi4340GEZZ	J	ZZUK			AD
Q9062	VS2SC2412KQ-1	J		AA							
Q9101	VSDTC114EK/-1	J		AB		CAPA	CI.	TARS			
Q9101	VSDTC114EK/-1	J		AB							
Q9102	VS2SA1015Y/1E	J		AC	C8901	VCCCCY1HH330J		•	50V	Ceramic	AA
Q9103	VSDTA114EK/-1	ı	DTA114EK	AB	C8902	VCCCCY1HH180J		•	50V	Ceramic	AA
Q9105	VS2SC1815YW-1	ı	TRANSISTOR	AC	C8903	VCKYCY1HF103Z			50V	Ceramic	AA
Q9105	V\$2\$A988///1E	1	TRANSISTOR	AB	C8904	VCEAEA1CW106N		10	16V	Electrolytic	AB
Q9107	VSDTC144EK/-1	ı	DTC144EK	AB	C8905	VCCCCY1HH151J		150p	50V	Ceramic	AA
		J			C8906	VCKYCY1HB681K	J	680p	50V	Ceramic	AA
Q9108	VS2SC1815YW-1	J		AC	C8908	VCKYCY1HF103Z			50V	Ceramic	AA
Q9109	VS2C1740SQR1E	J		AC	C8910	VCKYCY1HF103Z	J	0.01	50V		AA
Q9113	VSDTC124EK/-1	J		AB	C8911	RTO-H1071GEZZ	J	50p		Trimmer	AD
	VS2SC1815YW-1 VSDTC124EK/-1	J		AC	C8913	VCKYCY1HF103Z	J	0.01	50V	Ceramic	AA
Q9115	VS2SC2412KQ-1	J	DTC124EK 2SC2412KQ	AB	C8914	VCKYCY1HF103Z			50V	Ceramic	AA
Q9116	V52502412NQ-1	J	2502412NQ	AA	C8915	VCKYCY1HF103Z	J	0.01	50V	Ceramic	AA
					C8916	VCCCCY1HH390J	J	39p	50V	Ceramic	AA
	DIC	\ D.	=0		C8917	VCFYSA1HB334J	J	0.33	50V	Mylar	AB
	אוע	וטו	- 5		C8920	VCKYCY1HF103Z	J	0.01	50V	Ceramic	AA
D8909	VHD1SS119//-1	J	1SS119	AB	C8925	VCEAEA1HW474N	ΛJ	0.47	50V	Electrolytic	AB
D8930	VHD1\$\$119//-1	J	188119	AB	C8926	VCKYCY1HF103Z	J	0.01	50V	Ceramic	AA
D9001	VHDHVU17TRF-1	J	HVU17TRF	ΑE	C8930	VCKYCY1HF103Z	J	0.01	50V	Ceramic	AA
D9045	RH-EX0630GEZZ	J	Zener Diode	AA	C8931	VCCCCY1HH8R0I	D J	8p	50V	Ceramic	AA
D9101	RH-EX0644GEZZ		Zener Diode	AB	C8933-	-VGKYGY1HF103Z	 J-	-0:01-	- 5 0∀-	Ceramic	AA
D9102	RH-EX0617GEZZ	J	Zener Diode	AA	C8934	VCKYCY1HF103Z	J	0.01	50V	Ceramic	AA
D9103	RH-EX0626GEZZ	J	Zener Diode	AA	C8936	VCCCCY1HH6R0) J	6p	50V	Ceramic	AA
D9104	RH-EX0648GEZZ	J	Zener Diode	AE	C8940	VCKYCY1AF105Z	J	1	10V	Ceramic	AC
D9105	RH-EX0627GEZZ	ل	Zener Diode	AA	C8941	VCKYCY1AF105Z	J	1	10V	Ceramic	AC
	VHD1SS119//-1	.1	188119	AB	C8942	VCKYCY1HF103Z	J	0.01		Ceramic	AA
D9107	4UD19911991-1	•								00,01110	
D9107	VHD165119//-1	Ū			C8943	VCKYCY1AF105Z		1			AC

Ref. No.	Part No.	*		Descri	ption (Code	Ref. No.	Part No.	*		Description	on C	ode
	CAPASITOF	S (Conti	nued)			CAPACITOR	S (Cont	inued)		
C8947	VCKYCY1HF103Z				Ceramic	AA	C9122	VCKYCY1EF104Z	J	0.1	25V Cera	amic	AA
C8950	VCKYCY1HF103Z	J	0.01	50V I	Ceramic	AA		RC-EZ0458GEZZ	J	680	10V Elec	torolytic	AD
C8955	VCKYCY1HF103Z	J	0.01	50V	Ceramic	AA	C9126	VCKYCY1EB103K	J	0.01	25V Cera	amic	AA
C8960	VCKYCY1HF103Z	J	0.01	50V	Ceramic	AA							
C8962	VCKYCY1HB561K		560p	50V	Ceramic	AA							
C8963	VCKYCY1EF104Z		0.1	25V	Ceramic	AA		RESI	STO	DRS			
C8965	VCKYCY1HF103Z		0.01	50V	Ceramic	AA	R8901	VRS-CY1JF103J	J	10k	1/16W Met	al Oxide	AA
C8970	VCKYCY1CF104Z	j	0.1		Ceramic	AA	R8903	VRS-CY1JF153J	J	15k	1/16W Met	al Oxide	AA
C8974	VCKYCY1HB391K	J	390p		Ceramic	AA	R8904	VRS-CY1JF335J	J	3.3M	1/16W Met		AA
C8977	VCEAEA1CW106N	ΛJ	10		Electrolytic		R8905	VRS-CY1JF563J	J	56k	1/16W Met		
C8980	VCEAEA1CW106	ΛJ	10		Electrolytic		R8906	VRS-CY1JF273J	J	27k	1/16W Met		AA
C8990	VCKYD41CY103N	J	0.01		Ceramic	AA	R8907	VRS-CY1JF151J	J	150	1/16W Met		AA
C8992	VCKYCY1AF105Z		1		Ceramic	AC	R8908	VRS-CY1JF393J	J	39k	1/16W Met	al Oxide	AA
C8993	VCCCCY1HH560	IJ	56p		Ceramic	AA	R8909	VRS-CY1JF104J	J	,	1/16W Met		
C8994	VCEAEA1HW335I	ΙN	3.3		Electrolytic		R8910	VRS-CY1JF154J	J		1/16W Met		AA
C8996	VCKYCY1HF103Z		0.01		Ceramic	AA	R8913	VRD-RA2BE564J	J	560k	1/8W Car		AA
C8998	VCEAEA1AW107	ΝJ	100		Electrolytic		R8915	VRS-CY1JF223J	J	22k	1/16W Met	tal Oxide	AA
C9001	VCKYCY1HB102k	J	1000p		Ceramic	AA	R8917	VRS-CY1JF105J	J	1M1	1/16W Me	tal Oxide	AA
C9002	VCCCCY1HH470		47p	50V	Ceramic	AA	R8918	VRS-CY1JF562J	J	5.6k	1/16W Me	tal Oxide	AA
C9005	VCKYCY1EF104Z	J	0.1	25V	Ceramic	AA	R8920	VRS-CY1JF473J	J	47k	1/16W Me	tal Oxide	AA
C9006	VCKYCY1AF105Z	J	1	10V	Ceramic	AC	R8921	VRS-CY1JF473J	J	47k	1/16W Me	tal Oxide	AA.
C9010	VCEAEA1HW105			50V	Electrolytic		R8922	VRS-CY1JF333J	J	33k	1/16W Me	tal Oxide	AA :
C9011	VCCCCY1HH101	J	•	50V	Ceramic	AA	R8923	VRS-CY1JF223J	Ţ	22k	1/16W Me	tal Oxide	AA
C9013	VCCSD41HL560J	J	,	50V	Ceramic	AA	R8925	VRS-CY1JF822J	J	8.2k	1/16W Me	tal Oxide	AA
C9014	VCCSD41HL220J	J	,	50V	Ceramic	AA	R8926	VRS-CY1JF562J	J	5.6k	1/16W Me	tal Oxide	AA e
C9015	VCKYD41HB102k	J	1000		Ceramic	AA	R8927	VRS-CY1JF273J	J	27k	1/16W Me	ital Oxide	AA e
C9045	VCE9EA1HW105			50V	Elect.(N.P	•	R8930	VRD-RA2BE103J	J	10k			AA
C9046	VCEAEA1HW475			50V	Electrolytic		R8931	VRS-CY1JF822J	J	8.2k			
C9050	VCKYCY1EF104Z			25V	Ceramic	AA	R8932	VRS-CY1JF153J	J				
C9052	VCKYCY1EF104Z			25V	Ceramic	AA	R8933	VRS-CY1JF152J	J	1.5k	: 1/16W Me		
C9060	VCCCCY1HH8R0		•	50V	Ceramic	AA	R8934	VRS-CY1JF153J	J				
C9062	VCKYCY1HF103Z			50V	Ceramic	AA	R8935	VRS-CY1JF822J	J		1/16W Me		
C9063	VCEAEM1AW107			10V	Electrolytic		R8936	VRS-CY1JF681J	Ļ				
C9064	VCKYCY1EF104Z			25V	Ceramic	AA	R8937	VRD-RA2BE222J	J		c 1/8W Ca		AA
C9065	VCKYCY1EF1042			25V	Ceramic	AA	R8945	VRS-CY1JF393J	J	39k			
C9101	VCEAEA1EW476			25V	Electrolyti		R8946	VRS-CY1JF393J	J				
C9102	VCEAEA1AW107			10V	Electrolyti		R8947	VRS-CY1JF153J	U				
C9103	VCKYCY1HF103			50V	Ceramic	AA - AO	R8948	VRS-CY1JF473J	J				
C9104	VCEAEA1CW107			16V	Electrolyti		R8950	VRS-CY1JF333J					
C9105	VCKYCY1EF1042			25V	Ceramic	AA	R8951	VRS-CY1JF473J		1 47k			
C9106	VCEAEA1CW107			16V	Electrolyti		R8955			J 47k			
C9107	VCEAEA1CW476			16V	Electrolyti		R8956			27k			
C9108	VCKYCY1HF103			50V	Ceramic	AA	R8957			68k			
C9109	VCEAEA1CW226			16V	Electrolyti		R8958	15070 1		J 33k			
C9110	VCEAEA1CW226			16V	Electrolyti		R8960			J 27k			
C9111	VCEAEA1EW476			25V	Electrolyti		R8962) 39k			
C9113	VCKYCY1HF103		J 0.01	50V	Ceramic	AA AA	R8965) 27k			
C9114	VCKYCY1HF103		J 0.01	50V	Ceramic Electrolyti		R8967			J 39k			
C9115	VCEAEA1CW476			16V	Electrolyti		R8970			J 1k	1/16W M		
C9116	VCEAEA1EW476			25V 25V	Electrolyti		R8974			J 560			
C9117	VCEAEA1EW476			50V	Electrolyti		R8975				k 1/16W M		
C9118	VCEAEA1HW334			16V	Electrolyti		R8976			J 10k			
C9119	VCEAEA1CW476			16V	Electrolyt		R8977			J 10k			
C9120	VCEAEA0JW476				Electrolyti		R8978			J 1k	1/16W M		
C9121	- VOLALAGOV4470	144 1					R8979	VRS-CY1JF102J		J 1k	1/16W M	etai Oxid	e AA

Ref. No.	Part No.	*	Description	on Co	de	Ref. No.	Part No.	*	١	Description	n Cod	ie ——
	RESISTOR		Continued)				RESISTORS	(C	ontir	nued)		
				tal Ovide	AA	R9118	VRS-CY1JF824J	J 8	320k 1	1/16W Meta	l Oxide	A A
R8981	VRS-CY1JF333J		33k 1/16W Me 10k 1/16W Me		AA	R9119	VRS-CY1JF824J	-		1/16W Meta		ĄΑ
R8982	VRS-CY1JF103J		1M 1/16W Me		AA	R9120	VRD-RA2BE124J			1/8W Carb		λA
R8985	VRS-CY1JF105J				AA	R9121	VRS-CY1JF224J	J	220k 1	1/16W Meta	l Oxide	ĄΑ
R89 9 1	VRS-CY1JF183J	J			AA	R9122	VRS-CY1JF824J	_		1/16W Meta		٩A
R8992	VRS-CY1JF272J	J			AA		VRS-CY1JF392J	j	3.9k	1/16W Meta	d Oxide	٩A
R8994	VRS-CY1JF334J	J			AA		VRS-CY1JF681J	J	680	1/16W Meta	d Oxide	AA
R8995	VRD-RA2BE334J	J			AA		VRS-CY1JF104J	J	100k	1/16W Meta	al Oxide	AA
R8996	VRS-CY1JF393J	J			AA	,	VRS-CY1JF473J	J	47k	1/16W Meta	al Oxide	AA
R8997	VRS-CY1JF393J	J			AA	R9129	VRS-CY1JF152J	J	1.5k	1/16W Meta	al Oxide	AΑ
R9001	VRS-CY1JF331J	J ,			AA	R9130	VRD-RA2HD680J	J	68	1/2W Carb	oon	AA
R9002	VRS-CY1JF331J	J		etal Oxide	AA	R9131	VRD-RA2BE180J	J	18	1/8W Cart	oon	AA
R9003	VRS-CY1JF561J				AA	R9132	VRD-RA2HD560J	J	56	1/2W Cart	oon	AA
R9004	VRS-CY1JF561J	-		etal Oxide		R9133	VRS-CY1JF333J	J	33k	1/16W Met	al Oxide	AA
R9005	VRS-CY1JF123J	_		etal Oxide	AA	R9135	VRS-CY1JF272J	J	2.7k	1/16W Met	al Oxide	AΑ
R9006	VRS-CY1JF561J			etal Oxide	AA	R9136	VRS-CY1JF104J	J	100k	1/16W Met	al Oxide	AA
R9007	VRD-RA2BE471J		470 1/8W Ca		AA	R9137	VRD-RA2BE472J	J	4.7k	1/8W Carl	bon	AA
R9008	VRD-RA2BE561J		560 1/8W Ca		AA	R9138	VRS-CY1JF471J	J	470	1/16W Met		AA
R9009	VRS-CY1JF105J			etal Oxide	AA	113 100	V/10 01 101 11 1=					
R9010	VRS-CY1JF471J			etal Oxide	AA							
R9011	VRS-CY1JF103J	•		ietal Oxide	AA		MISCELLA	VEC	us I	PARTS		
R9012	VRS-CY1JF470J			letal Oxide	AA							AC
R9013	VRD-RA2BE564.) .	J 560k 1/8W C		AA	P9101	QPLGN1178GEZZ		-	, 11pin		AD
R9014	VRD-RA2BE564) ,	j 560k 1/8W C		AA		QSOCN1894REZZ			et, 18pin		AA
R9016	VRS-CY1JF104J	,	J 100k 1/16W M			TP8940	QPLGN0447REZZ	J	Plug	, 4pm		7.7
R9018	VRS-CY1JF102J			letal Oxide								
H9030	VRS-CY1JF105J		•	1etal Oxide								
R9031	VRS-CY1JF683J		=	letal Oxide								
R9032	VRS-CY1JF472J	l		/letal Oxide								
R9033	VRS-CY1JF223J)		/letal Oxide					_ =	nd of LC	D Unit	
R9034	VRS-CY1JF683.	j		/letal Oxide						ila oi Lo	D 01.110	
R9035	VRS-CY1JF473.	j		⁄ietal Oxide						/ IOD		
R9036	VRS-CY1JF472	J	J 4.7k 1/16W N				DUNTK	(53	692	(J6B		
R9045	VRS-CY1JF153.	j		vletal Oxide			REL	ĀΥ	UN	IT		
R9046		J	J 120k 1/16W N	vietal Oxide	e AA							
R9050			J 100 1/8W 0	Carbon	AA		CAP	AC	ITOR	S		
R9051		J	J 100 1/8W 0	Carbon	AA	C2801	VCKYCY1EF104	z.	J 0.1	25V C	eramic	AA
R9052			J 100 1/8W 0	Carbon	AA	C2802			J 0.1	25V C	eramic	AA
R9060			J 15k 1/16W	Metal Oxid	e AA	C2803			J 0.1	25V C	eramic	AA
R9062			J 180k 1/16W1	Metal Oxid	e AA	C2804			J 0.1	25V C	eramic	AA
R9063			J 560k 1/16W	Metal Oxid	e AA	C2805			J 0.1	25V C	eramic	AA
R9069	·		J 10k 1/16W	Metal Oxid	e AA	C2806				1 25V C	eramic	AA
R910			J 2.7k 1/16W	Metal Oxid	e AA	02800	, ,0,0,1,0,1,0,1,0					
R910				Carbon	AA							
R910				Metal Oxid	le AA		RE	SIS	TOR	s		
H910			*	Metal Oxid							letal Oxide	ΔΔ
R910			J 3.3k 1/4W		AA	R280			J 22	k 1/16W N		
			J 3.3k 1/4W		AA	R280					netal Oxide	
R910				Metal Oxio	de AA	R280			J 22		netal Oxide Netal Oxide	
A910				Metal Oxio		R280			J 18			
R910				Metal Oxid		R280				Ik 1/16W N		
R911				Carbon	AA	R280			J 10		ietal Oxid	
R911				Metal Oxid		R280	7 VRS-CY1JF561	J	J 56	0 1/16W N	/letal Oxid	e AA
R911			J 12k 1/16W J 390k 1/16W									
R911			J 1.5k 1/16W						=	nd of Re	lav Unit	
R911			J 1.5k 1/16W J 27k 1/16W							na vi ne	ay Oint	
R911	7 VRS-CY1JF27	33	J 2/K 1/164V	Wieldi Oxii								

Ref. No.	Part No.	*	Description	Code	Ref. No.	Part No.	*	Description Co	de
			ASSIS PARTS	 S	47	NPLYV0155GEZZ		Motor Pulley	AR
ME	CHANISM C	JH.	ASSIS PARTS	_	48	NPLYV0156GEZZ	J	Limitter Pulley Ass'y	AU
					49	NROLP0110GEZZ	. J	Guide Roller	AH
1	LBNDK1009GEZZ	J	Tension Band Ass'y	AT	50	NSFTP0034GEZZ	J	Tension Pole Adjust Cam	AA
2	LBO\$Z1001GEZZ		Tension Arm Boss	AC	51	PGUMM0043GEZ	ΖJ	Damper Rubber	AB
3	LBOSZ1002GEZZ		Slow Brake Boss	AR	52	PREFL1007GEZZ	J	Light Guide	AR
4	LBOSZ1003GEZZ		Cassette Stay L	AR	53	QCNW-7860GEZZ	Z J	FFC For Drum Motor	ΑĒ
5	LCHSM0158GEZZ		Main Chassis Ass'y	AY	54	QCNW-7501GEZ	. J	Lead Wire For Loading	AD
6	LHLDZ1958GEZZ		Loading Motor Block	AR				Motor	
7	LPOLM0056GEZZ		Supply Pole Base Ass		55	QCNW-7769GEZ	Z J	FFC For Audio/Control	AF
8	LPOLM0057GEZZ		Take-Up Pole Ass'y	AM				Head	
9	MLEVF0459GEZZ		Take-Up Loading Arm	AS	56	QPWBF5243GEZ	Z J	Audio/Control Head PWE	3 AE
			Ass'y		57	QSOCN0685REZ		"Socket, 6 pin"	AB
10	MLEVF0461GEZZ	<u>.</u> J	Supply Loading Arm	AS	58	RHEDT0031GEZ		Fuil Erase Head	AΗ
			Ass'y		59	RHEDU0085GEZ			/ BA
11	MLEVF0463GEZZ	<u> </u>			60	RMOTM1062GEZ		Loading Motor	AP
12	MLEVF0464GEZZ		Pinch Roller Lever As	s'y AW	61	RMOTN2053GEZ			BF
15	MLEVF0467GEZZ		Tension Arm Ass'y	AS	62	RMOTP1129GEZ		•	BF
16	MLEVF0468GEF		Audio/Control Head A	Arm AS	63	DDRMW0016HE		•	вν
17	MLEVP0271GEZ		Sifter Drive Lever	AS		DB, ((V)) (00 (0) (1	- / -	Ass'y	
18	MLEVP0272GEZ		Pinch Double Action	AS	64	MSPRC0194GEI	=J _		AA r
10	WELLT SEVERE		Lever		65	QBRSK0034GEZ			AD
19	MLEVP0273GEZ	z J	Reverse Guide Lever	· AT	66	XBPSD26P05J0		Drum Drive Motor	AA
13	14122 %1 OZ. GZ.		Ass'v		00	ADI ODZOI OOGO	•	Mounting Screw	
20	MLEVP0275GEZ	z J		AB				(SW2.6P+5S)	
20	MLEVP0276GEZ			AS		PGIDC0055GEF	1A7	J Drum Base	AL
21	MLEVP0277GEZ			AS	67	PGIDCUUSSGEF	** ') Djulli Dase	
22 23	MLEVP0278GEZ			AS					
23 24	MLEVP0279GEZ			ss'y AS					
2 4 25	MLEVP0280GEZ								
25 26	CLEVP0287GEZ		J Auto Head Cleaner					•	
	MSLiP0008GEZ		J Sifter	AS					
27	MSPRC0205GE	-	J Audio/Control Head	AR					
28	VIS# 1100203GE		Spring						
00	MSPRD0165GE	E.I	J Reverse Guide Sprir	ng AR					
29	MSPRT0402GE	F.1	J Loading Double Acti						
30	MOEUL		Spring						
	MSPRT0403GE	- I	J Pinch Double Action	a AR					
31	MSPHIU403GL	1 0	Spring						
	MSPRT0405GE	= 1	J Tension Spring	AR					
33	NBLTK0066AJ0		J Drive Belt	AE					
34	NDAIV1070GE0		J Reel Disk	AS					
35	NGERH1267GE								
36	NGERH1268GE			AS					
37				rive AS					
38	NGERH1269GE	-22	Gear						
				ear AF					
39	NGERH1270GE			·· -					
40	NGERH1271GE		^	AS					
41	NGERH1272GI		ی امام ا است.	Gear AS					
42	NGERH1275GI		Date	y Gear AS					
43	NGERH1276GI	544 577	 .	AS					•
44	NGERW1062G NGERW1063G	にんん		AS					
45	NGERW 1063G NIDR-0015GEZ	7Z	J Idler Wheel Ass'y						
46	MIDH-00 ISOTE	_	•						_
_						—— End of N	ieci	nanism Chassis Parts	· —

312

313

314

315

316

317

NGERH1278GEZZ J

NGERH1279GEZZ J

NGERR1008GE00 J

NGERR3005GEFW J

NSFTD0041GEFD J

Code Description Part No. Ref. No. Code Description Part No. Ref. No. SCREWS, NUTS AND WASHERS CASSETTE HOUSING CONTROL PARTS J Set Screw AC LX-XZ3030GEFD 200 ΑŻ J Cassette Housing CHLDX3074GE02 300 AD J Tilt Adjusting Screw LX-BZ3176GEZZ 201 Control Ass'y Audio/Control Head ScrewAD LX-HZ3082GEZZ 202 ΑT Upper Plate LANGF9592GEFW J 301 Screw, C2.6P+6S (For XHPSD26P06000 203 AS LHLDX1028GE00 Frame (L) 302 Capstan Motor) AS Frame (R) LHLDX1029GE00 303 Screw, SW2.6P+5S (For XBPSD30P05J00 204 AR Holder (L) LHLDX1030GEZZ 304 Loading Motor) AR Holder (R) LHLDX1031GEZZ 305 Screw, C2.6P+6S (For AA XHPSD26P06WS0 J 205 AS Proof Lever (R) J MLEVF0469GEFW 306 Loading Motor Block) AS Door Open Lever MLEVP0281GE00 307 AΑ Screw, C2.6P+8S XHPSD26P08WS0 206 AΤ Slider J MSLiF0073GEFW 308 (For F/E Head) AB Proof Lever (R) Spring MSPRD0151GEFJ J 309 Screw, C3.0P+8S AA XHPSD30P08WS0 207 Drive Gear (R) Spring AR MSPRD0166GEFJ J 310 (For Drum Base) ΑD Cassette Spring MSPRP0159GEFJ 311 AΑ E-Ring, E-4 ΑВ Double Action Spring MSPRT0381GEFJ

AS

A\$

AS

AF


Drive Gear (L)

Drive Gear (R)

Main Shaft

Drive Angle Gear


Double Action Rack Gear AS




End of Cassette Housing Control Parts


End of Screws, Nuts And Washers -

Ref. No.	Part No.	k	Description	Code	Ref. No.	Part No.	*	Description	Code
	MECHANIC	AL	PARTS	-	518 519	JKNBK1097GESA JKNBK1098GESA		Dial Volume Knob	AE AD
 600	GCABA3109GESF	J To	p Cabinet	AU					
		J Bo	ttom Plate	AK					
	GCABB1175GEZZ	.I Ma	ain Frame	ΑT					
	GCOVA2019GEZZ	J An	ntenna Terminal Cove	er AD					
	LANGK0165GEFW	J To	p Cabinet Angle	AC					
607	LANGK0171GEFW	J To	op Cabinet Angle (R)	ΑE		Fn	id of	f Front Panel Part	ts
609	LHLDZ1972GEZZ	J Ma	ain PWB Holder	AE			iu o		
610	LHLDZ1988GEZZ	j Fr	ame Holder	AG		<u> </u>			
611	LX-HZ3047GEFF		crew	AA		LCD UI	TIV	PARTS	
612	LHLDZ1990GEZZ		i-Fi PWB Holder	AG		202 0.			
616	PSPAZ0535GEZZ	J To	op Cabinet Spacer	AD					AM
618	LHLDP1089GE00	JTI	MER/REC LED Hold		520	CCOVA1997GE0		LCD Cover Ass'y	AB
623	LX-HZ3040GEFF	J S	crew	AA	520-2	QEARP0422GEZ		LCD Earth	AE
624	XEBSD30P12000	JS	crew	AA	521	CHLDZ1982GE0		PWB Holder Ass'y	AF
625	XHPSD30P06WS0	JS	crew	AA	521-1	LHLDZ1982GEZ		PWB Holder	
626	XHPSD30P08WS0		Screw	AA	521-2	QEARP0423GEZ			AA
627	XEBSD40P12000		Screw	AA	522	GCOVA1996GE			AD
628	XESSF30P12000	JS	Screw	AA	523	LHLDZ1981GEZ		J LCD Holder	AK
629	LHLDF1092GEZZ	J F	WB Holder	AD	525	CLMPV0019TAC		J Lamp Unit	BA
630	PSLDM4525GEFV	v J S	Shield Case	AF	526	PMIR-0018TAZZ		J Mirror	ΑĽ
631	QCNW-7857GEZZ		Earth Cord	AC	527	PGIDM0023TAZ	z,	J Light Guide	A
100	G01414-1001 CZ				528	PSHEP0025TAZ	ZZ ·	J Sheet	AF
					530	RLCDV0002GE	ZZ ·	J Display	B
	En	nd of	Mechanical Part	ts ——	531	XEBSD30P1400	00	J SCREW	A
					532	XEPSD20P0600	00	J SCREW	A
					533	XEPSF30P0800		J SCREW	A.
	FRONT PA	ANE	L PARTS		534	XEPSF30P1000		J SCREW	A
	,				536	CANGF9605GE		J LCD Unit Angle	A
				ΑZ	538	QCNW-7848GE		J FFC Cable	A
			E+ Donal Acciu			GO 1444-1 0-10 0-1			
500	CPNLC2192GE0		Front Panel Ass'y		550	QOIVV-10-00			
500 501	CBTN-2765GE01	J	Power Button Ass'y	AG	550	Q0 444-70-40 s.r.			
	CBTN-2765GE01 GCOVA1992GEZ	J ZZ J	Power Button Ass'y Power LED Cover	AG AD	330	QOIVVV-70400X			
501	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0	J ZZ J 11 J	Power Button Ass'y Power LED Cover Door Ass'y	AG AD AV	550			nd of LCD Unit Pa	arts —
501 501-2	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GE5	J ZZ J M J SB J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover	AG AD AV AM	330	QOIVV -70-05.		nd of LCD Unit Pa	arts —
501 501-2 502	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GES HBDGD1003GES	J ZZ J D1 J SB J SA J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge	AG AD AV AM AH			– E		
501 501-2 502 502-1	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GES HBDGD1003GES LANGF9484GE0	J ZZ J 31 J SB J SA J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle	AG AD AV AM AH AC			– E	nd of LCD Unit Pa	
501 501-2 502 502-1 502-3	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GES HBDGD1003GES LANGF9484GE0 PSPAG0019GEZ	J ZZ J 31 J SB J SA J 40 J ZZ J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer	AG AD AV AM AH AC AA			– E		
501 501-2 502 502-1 502-3 502-4	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GE5 HBDGD1003GE5 LANGF9484GE0 PSPAG0019GEZ XESSF20P06000	J ZZ J SB J SA J SO J ZZ J O J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw	AG AV AM AH AC AA		SUPPLIE	– E	CCESSORIES	
501 501-2 502 502-1 502-3 502-4 502-5	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GE5 HBDGD1003GE5 LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GE	ZZ J SSB J SSA J SO J ZZ J O J ZZ J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration	AG AD AV AM AH AC AA AA		SUPPLIED	- E	CCESSORIES	3
501 501-2 502 502-1 502-3 502-4 502-5	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GES HBDGD1003GES LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GEZ GCOVA1994GE	ZZ J SB J SB J SC J ZZ J ZZ J ZZ J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration	AG AD AV AM AH AC AA AA AA		SUPPLIE	- E	CCESSORIES SORIES J 750hm Coaxial Ca	Sable /
501 501-2 502 502-1 502-3 502-4 502-5 502-6	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GE5 HBDGD1003GE5 LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GE3 GCOVA1994GE3 HDECQ1576GE	ZZ J SB J SB J SO J ZZ J ZZ J ZZ J SA J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration R/C Cover Cassette Flap	AG AD AV AM AH AC AA AA AA AE AH		SUPPLIED AC QCNW-2702G QCNW-7581G	- E CCES EZZ	CCESSORIES SORIES J 750hm Coaxial Ca J AV Cable	able /
501 501-2 502 502-1 502-3 502-4 502-5 502-6 503 504	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GE5 HBDGD1003GE5 LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GE3 GCOVA1994GE3 HDECQ1576GE	ZZ J SB J SA J ZZ J ZZ J ZZ J SA J SA J SA J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration R/C Cover Cassette Flap Foot Dec.(R)	AG AD AV AM AH AC AA AA AE AH AD		SUPPLIED AC QCNW-2702G QCNW-7581G	- E CCES EZZ	CCESSORIES SORIES J 750hm Coaxial Ca	able /
501 501-2 502 502-1 502-3 502-4 502-5 502-6 503 504 505	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GES HBDGD1003GES LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GEZ GCOVA1994GEZ HDECQ1576GEZ HDECQ1507GEZ	ZZ J SB J SA J ZZ J ZZ J ZZ J SA J SA J SA J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration R/C Cover Cassette Flap Foot Dec.(R) Foot Dec.(L)	AG AV AM AH AC AA AA AA AE AH AD		SUPPLIED AC QCNW-2702G QCNW-7581G	- E CCES EZZ	CCESSORIES SORIES J 750hm Coaxial Ca J AV Cable J Infrared Remote C	able /
501 501-2 502 502-1 502-3 502-4 502-5 502-6 503 504 505	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GE5 HBDGD1003GE5 LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GE3 HDECQ1576GE HDECQ1507GE HDECQ1508GE JBTN-2766GES	ZZ J SBB J SA J ZZ J ZZ J ZZ J SA J SA J SA J A J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration R/C Cover Cassette Flap Foot Dec.(R) Foot Dec.(L) CH Button	AG AD AV AM AH AC AA AA AA AB AD AD		SUPPLIED AC QCNW-2702G QCNW-7581G	OCE:	CCESSORIES SORIES J 750hm Coaxial Ca J AV Cable J Infrared Remote C Unit J Battery Cover, Infr	able /
501 501-2 502 502-1 502-3 502-4 502-5 502-6 503 504 505 506 507	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GES HBDGD1003GES LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GEZ GCOVA1994GEZ HDECQ1576GEZ HDECQ1507GEZ HDECQ1508GEZ JBTN-2766GES	ZZ J SB J SA J ZZ J ZZ J SA J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration R/C Cover Cassette Flap Foot Dec.(R) Foot Dec.(L) CH Button	AG AD AV AM AH AC AA AA AA AE AH AD AD AE		SUPPLIED AC QCNW-2702G QCNW-7581G RRMCG0162A	OCE:	CCESSORIES SORIES J 750hm Coaxial Ca J AV Cable J Infrared Remote C	able /
501 501-2 502 502-1 502-3 502-4 502-5 502-6 503 504 505 506 507 509 510	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GE5 HBDGD1003GE5 LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GE3 HDECQ1576GE HDECQ1507GE HDECQ1508GE JBTN-2766GES	ZZ J SB J SA J ZZ J ZZ J SA J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration R/C Cover Cassette Flap Foot Dec.(R) Foot Dec.(L) CH Button Rec Button	AG AD AV AM AH AC AA AA AE AH AD AD AE AD		SUPPLIED AC QCNW-2702G QCNW-7581G RRMCG0162A	OCE:	CCESSORIES SORIES J 750hm Coaxial Ca J AV Cable J Infrared Remote C Unit J Battery Cover, Infr	able /
501 501-2 502 502-1 502-3 502-4 502-5 503 504 505 506 507 509 510	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GES HBDGD1003GES LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GEZ GCOVA1994GEZ HDECQ1576GEZ HDECQ1507GEZ HDECQ1508GEZ JBTN-2766GES	ZZ J SSB J SSA J ZZ J ZZ J SSA	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration R/C Cover Cassette Flap Foot Dec.(R) Foot Dec.(L) CH Button Rec Button Magnet	AG AD AV AM AH AC AA AA AE AH AD AE AD AE AD AB		SUPPLIED AC QCNW-2702G QCNW-7581G RRMCG0162A 93GHR19472	- E CCE: EEZZ AJSA 001	CCESSORIES SORIES J 750hm Coaxial Ca J AV Cable J Infrared Remote C Unit J Battery Cover, Infr	Sable // Control // rared
501 501-2 502-1 502-3 502-4 502-5 502-6 503 504 505 506 507 509 510 511	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GES HBDGD1003GES LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GEZ GCOVA1994GEZ HDECQ1507GEZ HDECQ1507GEZ HDECQ1507GEZ JBTN-2766GES JBTN-2766GES LHLDZ3041GEZ	ZZ J J SSA J J J SSA J SSA J SSA J SSA J J SSA	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration R/C Cover Cassette Flap Foot Dec.(R) Foot Dec.(L) CH Button Rec Button Magnet Cassette Spring	AG AD AV AM AH AC AA AA AE AH AD AD AE AD		SUPPLIED AC QCNW-2702G QCNW-7581G RRMCG0162A 93GHR19472	- E CCE: EEZZ AJSA 001	CCESSORIES SORIES J 750hm Coaxial Ca J AV Cable J Infrared Remote C Unit J Battery Cover, Infr	Sable // Control // rared
501 501-2 502-1 502-3 502-4 502-5 502-6 503 504 505 506 507 509 510 511 512 513	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GE5 HBDGD1003GE5 LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GE5 GCOVA1994GE5 HDECQ1507GE6 HDECQ1507GE6 HDECQ1507GE5 JBTN-2766GES JBTN-2767GES LHLDZ3041GEZ MSPRD0103GE6 MSPRP0179GE5	ZZ J J J SSA J J J J SSA J J J J SSA J J J J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration R/C Cover Cassette Flap Foot Dec.(R) Foot Dec.(L) CH Button Rec Button Magnet Cassette Spring Door Spring	AG AD AV AM AH AC AA AA AE AH AD AE AD AE AD AB	Α	SUPPLIED AC QCNW-2702G QCNW-7581G RRMCG0162A 93GHR19472	- E CCE: EZZ EZZ AJSA 0001	CCESSORIES SORIES J 750hm Coaxial Ca J AV Cable J Infrared Remote C Unit J Battery Cover, Infr Remote Control U	Sable // Control // rared Unit
501 501-2 502-1 502-3 502-4 502-5 502-6 503 504 505 506 507 509 510 511 512 513 514	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GES HBDGD1003GES LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GEZ HDECQ1507GE HDECQ1507GE HDECQ1507GES JBTN-2766GES JBTN-2767GES LHLDZ3041GEZ MSPRD0103GE MSPRP0179GE CBTN-2776GE0	ZZ J SB J SA J SZ J SZ J SA J SSA J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration R/C Cover Cassette Flap Foot Dec.(R) Foot Dec.(L) CH Button Rec Button Magnet Cassette Spring Door Spring	AG AD AV AM AC AA AA AE AH AD AE AD AB AF AB	Α	SUPPLIED AC QCNW-2702G QCNW-7581G RRMCG0162A 93GHR19472	- E CCE: EZZ EZZ AJSA 0001	CCESSORIES SORIES J 750hm Coaxial Ca J AV Cable J Infrared Remote C Unit J Battery Cover, Infr	Sable // Control // rared Unit
501 501-2 502-1 502-3 502-4 502-5 502-6 503 504 505 506 507 509 510 511 512 513 514 514-1	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GE5 HBDGD1003GE5 LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GE3 GCOVA1994GE3 HDECQ1507GE4 HDECQ1507GE5 HDECQ1507GE5 LHLDZ3041GE2 MSPRD0103GE5 MSPRD0103GE6 MSPRP0179GE6 CBTN-2777GE5	ZZ J SB J SB J SCZ J SCZ ZZ SA J SCZ ZZ SA J SCZ ZZ SA J SCZ ZZ J SCZ J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration R/C Cover Cassette Flap Foot Dec.(R) Foot Dec.(L) CH Button Rec Button Magnet Cassette Spring Door Spring Play Botton Ass'y Stop/Pause Button	AG AD AV AM AC AA AA AE AH AD AE AD AB AF AB	A	SUPPLIED AC QCNW-2702G QCNW-7581G RRMCG0162A 93GHR19472	- E CCE: EZZ EZZ AJSA 0001	CCESSORIES SORIES J 750hm Coaxial Ca J AV Cable J Infrared Remote C Unit J Battery Cover, Infr Remote Control U	Sable // Control // rared Unit
501 501-2 502-1 502-3 502-4 502-5 502-6 503 504 505 506 507 509 510 511 512 513 514 514-514-	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GES HBDGD1003GES LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GEZ GCOVA1994GEZ HDECQ1507GEZ HDECQ1507GEZ HDECQ1507GES JBTN-2766GES JBTN-2766GES JBTN-276GES LHLDZ3041GEZ MSPRD0103GEZ MSPRP0179GEZ CBTN-2777GES LHLDZ1974GEZ 3 LHLDZ1974GEZ	ZZ J J J SBB J J J J ZZ ZZ SA J J J S SA J J J J J J J J J J J J J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration R/C Cover Cassette Flap Foot Dec.(L) CH Button Rec Button Magnet Cassette Spring Door Spring Play Botton Ass'y Stop/Pause Button Button Holder	AG AD AW AH AC AA AE AH AD AE AD AB AF AH AH AB	A	SUPPLIED AC QCNW-2702G QCNW-7581G RRMCG0162A 93GHR19472	- E CCE: EZZ EZZ AJSA 0001	CCESSORIES SORIES J 750hm Coaxial Ca J AV Cable J Infrared Remote C Unit J Battery Cover, Infr Remote Control U	Sable // Control // rared Unit
501 501-2 502-1 502-3 502-4 502-5 502-6 503 504 505 506 507 509 510 511 512 513 514 514-1	CBTN-2765GE01 GCOVA1992GEZ CDORF2243GE0 GCOVA2015GE5 HBDGD1003GE5 LANGF9484GE0 PSPAG0019GEZ XESSF20P06000 GCOVA1993GE3 GCOVA1994GE3 HDECQ1507GE4 HDECQ1507GE5 HDECQ1507GE5 LHLDZ3041GE2 MSPRD0103GE5 MSPRD0103GE6 MSPRP0179GE6 CBTN-2777GE5	ZZ J J J SBB J J J J ZZ ZZ SA J J J J J J SBB ZZ SFW J J J J J J J J J J J J J J J J J J J	Power Button Ass'y Power LED Cover Door Ass'y Door Cover SHARP Badge Magnet Angle Spacer Screw Timer/Rec Decoration R/C Cover Cassette Flap Foot Dec.(L) CH Button Rec Button Magnet Cassette Spring Door Spring Play Botton Ass'y Stop/Pause Button Button Holder	AG AD AV AM AC AA AE AH AD AE AE AD AE AE AD AE	A	SUPPLIED AC QCNW-2702G QCNW-7581G RRMCG0162A 93GHR19472	- E CCE: EZZ EZZ AJSA 001	CCESSORIES SORIES J 750hm Coaxial Ca J AV Cable J Infrared Remote C Unit J Battery Cover, Infr Remote Control U	Sable // Control // rared Init






VC-ML3W MACHANICAL PARTS 机械零件分解图 624 В (616) С 626) Ď **(** E 631_© 624 F G (60) Н 624 6 5 4 3 2 1



PRECAUTIONS ON FRONT PANEL SET-UP





Cassette cove 食室壳盖 (2)

Before attaching the front panel in position, make sure that the cassette cover open lever is in its right place (lowermost). If it is out of position, push it down with a finger.

安置胸面板靴位之痢. 必須先检查口蓋并密納 是否實于正当位置(量 下位置)、否制、用手指 向下按压口盖开启情。

Keep the cassette over about 45" open and make sure that the cassette cover open lever is between the front panel and the cassette cover. Now fix the front panel in place.

保持将带盒養填口畫升 启为约45°的状态。然后 确认口量开启物位于前 面板与带盒要填口量之 间,这样便可将前面板 安量な算定位置と、

Do not mount the front panel with the cassette cover tilted too open. Otherwise the cassette cover might wrongly run on the cassette


带鱼装填口盖开启度 过大时,切勿安装前 面板、否则磁填录象 带于盒室机构内时。 会导致其口盖开闭机 作不当.

Removing the cassette compartment cover.

① Open the cassette compartment

- cover fully.
- @ Remove the center positioner.
- 1 Slide the cover to the right.
- Slightly bend the cover.Draw out the left-side rod


盒室壳盖的拆除 ①完全打开盒室壳盖。 ②拆下中心位置控制器。 ③向右方移动盒室壳盖。 ④稍微把盒室壳盖倾斜。 ⑤取出左侧杆。



12. PACKING OF THE SET 包装方法

• Setting position of the Knobs ●各旋钮设定方法

RF Converter (HONG KONG)	at "E36" position	RF Converter (SINGAPORE) 射頻变換器(新加坡)	at "E39" position
射頻变換器(香港)	頻道为 "E36"		頻道为 "E39"
System Switch	at "B/G, I, D/K" position	Test Signal Switch	at "OFF" position
系统开关	"B/G-I-D/K" 位重	灣试信号开关	"OFF" 位置



SHARP

TQ0148-S Printed in Japan 在日本印刷